

INTERFACE BOX FOR R-BUS/ADAT

# DIF-AT24

## Owner's Manual



**Congratulations on your purchase of the Roland DIF-AT24.**

Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" (p. 2, 3) and "IMPORTANT NOTES" (p. 4). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner's Manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.

### Main Features

The DIF-AT24 lets you transfer up to 8 channels of 24-bit digital audio data between an R-BUS device and a device equipped with an ADAT interface.

- \* ADAT is a registered trademark of Alesis Corporation.
- \* All product names mentioned in this document are trademarks or registered trademarks of their respective owners.



**Copyright © 2003 ROLAND CORPORATION**



All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

Roland Web Site: <http://www.roland.co.jp>







# USING THE UNIT SAFELY

## INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About  WARNING and  CAUTION Notices







 <b>WARNING</b>	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
 <b>CAUTION</b>	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols






	The  symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The  symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The  symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

### ALWAYS OBSERVE THE FOLLOWING

#### **WARNING**

- Before using this unit, make sure to read the instructions below, and the Owner's Manual. 
- Do not open or perform any internal modifications on the unit. 
- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page. 
- Never use or store the unit in places that are:
  - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are 
  - Damp (e.g., baths, washrooms, on wet floors); or are 
  - Humid; or are
  - Exposed to rain; or are
  - Dusty; or are
  - Subject to high levels of vibration.
- Make sure you always have the unit placed so it is level and sure to remain stable. Never place it on stands that could wobble, or on inclined surfaces. 

#### **WARNING**

- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.   

- Immediately turn the power off, and request servicing by your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page when: 
  - If smoke or unusual odor occurs
  - Objects have fallen into, or liquid has been spilled onto the unit; or
  - The unit has been exposed to rain (or otherwise has become wet); or
  - The unit does not appear to operate normally or exhibits a marked change in performance.
- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit. 
- Protect the unit from strong impact. (Do not drop it!) 

**⚠ CAUTION**

- Try to prevent cords and cables from becoming entangled. Also, all cords and cables should be placed so they are out of the reach of children.



- Never climb on top of, nor place heavy objects on the unit.



- Disconnect all cords coming from external devices before moving the unit.



This product complies with the requirements of European Directive 89/336/EEC.

For EU Countries

**FEDERAL COMMUNICATIONS COMMISSION  
RADIO FREQUENCY INTERFERENCE STATEMENT**

For the USA

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Unauthorized changes or modification to this system can void the users authority to operate this equipment. This equipment requires shielded interface cables in order to meet FCC class B Limit.

For Canada

**NOTICE**

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

**AVIS**

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

# IMPORTANT NOTES

In addition to the items listed under “USING THE UNIT SAFELY” on page 2, please read and observe the following:

## Power Supply

- Before connecting this unit to other devices, turn off the power to all units. This will help prevent malfunctions and/or damage to speakers or other devices.

## Placement

- This device may interfere with radio and television reception. Do not use this device in the vicinity of such receivers.
- Noise may be produced if wireless communications devices, such as cell phones, are operated in the vicinity of this unit. Such noise could occur when receiving or initiating a call, or while conversing. Should you experience such problems, you should relocate such wireless devices so they are at a greater distance from this unit, or switch them off.
- When moved from one location to another where the temperature and/or humidity is very different, water droplets (condensation) may form inside the unit. Damage or malfunction may result if you attempt to use the unit in this condition. Therefore, before using the unit, you must allow it to stand for several hours, until the condensation has completely evaporated.

## Maintenance

- For everyday cleaning wipe the unit with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a cloth impregnated with a mild, non-abrasive detergent. Afterwards, be sure to wipe the unit thoroughly with a soft, dry cloth.
- Never use benzine, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

## Additional Precautions

- Use a reasonable amount of care when using the unit's switches and when using its jacks and connectors. Rough handling can lead to malfunctions.
- When connecting / disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.

- To avoid disturbing your neighbors, try to keep the unit's volume at reasonable levels (especially when it is late at night).
- When you need to transport the unit, package it in the box (including padding) that it came in, if possible. Otherwise, you will need to use equivalent packaging materials.

## Copyright

- When exchanging audio signals through a digital connection with an external instrument, this unit can perform recording without being subject to the restrictions of the Serial Copy Management System (SCMS). This is because the unit is intended solely for musical production, and is designed not to be subject to restrictions as long as it is used to record works (such as your own compositions) that do not infringe on the copyrights of others. (SCMS is a feature that prohibits second-generation and later copying through a digital connection. It is built into MD recorders and other consumer digital-audio equipment as a copyright-protection feature.)
- Do not use this unit for purposes that could infringe on a copyright held by a third party. We assume no responsibility whatsoever with regard to any infringements of third-party copyrights arising through your use of this unit.

## When connecting to the VM-7100/7200

- The DIF-AT24 will not operate correctly if the VM-7100/7200 system version is earlier than 1.7. Use the following procedure to check the system version, and be sure to update to system version 1.7 or later. For details on updating, please contact the nearest Roland office or service center.

### – To check the version –

1. Connect the VM-7100/7200 to the VM-C7100/C7200.
2. Turn on the power to start up the system.
3. Hold down [On Display] and press numeric key [0].

The version display screen will appear, with an indication like the following:

“Unit X Version: 1.XXX”

4. Note the version number shown in “1.XXX”

# Contents

Main Features .....	1
USING THE UNIT SAFELY .....	2
IMPORTANT NOTES .....	4
<b>Panel descriptions .....</b>	<b>6</b>
Front Panel .....	6
Rear Panel .....	6
<b>Turning the power on/off.....</b>	<b>7</b>
Turning the power on.....	7
Turning the power off.....	7
<b>Connections and settings .....</b>	<b>8</b>
Connection example 1	
Connecting the VS-2400CD and a computer.....	8
Connection example 2	
Connecting the VS-2400CD and a computer.....	10
Connection example 3	
Connecting the VS-2400CD and an ADAT device .....	12
Connection example 4	
Connecting the VS-2400CD with an ADAT device and BRC .....	13
Connection example 5	
Using the DIF-AT24 as an additional MIDI OUT for the MV-8000 .....	15

## Specifications

### DIF-AT24: Interface Box for R-BUS/ADAT

<b>Sampling Frequency</b>	44.1/48kHz
<b>Audio Data Format</b>	16/20/24 bit
<b>Indicators</b>	Power indicator ADAT indicator
<b>Connectors</b>	R-BUS connector ADAT optical connectors in, out MIDI connectors in, out
<b>Power Supply</b>	Supplied from connected R-BUS device
<b>Dimensions</b>	138 (W) x 197 (D) x 43 (H) mm 5-7/16 (W) x 7-13/16 (D) x 1-3/4 (H) inches
<b>Weight</b>	0.5 kg 1 lb 2 oz
<b>Accessories</b>	R-BUS cable (1 m) Owner's manual

\* In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.

# Panel descriptions

## Front Panel



### 1 ADAT indicator


This indicator will light green if an ADAT interface signal is being input to the ADAT digital IN connector.

### 2 POWER indicator

When the R-BUS device connected to the R-BUS connector is powered up, this indicator will light red to indicate that power is being supplied to the DIF-AT24.

\* Power is supplied to the DIF-AT24 via the R-BUS connector.

## Rear Panel



### 3 MIDI IN/OUT connectors

These are used mainly for MTC synchronization.

#### MEMO

The data that is transmitted from the MIDI OUT connector will depend on the settings of the R-BUS device connected to the R-BUS connector.

### 4 MASTER CLK (Master clock) switch

This switches the master clock (sampling clock) synchronization.

MASTER CLK switch	Master clock device
Set to [R-BUS]	When using the R-BUS device connected to the R-BUS connector as the master clock.
Set to [ADAT]	When using the digital device connected to the ADAT OUT/IN connector as the master clock

### 5 ADAT OUT/IN (ADAT digital out/in) connector

This is the ADAT digital interface.

It allows eight channels of digital audio data to be transferred between the DIF-AT24 and an ADAT-compatible digital device.

### 6 R-BUS connector

Provides for the input/output of eight channels of digital audio data, thus allowing the exchange of data between the DIF-AT24 and an R-BUS device to take place. Also transmits/receives synchronization signals.

\* Power is supplied to the DIF-AT24 via the R-BUS connector.

#### NOTE

- Connect only an R-BUS device to the R-BUS connector. You must never connect a device with a SCSI, RS-232C, or parallel interface. Even though the connectors on such devices may look similar, they are incompatible, and damage and/or malfunction could result if you attempt their connection. Also, you must use only a special R-BUS cable to make connections.
- You must turn off the power of the R-BUS device before connecting or disconnecting the R-BUS cable. If you connect or disconnect the cable while power is being supplied, the external R-BUS device will stop working correctly, and the DIF-AT24 or the external R-BUS device may also be damaged.
- The specifications for "R-BUS" are identical to those of RMDB2 and RMDB II. You can use it with any device that is marked "RMDB2" or "RMDB II."
- R-BUS (RMDB2) is not compatible with the older RMDB specification.

# Turning the power on/off

## Turning the power on

Before you turn each device on, make sure that all devices are connected correctly.

Once the connections have been completed, turn on power to your various devices in the order specified. By turning on devices in the wrong order, you risk causing malfunction and/or damage to speakers and other devices.

- 1** Turn on the power of your R-BUS device.  
When power is supplied to the DIF-AT24, its power indicator will light.
- 2** Turn on the power of your computer, ADAT device, etc.
- 3** Turn on the power of your audio device like audio mixers etc.

## Turning the power off

- 1** Turn off the power of your audio device like audio mixers etc.
- 2** Turn off the power of your computer, ADAT device, etc.
- 3** Turn off the power of your R-BUS device.  
Power will no longer be supplied, and the DIF-AT24's power indicator will go out.

# Connections and settings

## Connection example 1


## Connecting the VS-2400CD and a computer

Here's an example of synchronization with computer-based sequencer software or the VS-2400CD functioning as the master.

Make connections as shown in the diagram. This example uses the UA-1000 to perform input/output with the computer via USB 2.0.



To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.






## Settings

### ■ Sampling Frequency settings

Set the sampling frequency of your sequencer software, the VS-2400CD, and the UA-1000 to the same setting (44.1 kHz or 48 kHz).

### ■ Master Clock settings

Master clock device	VS-2400CD setting	DIF-AT24 MASTER CLK switch
VS-2400CD	PROJECT PARAMETER screen ○ MASTER CLOCL.....INT	R-BUS
Sequencer software	PROJECT PARAMETER screen ○ MASTER CLOCL.....R-BUS	ADAT

 You'll also need to set the Master Clock for your sequencer software. For details on this setting, refer to the owner's manual for your sequencer software.

### ■ Synchronization settings

Set the VS-2400CD's parameters as follows.


#### MMC settings

If using the sequencer software as the MMC master	If using the VS-2400CD as the MMC master
MIDI PARAMETER screen ○ SysEx. Rx. Sw ..... On ○ MMC MODE..... SLAVE ○ MMC SOURCE..... R-BUS	MIDI PARAMETER screen ○ MIDI OUT/THRU ..... Out ○ SysEx. Tx. Sw ..... On ○ MMC MODE..... MASTER

#### MTC settings

If using the sequencer software as the MMC master	If using the VS-2400CD as the MMC master
SYNC PARAMETER screen ○ SYNC MODE ..... EXT ○ EXT SYNC SOURCE..... R-BUS ○ FRAME RATE..... Same setting as the software.*	SYNC PARAMETER screen ○ SYNC MODE ..... INT ○ FRAME RATE..... Select the MTC type.* ○ MIDI OUT SYNC Gen ..... MTC

\* Check the specifications of your sequencer software, and set your software and the VS-2400CD to the same frame rate.

 In order to synchronize operation with your sequencer software, you'll also need to make settings in the sequencer software. For details on these settings, refer to the owner's manual for your sequencer software.


Connection example 2

## Connecting the VS-2400CD and a computer

Here's an example of synchronization with computer-based sequencer software or the VS-2400CD functioning as the master.

Make connections as shown in the diagram. This example uses an ADAT interface and MIDI interface connected to your computer.

**NOTE** To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.



## Settings

### ■ Sampling Frequency settings

Set the sampling frequency of your sequencer software and the VS-2400CD to the same setting (44.1 kHz or 48 kHz).

### ■ Master Clock settings

Master clock device	VS-2400CD setting	DIF-AT24 MASTER CLK switch
VS-2400CD	PROJECT PARAMETER screen ○ MASTER CLOCL.....INT	R-BUS
Sequencer software	PROJECT PARAMETER screen ○ MASTER CLOCL.....R-BUS	ADAT

**MEMO** You'll also need to set the Master Clock for your sequencer software. For details on this setting, refer to the owner's manual for your sequencer software.

### ■ Synchronization settings

Set the VS-2400CD's parameters as follows.

#### MMC settings

If using the sequencer software as the MMC master	If using the VS-2400CD as the MMC master
MIDI PARAMETER screen ○ SysEx. Rx. Sw ..... On ○ MMC MODE..... SLAVE ○ MMC SOURCE..... R-BUS	MIDI PARAMETER screen ○ MIDI OUT/THRU ..... Out ○ SysEx. Tx. Sw ..... On ○ MMC MODE..... MASTER

#### MTC settings

If using the sequencer software as the MMC master	If using the VS-2400CD as the MMC master
SYNC PARAMETER screen ○ SYNC MODE ..... EXT ○ EXT SYNC SOURCE..... R-BUS ○ FRAME RATE..... Same setting as the software.*	YNC PARAMETER screen ○ SYNC MODE ..... INT ○ FRAME RATE..... Select the MTC type.* ○ MIDI OUT SYNC Gen ..... MTC

\* Check the specifications of your sequencer software, and set your software and the VS-2400CD to the same frame rate.

**MEMO** In order to synchronize operation with your sequencer software, you'll also need to make settings in the sequencer software. For details on these settings, refer to the owner's manual for your sequencer software.


Connection example 3

Connecting the VS-2400CD and an ADAT device

This example allows digital audio signals to be transferred. Make connections as shown in the diagram.



To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.



Settings

■ Sampling Frequency settings

Set the sampling frequency of the VS-2400CD and ADAT device to the same setting (44.1 kHz or 48 kHz).

■ Master Clock settings

Master clock device	VS-2400CD setting	DIF-AT24 MASTER CLK switch
VS-2400CD	PROJECT PARAMETER screen ○ MASTER CLOCL.....INT	R-BUS
ADAT device	PROJECT PARAMETER screen ○ MASTER CLOCL.....R-BUS	ADAT



You'll also need to set the Master Clock for the ADAT device. For details on this setting, refer to the owner's manual for the ADAT device.


Connection  
example 4

## Connecting the VS-2400CD with an ADAT device and BRC

The BRC is used to operate the VS-2400CD and ADAT device in synchronization. Make connections as shown in the diagram.



To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.



## Settings

### ■ Sampling Frequency settings

Set the sampling frequency of the VS-2400CD and ADAT device to the same setting (48 kHz).

### ■ Master Clock settings

Master clock device	VS-2400CD setting	DIF-AT24 MASTER CLK switch
VS-2400CD	PROJECT PARAMETER screen ○ MASTER CLOCL.....INT	R-BUS
ADAT device	PROJECT PARAMETER screen ○ MASTER CLOCL.....R-BUS	ADAT

 You'll also need to set the Master Clock for the ADAT device. For details on this setting, refer to the owner's manual for the ADAT device.

### ■ Synchronization settings

Set the VS-2400CD's parameters as follows.

MIDI PARAMETER screen

- SysEx. Rx. Sw. On
- MMC MODE..SLAVE
- MMC SOURCER-BUS

SYNC PARAMETER screen

- SYNC MODE.EXT
- EXT SYNC SOURCER-BUS
- FRAME RATE..... Same setting as the software.\*

### ■ BRC settings

- 1** Press [EDIT] → [GEN SYNC] → [GEN SYNC].  
The screen will indicate "Generate Sync."
- 2** Use [▲][▼] to select "MIDI: MTC," and press [EDIT].  
[EDIT] will go dark.
- 3** Press [GEN SYNC].  
[GEN SYNC] will light, and the BRC will output MTC.

**Connection  
example 5**
**Using the DIF-AT24 as an additional MIDI OUT for the MV-8000**


Make connections as shown in the diagram.



To prevent malfunction and/or damage to speakers or other devices, always turn down the volume, and turn off the power on all devices before making any connections.



In order to make these connections, the MV8-OP1 (audio I/O expansion; sold separately) must be installed in the MV-8000.


**Settings**
**■ MV-8000 settings**
**1**

Press the [SEQUENCE] button.

The SEQUENCE screen will appear.

**2**

Move the cursor to the track whose MIDI settings you want to make.

**3**

Press function button [F1 (Track Param)].

The TRACK PARAMETER screen will appear.

**4**

In the TRACK PARAMETER screen, move the cursor to "MIDI," and select "R-1"–"R-16" as the MIDI channel on which the track will be transmitted via R-BUS.

## Information

When you need repair service, call your nearest Roland Service Center or authorized Roland distributor in your country as shown below.

### AFRICA

#### EGYPT

**AI Fanny Trading Office**  
9, EBN Hagar Al Askalany Street,  
ARD El Golf, Heliopolis,  
Cairo 11341, EGYPT  
TEL: 20-2-417-1828

#### REUNION

**Maison FO - YAM Marcel**  
25 Rue Jules Hermand,  
Chaudron - BP79 97 491  
Ste Clotilde Cedex,  
REUNION ISLAND  
TEL: (0262) 218-429

#### SOUTH AFRICA

**That Other Music Shop  
(PTY) Ltd.**  
11 Melle St., Braamfontein,  
Johannesburg, SOUTH AFRICA  
P.O.Box 32918, Braamfontein 2017  
Johannesburg, SOUTH AFRICA  
TEL: (011) 403 4105

#### Paul Bothner (PTY) Ltd.

17 Werdmuller Centre,  
Main Road, Claremont 7708  
SOUTH AFRICA  
P.O. BOX 23032, Claremont 7735,  
SOUTH AFRICA  
TEL: (021) 674 4030

### ASIA

#### CHINA

**Roland Shanghai Electronics  
Co.Ltd.**  
5F, No.1500 Pingliang Road  
Shanghai 200090, CHINA  
TEL: (021) 5580-0800

#### Roland Shanghai Electronics Co.Ltd.

**(BEIJING OFFICE)**  
10F, No.18 Anhuaxili  
Chaoyang District, Beijing 100011  
CHINA  
TEL: (010) 6426-5050

#### Roland Shanghai Electronics Co.Ltd.

**(GUANGZHOU OFFICE)**  
2/F, No.30 Si You Nan Er Jie Yi  
Xiang, Wu Yang Xin Cheng,  
Guangzhou 510600, CHINA  
TEL: (020) 8736-0428

#### HONG KONG

**Tom Lee Music Co., Ltd.  
Service Division**  
22-32 Pun Shan Street, Tsuen  
Wan, New Territories,  
HONG KONG  
TEL: 2415 0911

#### Parsons Music Ltd.

8th Floor, Railway Plaza, 39  
Chatham Road South, T.S.T.  
Kowloon, HONG KONG  
TEL: 2333 1863

#### INDIA

**Rivera Digitec (India) Pvt. Ltd.**  
409, Nirman Kendra Mahalaxmi  
Flats Compound Off. Dr. Edwin  
Moses Road, Mumbai-400011,  
INDIA  
TEL: (022) 2493 9051

#### INDONESIA

**PT Citra IntiRama**  
Jl. Cideng Timur No. 151-150  
Jakarta Pusat  
INDONESIA  
TEL: (021) 6324170

#### KOREA

**Cosmos Corporation**  
1461-9, Seocho-Dong,  
Seocho Ku, Seoul, KOREA  
TEL: (02) 3486-8855

#### MALAYSIA

**BENTLEY MUSIC SDN BHD**  
140 & 142, Jalan Bukit Bintang  
55100 Kuala Lumpur, MALAYSIA  
TEL: (03) 2144-3333

#### PHILIPPINES

**G.A. Yupango & Co. Inc.**  
339 Gil J. Puyat Avenue,  
Makati, Metro Manila 1200,  
PHILIPPINES  
TEL: (02) 899 9801

#### SINGAPORE

**Swee Lee Company**  
150 Sims Drive,  
SINGAPORE 387381  
TEL: 6846-3676

#### CRISTOFORI MUSIC PTE LTD

Blk 3014, Bedok Industrial Park E,  
#02-2148, SINGAPORE 489980  
TEL: 6243-9555

#### TAIWAN

**ROLAND TAIWAN  
ENTERPRISE CO., LTD.**  
Room 5, 9fl. No. 112 Chung Shan  
N.Road Sec.2, Taipei, TAIWAN,  
R.O.C.  
TEL: (02) 2561 3339

#### THAILAND

**Theera Music Co., Ltd.**  
330 Veng NakornKasem, Soi 2,  
Bangkok 10100, THAILAND  
TEL: (02) 2248821

#### VIETNAM

**Saigon Music**  
Suite DP-8  
40 Ba Huyen Thanh Quan Street  
Hochiminh City, VIETNAM  
TEL: (08) 930-1969

### AUSTRALIA/ NEW ZEALAND

#### AUSTRALIA

**Roland Corporation  
Australia Pty., Ltd.**  
38 Campbell Avenue  
Dee Why West, NSW 2099  
AUSTRALIA  
TEL: (02) 9982 8266

#### NEW ZEALAND

**Roland Corporation Ltd.**  
32 Shaddock Street, Mount Eden,  
Auckland, NEW ZEALAND  
TEL: (09) 3098 715

### CENTRAL/LATIN AMERICA

#### ARGENTINA

**Instrumentos Musicales S.A.**  
Av.Santa Fe 2055  
(1123) Buenos Aires  
ARGENTINA  
TEL: (011) 4508-2700

#### BRAZIL

**Roland Brasil Ltda**  
Rua San Jose, 780 Sala B  
Parque Industrial San Jose  
Cotia - Sao Paulo - SP, BRAZIL  
TEL: (011) 4615 5666

#### COSTA RICA

**JUAN BANSBACH  
Instrumentos Musicales**  
Ave.1, Calle 11, Apartado 10237,  
San Jose, COSTA RICA  
TEL: 238-0211

#### CHILE

**Comercial Fancy II S.A.**  
Rut.: 96.919.420-1  
Nataaniel Cox #739, 4th Floor  
Santiago - Centro, CHILE  
TEL: (02) 688-9540

#### EL SALVADOR

**OMNI MUSIC**  
75 Avenida Norte y Final  
Alameda Juan Pablo II,  
Edificio No.4010 San Salvador,  
EL SALVADOR  
TEL: 262-0788

#### MEXICO

**Casa Veerkamp, s.a. de c.v.**  
Av. Toluca No. 323, Col. Olivar  
de los Padres 01780 Mexico D.F.  
MEXICO  
TEL: (55) 5668-6699

#### PANAMA

**SUPRO MUNDIAL, S.A.**  
Boulevard Andrews, Albrook,  
Panama City, REP. DE PANAMA  
TEL: 315-0101

#### PARAGUAY

**Distribuidora De  
Instrumentos Musicales**  
J.E. Olear y ESQ. Manduvira  
Asuncion PARAGUAY  
TEL: (021) 492-124

#### URUGUAY

**Todo Musica S.A.**  
Francisco Acuna de Figueroa 1771  
C.P.: 11.800  
Montevideo, URUGUAY  
TEL: (02) 924-2335

#### VENEZUELA

**Musiland Digital C.A.**  
Av. Francisco de Miranda,  
Centro Parque de Cristal, Nivel  
C2 Local 20 Caracas  
VENEZUELA  
TEL: (212) 285-8586

### EUROPE

#### AUSTRIA

**Roland Austria GES.M.B.H.**  
Siemenstrasse 4, P.O. Box 74,  
A-6063 RUM, AUSTRIA  
TEL: (0512) 26 44 260

#### BELGIUM/HOLLAND/ LUXEMBOURG

**Roland Benelux N. V.**  
Houtstraat 3, B-2260, Oevel  
(Westerlo) BELGIUM  
TEL: (014) 575811

#### CZECH REP.

**K-AUDIO**  
Kardasovska 626,  
CZ-198 00 Praha 9,  
CZECH REP.  
TEL: (2) 666 10529

#### DENMARK

**Roland Scandinavia A/S**  
Nordhavnsvej 7, Postbox 880,  
DK-2100 Copenhagen  
DENMARK  
TEL: 3916 6200

#### FRANCE

**Roland France SA**  
4, Rue Paul Henri SPAAK,  
Parc de l'Esplanade, F 77 462 St.  
Thibault, Lagny Cedex FRANCE  
TEL: 01 600 73 500

#### FINLAND

**Roland Scandinavia As,  
Filial Finland**  
Elanontie 5  
FIN-01510 Vantaa, FINLAND  
TEL: (09) 68 24 020

#### GERMANY

**Roland Elektronische  
Musikinstrumente HmbH.**  
Oststrasse 96, 22844 Norderstedt,  
GERMANY  
TEL: (040) 52 60090

#### GREECE

**STOLLAS S.A.**  
Music Sound Light  
155, New National Road  
Patras 26442, GREECE  
TEL: 2610 435400

#### HUNGARY

**Roland East Europe Ltd.**  
Warehouse Area "DEPO" P/83  
H-2046 Torokbalint, HUNGARY  
TEL: (23) 511011

#### IRELAND

**Roland Ireland**  
G2 Calmount Park, Calmount  
Avenue, Dublin 12  
Republic of IRELAND  
TEL: (01) 4294444

#### ITALY

**Roland Italy S. p. A.**  
Viale delle Industrie 8,  
20020 Aresè, Milano, ITALY  
TEL: (02) 937-78300

#### NORWAY

**Roland Scandinavia Avd.  
Kontor Norge**  
Lilleakerveien 2 Postboks 95  
Lilleaker N-0216 Oslo  
NORWAY  
TEL: 2273 0074

#### POLAND

**MX MUSIC SP.Z.O.O.**  
Ul. Gibraltarska 4,  
PL-03664 Warszawa POLAND  
TEL: (022) 679 44 19

#### PORTUGAL

**Tecnologias Musica e Audio,  
Roland Portugal, S.A.**  
Cais Des Pedras, 8/9-1 Dto  
4050-465 PORTO  
PORTUGAL  
TEL: (022) 608 00 60

#### ROMANIA

**FBS LINES**  
Piata Libertatii 1,  
535500 Gheorgheni, ROMANIA  
TEL: (266) 604 609

#### RUSSIA

**MuTeK**  
3-Bogatyrskaya Str. 1.k.1  
107 564 Moscow, RUSSIA  
TEL: (095) 169 5043

#### SPAIN

**Roland Electronics  
de España, S. A.**  
Calle Bolivia 239, 08020  
Barcelona, SPAIN  
TEL: (93) 308 1000

#### SWEDEN

**Roland Scandinavia A/S  
SWEDISH SALES OFFICE**  
Danvik Center 28, 2 tr.  
S-131 30 Nacka, SWEDEN  
TEL: (08) 702 00 20

#### SWITZERLAND

**Roland (Switzerland) AG**  
Landstrasse 5, Postfach,  
CH-4452 Itingen,  
SWITZERLAND  
TEL: (061) 927-8383

#### UKRAINE

**TIC-TAC**  
Mira Str. 19/108  
P.O. Box 180  
295400 Munkachevo, UKRAINE  
TEL: (03131) 414-40

#### UNITED KINGDOM

**Roland (U.K.) Ltd.**  
Atlantic Close, Swansea  
Enterprise Park, SWANSEA  
SA7 9JF  
UNITED KINGDOM  
TEL: (01792) 702701

### MIDDLE EAST

#### BAHRAIN

**Moon Stores**  
No.16, Bab Al Bahrain Avenue,  
P.O. Box 247, Manama 304,  
State of BAHRAIN  
TEL: 211 005

#### CYPRUS

**Radex Sound Equipment Ltd.**  
17, Diagorou Street, Nicosia,  
CYPRUS  
TEL: (022) 66-9426

#### IRAN

**MOCO, INC.**  
No.41 Nike St., Dr.Shariyati Ave.,  
Roboeyeh Cerah Mirdamad  
Tehran, IRAN  
TEL: (01) 4294449

#### ISRAEL

**Halilit P. Greenspoon &  
Sons Ltd.**  
8 Retzif Ha'aluya Hashnya St.  
Tel-Aviv-Yafo ISRAEL  
TEL: (03) 6823666

#### JORDAN

**AMMAN Trading Agency**  
245 Prince Mohammad St.,  
Amman 1118, JORDAN  
TEL: (06) 464-1200

#### KUWAIT

**Easa Husain Al Youusif Est.**  
Abdullah Salem Street,  
Safat, KUWAIT  
TEL: 243-6399

#### LEBANON

**Chahine S.A.L.**  
Gerge Zeidan St., Chahine Bldg.,  
Achrafieh, P.O.Box: 16-5857  
Beirut, LEBANON  
TEL: (01) 20-1441

#### QATAR

**Al Emadi Co. (Badie Studio  
& Stores)**  
P.O. Box 82, Doha, QATAR  
TEL: 4423-554

#### SAUDI ARABIA

**aDavliah Universal  
electronics APL**  
Corniche Road, Aldorsayy Bldg.,  
1st Floor, Alkhuba,  
SAUDI ARABIA  
P.O.Box 2154, Alkhuba 31952  
SAUDI ARABIA  
TEL: (013) 898 2081

#### SYRIA

**Technical Light & Sound  
Center**  
Khaled Ebn Al Walid St.  
Bldg. No. 47, P.O.BOX 13520,  
Damascus, SYRIA  
TEL: (011) 223-3384

#### TURKEY

**Ant Muzik Aletleri Ithalat  
Ve Ihracat Ltd Sti**  
Siraselviler Caddesi Siraselviler  
Pasaji No:74/20  
Taksim - Istanbul, TURKEY  
TEL: (0212) 2499324

#### U.A.E.

**Zak Electronics & Musical  
Instruments Co. L.L.C.**  
Zabeel Road, Al Sherouq Bldg.,  
No. 14, Grand Floor, Dubai, U.A.E.  
TEL: (04) 3380715

### NORTH AMERICA

#### CANADA

**Roland Canada Music Ltd.  
(Head Office)**  
5480 Parkwood Way Richmond  
B. C., V6V 2M4 CANADA  
TEL: (604) 270 6626

#### Roland Canada Music Ltd. (Toronto Office)

170 Admiral Boulevard  
Mississauga On L5T 2N6  
CANADA  
TEL: (905) 362 9707

#### U. S. A.

**Roland Corporation U.S.**  
5100 S. Eastern Avenue  
Los Angeles, CA 90040-2938,  
U. S. A.  
TEL: (323) 890 3700

As of November 1, 2003 (Roland)

This owner's manual is printed on recycled paper.

# Roland Corporation

03454012

'03-11-1KS



# VM-7100/7200 と接続する場合

VM-7100/7200 のシステム・バージョンが 1.7 未満の場合、DIF-AT24 は正常に動作しません。以下の方法で VM-7100/7200 のバージョンを確認し、必ず 1.7 以降にバージョンアップしてください。

バージョンアップに関しては、最寄の弊社営業所またはローランド・サービス・ステーションまでお問い合わせください。

## バージョンの表示方法

- 1 VM-7100/7200 を VM-C7100/C7200 と接続します。
- 2 電源を入れ、起動させます。
- 3 [ On Display ] を押しながらテン・キー [ 0 ] を押します。  
バージョン表示画面になり、次のように表示されます。  
「Unit X Version : 1.XXX」
- 4 画面の「1.XXX」でバージョンの確認をしてください。

# When connecting to the VM-7100/7200

The DIF-AT24 will not operate correctly if the VM-7100/7200 system version is earlier than 1.7.

Use the following procedure to check the system version, and be sure to update to system version 1.7 or later.

For details on updating, please contact the nearest Roland office or service center.

## ■ To check the version

- 1 Connect the VM-7100/7200 to the VM-C7100/C7200.
- 2 Turn on the power to start up the system.
- 3 Hold down [On Display] and press numeric key [0].  
The version display screen will appear, with an indication like the following:  
“Unit X Version: 1.XXX”
- 4 Note the version number shown in “1.XXX”