

# Roland

## EM-55

INTERACTIVE KEYBOARD

Owner's Manual

For EU Countries



This product complies with the requirements of European Directive 89/336/EEC.

For the USA

## FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Unauthorized changes or modification to this system can void the users authority to operate this equipment.  
This equipment requires shielded interface cables in order to meet FCC class B Limit.

For Canada

### NOTICE

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

### AVIS

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

# Roland

## EM-55

### INTERACTIVE KEYBOARD

#### Owner's Manual

ENGLISH

Thank you for choosing a Roland EM-55 Interactive Keyboard, the perfect arranger instrument for countless hours of pure, unadulterated fun. Thanks to its novel integration of DJ-like functions, the EM-55 will take your musical endeavours to a completely new level.

To get the most out of the EM-55 and to ensure many years of trouble-free service, we urge you to read through this Owner's Manual thoroughly.

To avoid confusion, let's agree to use the word "button" for all keys on the front panel, and only use "key" when referring to the EM-55's keyboard.

Before using this instrument, carefully read the sections entitled "Important Safety Instructions" and "Important notes". They provide important information concerning the proper operation of the EM-55. Be sure to keep this manual in a safe place for future reference.

## Features

### Session Partner function

The EM-55's new Session Partner concept encompasses three functions: you can switch on/mute the Arranger's accompaniment parts; you can select from among 8 phrase patterns to be played either in isolation or together with the selected Music Style; or you can use the eight Session Partner buttons DJ style: to create remixes of existing phrases.

The Session Partner buttons can also be used for muting and switching on individual tracks of the 16-track Recorder, allowing you to be creative even with your recorded music.

### EZ Search & Music Assistant

The EZ Search function allows you to quickly locate the desired Music Style or Tone.

The EM-55 also provides a Music Assistant function for direct access to 100 User Programs (registrations).

### Style Morphing and Orchestrator functions

Style Morphing allows you to "create" new Music Styles (accompaniments) on the fly by replacing selected accompaniment parts of one Style with the parts from another Style.

The Orchestrator function, on the other hand, allows you to simplify, add, or leave out accompaniment parts of the selected Music Style. This intuitive way of controlling the arrangements of your accompaniments is a wonderful assistant for creating just the right atmosphere for the music you play.

### Graphic display

Your EM-55 is equipped with a backlit display that keeps you posted about the current status of your instrument. Most functions are represented by means of straightforward icons that provide massive at-a-glance information without confusing you.

### 64 User Programs

User Programs are memories where you can save your own panel settings. These include the currently selected Style, Tone (sound), tempo, as well as a lot of other parameters. At the press of a maximum of two buttons, you can thus completely reconfigure your instrument.

### 3,559 Tones and 116 Drum Sets

The EM-55 comes with 3,559 excellent instrument sounds taken from Roland's acclaimed VA-series sound library. In most instances, there will be several Tones to choose from for the song you are about to play.

The EM-55's sound source conforms to General MIDI System Level 2 (GM2 for short) as well as Roland's GS Format.

### 64 Music Styles

The EM-55 contains 64 Music Styles that will supply a perfect accompaniment for your solo playing. Each Music Style includes several "Divisions" that allow you to vary the accompaniment. Coupled with the Style Morphing and Orchestrator functions, the total number of accompaniment patterns adds up to far more than 64.

### Three modes

For enhanced operation, the EM-55 provides an M. Drums, Arranger, and a Piano mode. Pressing one of these button will immediately reconfigure your Interactive Keyboard.

# 1. Important notes

In addition to the items listed under "Important Safety Instructions", please read and observe the following:

## Power supply

- Do not use this instrument on the same power circuit with any device that will generate line noise (such as an electric motor or variable lighting system).
- Be sure to only use the supplied adapter (Roland ACJ). The use of other adapters may damage your EM-55.
- Before connecting the EM-55 to other devices, turn off the power to all units. This will help prevent malfunctions and/or damage to speakers or other devices.

## Placement

- Using the EM-55 near power amplifiers (or other equipment containing large power transformers) may induce hum. To alleviate the problem, change the orientation of this instrument or move it farther away from the source of interference.
- This instrument may interfere with radio and television reception. Do not use it in the vicinity of such receivers.
- Do not expose the EM-55 to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the instrument.

## Maintenance

- For everyday cleaning wipe the EM-55 with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a mild, non-abrasive detergent. Afterwards, be sure to wipe the instrument thoroughly with a soft, dry cloth.
- Never use benzene, thinner, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

## Repairs and data


- Please be aware that all data contained in the instrument's memory may be lost when it is sent for repairs. In certain cases (such as when circuitry related to memory itself is out of order), we regret that it may not be possible to restore the data. Roland assumes no liability concerning such loss of data.

## Additional precautions

- Please be aware that the memory contents can be irretrievably lost as a result of a malfunction, or the improper operation of the instrument.
- Use a reasonable amount of care when using the instrument's buttons, other controls, and jacks/connectors. Rough handling can lead to malfunctions.
- Never strike or apply strong pressure to the display.
- When connecting/disconnecting cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.
- A small amount of heat will radiate from the instrument during normal operation. This is perfectly normal.
- To avoid disturbing your neighbors, try to keep the instrument's volume at reasonable levels. You may prefer to use headphones, so you do not need to be concerned about those around you (especially late at night).
- When you need to transport the instrument, package it in the box (including padding) that it came in. Otherwise, you will need to use equivalent packaging materials, or a flightcase.

## Handling floppy disks

- Floppy disks contain a plastic disk with a thin magnetic coating. Microscopic precision is required to enable storage of large amounts of data on such a small surface area. To preserve their integrity, please observe the following when handling floppy disks:
  - Never touch the magnetic medium inside the disk.
  - Do not use or store floppy disks in dirty or dusty areas.
  - Do not subject floppy disks to temperature extremes (e.g., direct sunlight in an enclosed vehicle). Recommended temperature range: 10° to 50°C (50 to 122°F).
  - Do not expose floppy disks to strong magnetic fields, such as those generated by loudspeakers.
  - Floppy disks have a "WRITE" tab which can protect the disk from accidental erasure. It is recommended that the tab be kept in the PROTECT position, and moved to the WRITE position only when you wish to write new data onto the disk.




- Disks containing important performance data for this instrument should always be locked (have their write protect tab slid to the PROTECT position) before you insert them into the drive of another instrument.
- The identification label should be firmly affixed to the disk. If the label comes loose while the disk is in the drive, it may be difficult to remove the disk.
- Put the disk back into its case for storage.

# Contents

1. Important notes .....	3	11. Performance functions .....	33
2. Panel descriptions .....	5	Keyboard Velocity .....	33
Rear panel .....	7	Pitch Bend and Modulation .....	33
3. First steps .....	8	Footswitch/Expression .....	34
Setting up .....	8	D Beam functions .....	34
Demo songs .....	8	12. Recorder functions .....	36
DJ Pad function .....	9	About the recording modes .....	36
Musical Games .....	10	Playback functions .....	39
4. Playing with accompaniment .....	13	Playing back Standard MIDI Files .....	41
Selecting other Music Styles .....	14	13. Function menu .....	42
<i>Style selection via EZ Search</i> .....	15	14. Working with User Programs .....	47
Selecting sounds for the right hand .....	15	Writing your settings to a User Program .....	47
<i>Tone selection via EZ Search</i> .....	16	Selecting a User Program .....	48
5. Playing one sound (Piano) .....	17	15. MIDI functions .....	49
Playing a different sound with the left hand		MIDI Function parameters .....	49
(Split) .....	17	16. Using the outputs and an optional pedal .....	51
6. Drumming on the keyboard .....	18	17. Disk functions .....	52
7. Using the D Beam Controller .....	19	Loading User Programs from disk .....	52
8. Recording your music .....	20	Saving files to disk .....	52
9. Additional Music Style functions .....	21	Deleting files on disk .....	53
Session Partner functions .....	21	Disk Copy (copying an entire disk) .....	54
<i>Muting Arranger parts (Track)</i> .....	21	Format .....	55
<i>Adding yet another Arranger part (Style Pad)</i> .....	22	Functions for educational purposes .....	56
One Touch .....	23	18. Miscellaneous .....	56
Using the EM-55's Music Assistant .....	23	Initializing your EM-55 (Factory) .....	56
Melody Intelligence .....	24	19. Specifications .....	57
Bass Inversion (Bass Inv) .....	24	20. Index .....	58
Orchestrator .....	25	21. Tone List .....	175
Style Morphing .....	25	Tones that can be selected via the BANK/NUMBER/	
Working with Styles on floppy disk .....	26	VARIATION buttons .....	175
More Music Style functions .....	27	Tones only selectable via the EZ Search function .....	180
10. More Keyboard part functions .....	28	22. Music Style list .....	187
Using the Upper 2 part .....	28	23. Drum Sets .....	188
Selecting Tone Variations .....	28	24. Chord Intelligence .....	206
Using the multi-effects processor (M-FX) .....	29		
Reverb and Chorus .....	30		
Balance .....	31		
Transpose .....	32		
Other Keyboard part functions .....	32		

## 2. Panel descriptions

- ① **POWER ON button**  
Press this button to switch the EM-55 on and off.
- ② **BENDER/MODULATION lever**  
By performing left/right movements, you can bend your solo notes down (left) or up (right). Press this lever towards the rear of the instrument to add modulation (usually vibrato) to the notes you are playing.
- ③ **D Beam Controller**  
This controller allows you to influence the timbre of the notes you play, to control the Arranger, and to create some unique effects. All you need to do is move your hand up/down or left/right above the two "eyes". The buttons allow you to assign the desired function to the D Beam Controller. See p. 34.
- ④ **VOLUME knob**  
Use this knob to set the global volume of your EM-55.
- ⑤ **DEMO button**  
Press this button whenever you want to listen to the EM-55's demo songs (see p. 8).
- ⑥ **BALANCE [◀ACCOMP] [KEYBOARD ▶] buttons**  
Use the BALANCE buttons to change the volume of the corresponding section (accompaniment/song, or the parts you play on the keyboard).
- ⑦ **STYLE MORPHING buttons**  
Use these three buttons to create a new Style from two existing ones. See page 25 for details.
- ⑧ **ORCHESTRATOR buttons**  
Press one of these buttons to choose the desired orchestration for the selected Music Style. See page 25.
- ⑨ **Display**  
This is where you will find comprehensive information about the EM-55's current status, the functions that are available, the parameter values, etc.
- ⑩ **MUSICAL GAME button**  
Press this button if you want to learn more about the "nuts and bolts" of music – or just to have some fun with your EM-55.
- ⑪ **SONG button**  
This button allows you to select the EM-55's Song mode, and to specify that the [INTRO], [ORIGINAL], etc., buttons should be used to operate the on-board Recorder.



- ⑫ **STYLE button**  
Press this button if you want to select Music Styles. By activating this button, you also specify that the [INTRO], [ORIGINAL], etc., buttons are used for selecting a Style Division, while the [1]~[8] buttons can be used to select the desired Style memory (11~64). In DJ PAD mode, the [STYLE] button can be used for selecting the desired DJ phrase set.  
**Note:** Styles can also be selected via the EZ Search function (see p. 15).
- ⑬ **TONE button**  
Press this button if you want to use the [A/B] and [1]~[8] buttons for assigning a sound ("Tone") to the selected Keyboard part. See p. 15.  
**Note:** Tones can also be selected via the EZ Search function (see p. 16).
- ⑭ **USER PROGRAM/WRITE button**  
Press this button whenever you want to select a User Program (a set of registrations). Press and hold it to save the current panel and parameter settings to a User Program. See page 47.
- ⑮ **MUSIC ASSISTANT button**  
This button allows you to work with preprogrammed registrations (additional User Programs). See p. 23.
- ⑯ **METRONOME button**  
This button is used to switch the metronome on and off. Holding it for more than one second calls up a FUNCTION parameter you can set.
- ⑰ **MX EFFECTS button**  
This button allows you to switch the multi-effects processor on/off, to assign it to the desired Keyboard part, and to select the effect you need in a given situation. Holding it for more than one second calls up a FUNCTION parameter you can set. See p. 29.
- ⑱ **MELODY INTELL button**  
This button allows you to switch the Melody Intelligence function on/off. This function adds a harmony part to your melody playing. See p. 24. Holding it for more than one second calls up a FUNCTION parameter you can set for selecting the harmony type.
- ⑲ **TRANSPOSE button**  
Press this button to transpose the keyboard (see p. 32). Holding it for more than one second calls up a FUNCTION parameter you can set.
- ⑳ **REC button**  
This button allows you to engage the EM-55's record function.
- ㉑ **Style/Song control buttons**  
(INTRO, ORIGINAL, FILL, etc.) These buttons allow you to select the Music Style division (after pressing the [STYLE] button) or to control the EM-55's Recorder (after pressing [SONG]).
- ㉒ **EZ SEARCH button**  
This button allows you to quickly select the desired Music Style, Tone, or Drum Set. See p. 15 and p. 16.

- ㉓ **TEMPO/DATA dial**  
This dial is used for setting the tempo, parameter values, and for selecting Music Styles, Tones, or Drum Sets via the EZ SEARCH function.
- ㉔ **DISK button**  
Press this button to access the Disk functions. They are used for loading data from floppy, saving data to disk, and managing floppy disks. See p. 52.
- ㉕ **EXECUTE/TAP TEMPO button**  
In FUNCTION and DISK modes, this button allows you to confirm an operation. Outside those two modes, this button can be used for setting the tempo by pressing it repeatedly. Hold it down for a few seconds to return to the pre-programmed tempo.  
In FUNCTION mode, holding it down will recall the default value for the selected parameter.

- ㉖ **FUNCTION button**  
This button provides access to the FUNCTION menu. You can hold it down and use the BANK/NUMBER buttons for directly selecting one of the eight functions of the list to the right of this button.
- ㉗ **SESSION PARTNER PADS/TRACKS section**  
These buttons provide access to the EM-55's Session Partner function. They can also be used for muting and switching on Recorder tracks.
- ㉘ **KEYBOARD MODE buttons**  
These buttons allow you to specify how you want to use your EM-55:

Button	Function
M.DRUMS	You can drum on the keyboard.
ARRANGER	The chords you play with your left hand are used to transpose the automatic accompaniment in realtime. With your right hand, you can play solos.
PIANO	A piano sound is assigned to the entire keyboard. (Only the Arranger drums are available.)

- ㉙ **ONE TOUCH buttons (1-2, 3-4)**  
Press one of these buttons to select the desired One Touch memory. To select memory "2" or "4", you need to press the corresponding button twice. One Touch memories contain a number of settings that complement the currently selected Music Style. See p. 23.
- ㉚ **KEYBOARD PART buttons**  
These buttons allow you to switch three Keyboard parts (Upper 1, Upper 2, and/or Lower) on and off. "Keyboard parts" are sounds you yourself can play - as opposed to "Arranger parts" that are played by the EM-55's automatic accompaniment function.
- ㉛ **A/B buttons, numeric keypad, VARIATION/STYLE DISK button**  
Use [A/B] to select the Tone bank (there are two banks of 64 Tones each). The keypad is used for selecting Tones (sounds) for the Keyboard parts, Music Styles, and User Programs. The function of these buttons depends on which button you pressed last: the [STYLE], [TONE], or [USER PROGRAM] button.



The [VARIATION] button also doubles as [STYLE DISK] button (after pressing the [STYLE] button). See p. 26. The numeric keypad also allows you to enter file names.


### ③ PHONES sockets

This is where you can connect two pairs of optional headphones (Roland RH-25 or RH-50). By doing so, you switch off the EM-55's speakers.

### ③ Disk drive

This is where you can insert a 2DD or 2HD floppy disk with Standard MIDI Files (SMF) or Music Styles. It also allows you to save your User Program settings and the Songs you record.

## Rear panel



### ① LCD CONTRAST knob

Use this knob if the icons and characters in the EM-55's display are too light or too dark. Be aware that changing lighting conditions may require different contrast settings.

### ② MIDI OUT/IN sockets

Connect the MIDI OUT socket to the MIDI IN jack of your computer (or MIDI instrument) to transfer MIDI data from the EM-55 to the computer or external MIDI instrument. Connect the MIDI IN socket of the EM-55 to the computer's MIDI OUT jack to receive data from the computer.

### ③ FOOTSWITCH/EXPR socket

This is where you can connect an optional DP-2, DP-6, or BOSS FS-5U footswitch that allows you to hold ("sustain") the notes you play with your right hand. It can also be used for controlling certain parameters. Alternatively, you can connect a Roland EV-5 expression pedal for realtime control of the EM-55's volume.

### ④ OUTPUT R, L/MONO sockets

These sockets allow you to connect the EM-55 to your HiFi amplifier, a mixer, a cassette deck, a keyboard amplifier, etc. If the external amplifier is mono, be sure to connect it to the OUT L/MONO socket.

### ⑤ DC 12V IN socket

This is where you need to connect the supplied adapter (ACJ). After connecting the adapter cable, wind it around the cord hook to the socket's right to prevent accidental power failures.


**Note:** Be sure to only use the adapter supplied with your EM-55. Other adapters may damage your Interactive Keyboard.

# 3. First steps

## Setting up

The first thing you need to do is connect the supplied ACJ adapter to a suitable wall outlet.

- (1) Unpack the EM-55 and place it on a stable surface.
- (2) Connect the small end of the adapter cable to the EM-55's DC IN jack, and the other end to a suitable wall outlet.
- (3) Press the [POWER ON] button to switch on the EM-55.





## Demo songs

Your EM-55 comes with 16 Tone demos and 8 Style demos.

- **Tone demos** show off the EM-55's amazing sound quality.
- **Style demos** give you an impression of the quality of the on-board Music Styles.


- (1) Press the [DEMO] button (its indicator lights).  
The indicator lights and playback of all demo songs starts.




- (2) If necessary, use the [VOLUME] control to change the playback volume.
- (3) Press [DEMO] again to skip to the next song.

### Playback of a Tone demo song:

- (1) Press the [START/STOP] button. This will stop playback of the running demo song.



- (2) Press the [TONE] button.



- (3) Press the [A/B] button to select the desired group of Tone demo songs.

The Tone demo songs (16 in all) are divided into two groups (A and B) of 8 demos each.


- (4) Press a numeric button [1]~[8]. Each button selects a different Tone demo song. Playback of the selected demo song starts automatically. After a copyright message, the name of the selected song will be displayed.

You can now press [START/STOP] to stop playback of the currently selected song. If you press this button again, the next demo song will be played back.

- (5) Press [START/STOP] to stop demo song playback, and press [DEMO] (indicator goes dark) to switch off the Demo function.

**Playback of a Style demo song:**

- (1) Press the [STYLE] button.



- (2) Press a numeric button [1]~[8]. Each button selects a different Style demo song (there are eight).

Playback of the selected demo song starts automatically. After a copyright message, the name of the selected song will be displayed.

You can now press [START/STOP] to stop playback of the currently selected song. If you press this button again, the next demo song will be played back.

- (3) Press [START/STOP] to stop demo song playback.
- (4) Press [DEMO] (indicator goes dark) to switch off the Demo function.

**DJ Pad function**


Let us now look at one of the new Session Partner functions that allows you to use the EM-55 DJ style. (See pages 21 and 38 for the remaining Session Partner/Track functions.)

The DJ PAD function allows you to start and stop eight different phrases of a selected Music Style by pressing buttons, rather than playing on the keyboard.

After starting a phrase, you can change its key by playing the corresponding chord in the left half of the keyboard. This would allow you to create entire songs. You can even record the music you create using the DJ Pad function.


Oh... and one last thing: it is perfectly possible to start several phrases at once (the DJ Pad function is polyphonic).

- (1) Press the [STYLE] button. Check whether the [STYLE A] icon is displayed.



The upper SESSION PARTNER [TRACK] indicator lights.

- (2) Press the [STYLE PAD/DJ TRACK] button once or twice (the DJ PAD indicator must light).




- (3) Now use the [1/9]~[8/16] buttons to start the assigned phrases (the indicators of the buttons you press light).

You can press several buttons simultaneously if you like.

Briefly pressing them starts the assigned phrase, which will be played for as long as you hold the button.


If you press and hold one of these buttons, the phrase will be repeated again and again ("looped"). Press the corresponding button again to stop the loop of the assigned phrase.

- (4) If necessary, use the [TEMPO/DATA] dial to change the tempo.



Choosing other sets


- (5) If necessary, use the BANK/NUMBER [1]~[8] buttons to select a different set.



The EM-55 provides 8 Sets of DJ phrases (with 8 phrases each). These sets are called: Dance 1, Dance 2, HipHop, House 1, House 2, Rap, Techno 1, Techno 2

2, Rap, Techno 1 and Techno 2. The illustration above shows you which button you need to press to select the desired set.

The name of the set you select appears in the display:



**Note:** Do not press the [START/STOP] button, because doing so would start the Arranger and stop playback of the DJ PAD function.


**Note:** There is also a parameter that allows you to specify whether playback of the various phrases should be synchronized. See p. 46.

## Musical Games


Your EM-55 contains several musical games you may want to play at times. These games will help you master some basic musical concepts. They are called:

- **Guess the Note:** play the note you hear.
- **Guess the Chord:** see if you can play the chords you hear.
- **Chord Finder:** this game will help you find out how to play chords you may come across in written music. This is a wonderful way of learning new chords. For GuessNte and GuessChd, speed is an important factor: the faster you play the right note(s), the higher your score will be.

- (1) Press the [MUSICAL GAME] button.




The [MUSICAL GAME] icon appears in the center of the display, while the message line in the upper left-hand corner displays the name of the first game.



- (2) Press [MUSICAL GAME] again to select the desired game ("GuessNte", "GuessChd" or "ChordFnd").

You can also press ORCHESTRATOR [DRUM & BASS] or [COMBO] to select the game.



- (3) Use the STYLE MORPHING [DRUM], [BASS], and [ACCOMP] buttons to select the level (only for "Guess Nte" and "GuessChd").

Button	Function
DRUM	Beginner (easiest)
BASS	Advanced (intermediary)
ACCOMP	Expert (most difficult)

Example: to select the "Advanced" level of the "GuessNte" game:


- Press [MUSICAL GAME].
- Press [MUSICAL GAME] twice again (or ORCHESTRATOR [COMBO]).
- Press STYLE MORPHING [BASS].
- (4) Press ORCHESTRATOR [BIG BAND] to confirm your choice ("OK").

### Guess Note

After pressing "OK" (see step (4) above), the EM-55 plays a note, while the display shows "Listen". The score graphic in the left part of the display shows the note sounded by the EM-55.

- (1) Play a note on the keyboard.  
Next, the EM-55 sounds four other notes. Play them too.  
After five notes and responses the display indicates how long it took you to play the notes, and how well you scored. If the notes were correct, you will also get a standing ovation from your EM-55.  
If your notes were wrong, the EM-55 plays a "car crash" sound.
- (2) Press "OK" to have the EM-55 sound another round of five notes.  
Use the ◀ ▶ or "1", "2", "3" buttons if you wish to select another level. Then confirm by pressing "OK".
- (3) Play the notes again.

- After applauding (or playing the crashing sound), the EM-55 returns to the level indication. Repeat step (2), if you like, or press [MUSICAL GAME] to select another game.
- (4) Press [SONG], [STYLE], [TONE], [USER PROGRAM] or [FUNCTION] to leave this function.



### Guess Chord

After pressing "OK" (see step (4) under "Musical Games"), the EM-55 plays a chord and displays the notes in the score graphic in the left part of the display.

- (1) Play the chord notes on the keyboard.  
Next, the EM-55 sounds four other chords. Play them too.  
After five chords and responses the display indicates how long it took you to play the chords, and how well you scored. If the chords were correct, you will also get a standing ovation from your EM-55.  
If your choices were wrong, the EM-55 plays a "car crash" sound.
- (2) Press "OK" to have the EM-55 sound another round of five chords.

- Use the ◀ ▶ or "1", "2", "3" buttons if you wish to select another level. Then confirm by pressing "OK".
- (3) Play the chords again.  
After applauding (or playing the crashing sound), the EM-55 returns to the level indication. Repeat step (2), if you like, or press [MUSICAL GAME] to select another game.
  - (4) Press [SONG], [STYLE], [TONE], [USER PROGRAM] or [FUNCTION] to leave this function.

### Chord Finder

Apart from being a fun game, the Chord Finder is also useful for learning how to play certain chords you are unfamiliar with. Here is how to play this game:


- (1) Press the [MUSICAL GAME] button.  
See p. 10 for a detailed discussion.
- (2) Press [MUSICAL GAME] again to select "ChordFnd".  
Alternatively, press "3" [ACCOMP] to select it directly.
- (3) Use the "1" or "2" button to select the entry you wish to specify:



Button	Function
"1"	Root (i.e. the "name" of the chord).
"2"	Type (major, minor, etc.)


#### To specify the Root:

- Press "1". The display now shows the message "1 Root".
- Use the ◀ ▶ buttons to select the root ("C", for example). The name of this chord appears in the ARRANGER CHORD field of the display.



**To specify the Type:**

- Press the "2" button. The display now shows the message "2 TYPE".
  - Use the ◀ ▶ buttons to select the chord type ("7", for example). The complete name of this chord appears in the ARRANGER CHORD field of the display, while the keyboard and score graphics also show the notes.
- (4) Use the "1" and "2" buttons as well as ◀ ▶ to select other chords you wish to practise.
- (5) Press [SONG], [STYLE], [TONE], [USER PROGRAM] or [FUNCTION] to leave this function.




Black keys you need to press are temporarily displayed as white keys (see the Bb/A# in the illustration).

## 4. Playing with accompaniment

Let us now take advantage of the EM-55's accompaniment function. This function is called "Arranger".

### Starting/stopping the Arranger


- (1) Press the KBD MODE [ARRANGER] button (its indicator lights).



The keyboard is split into two halves. The keys you press in the left half are used to specify the key of the accompaniment. The **right half** of the keyboard allows you to play a **tune** to the accompaniment.

At power-on, the EM-55 automatically selects the "A24 TwoStep" Style.

- (2) Press the [START/STOP] button to start Arranger playback.




**Note:** If the [ARRANGER] indicator lights, playing in the left half of the keyboard while the Arranger is stopped, will sound an electric piano and bass Tone. The left half of the keyboard is thus not muted (like on previous Roland arranger instruments). This can be switched off, however (see "EP Chord (Left-hand E. Piano + Bass)" on page 43).

- (3) Play a chord (or just one note) with your left hand.



- (4) Play another chord (or note) to change the Arranger's key.

- (5) Press the following buttons to use other patterns of the currently selected Music Style:




Button	Function
INTRO	Playback of an introduction. Press this button before activating [START/STOP].
ORIGINAL	Simple accompaniment version.
FILL	Transition ("Fill In") to VARIATION or ORIGINAL.
VARIATION	Slightly more complex accompaniment version.
ENDING	Phrase that indicates the end of the song. Use this button instead of [START/STOP] to stop playback.

These buttons select Music Style "patterns". The indicator of the button you press lights. Also, the ARRANGER CHORD field indicates which chord you played last. This chord is used by the accompaniment.

As soon as you feel comfortable with the Arranger, you should try to play a melody with your right hand while using your left for selecting Arranger chords.

### Changing the tempo

- (6) Use the [TEMPO/DATA] dial to decrease (turn left) or increase (turn right) the tempo (if necessary).



To return to the Music Style's default tempo, press and hold [EXECUTE/TAP TEMPO] for a few seconds.


Alternatively, you can also press the [EXECUTE/TAP TEMPO] button several times at the desired tempo.

### Stopping Arranger playback

- (7) Press [START/STOP] again to stop playback. You can also press [ENDING]. In that case, you first hear an ending phrase. When it is finished, Arranger playback stops automatically.

### Automatic playback start (Sync Start)

Press [SYNC START] (indicator lights). Arranger playback now starts as soon as you play a chord in the left half of the keyboard.




## Selecting other Music Styles

### Selection via the numeric keypad

Your EM-55 comes with 64 different accompaniments (called "Music Styles") that reside in eight banks. Here is how to select them:

- (1) Press the [STYLE] button.
- (2) Press the [A/B] button to select Group A (the A appears in the upper left-hand corner of the display).
- (3) Use the numeric keypad to select the desired Music Style bank (1~8).
- (4) Use the numeric keypad to select a Music Style memory of that bank (x1~x8). Example: press [2] to select the "Bossa 2" Style.

Note: You can also press [STYLE] to scroll through all 64 Music Styles of the currently selected group (A or B).



See the STYLE bank list in the left half of the front panel and p. 71 for locating the Music Style bank.


Example: press [6] to select the "LATIN" bank.



### Style selection via EZ Search

Another easy way of selecting Music Styles goes like this:

- (1) Press the [EZ SEARCH] button (indicator lights).



The display now shows the number and name of the currently selected Music Style.

- (2) Look at the STYLE list in the upper left part of the front panel to select a Style bank, then press the BANK/NUMBER button that corresponds to that bank.

Example: to select a Music Style from the "POP" bank, press [3].

STYLE	
1	ROCK
2	CONTEMPORARY
3	POP
4	50'S & 60'S
5	SWING
6	LATIN
7	VARIETY
8	ACOUSTIC

- (3) Use the [TEMPO/DATA] dial to select the desired Music Style from that bank. After selecting the POP bank, that would be Pop 1A~4A, Pop 1B~4B.

Note: EZ Search only works for the "A" group (the Styles in the EM-55's internal memory).

### Working with Music Styles on a floppy disk

Your EM-55 comes with two floppy disks, one of which contains 64 additional Music Styles for the Disk Link function. (The other floppy disk contains additional Styles that you can load via STYLE DISK.) Using those is just as easy as working with the internal Styles – and loading them from floppy is just as quick. This function is called "Disk Link".

The Music Style referenced by the Disk Link memory you select is automatically loaded from disk and copied to the Style Disk memory (see also p. 26).


- (1) Insert the "Disk Link" floppy disk into the drive (front panel, below the keyboard).
- (2) Press the [STYLE] button.
- (3) Press the [A/B] button to select Group b (the **b** appears in the upper left-hand corner of the display).

- (4) Use the numeric keypad to select the desired Music Style bank (1~8).
- (5) Use the numeric keypad to select a Music Style memory of that bank (x1~x8).  
Note: You can also assign other Styles to the Music Style memories of group b (see p. 27).  
Note: The EM-55 does not store the Music Styles for group b. You need to insert the (correct) floppy disk into the drive each time you wish to use those Styles.

## Selecting sounds for the right hand

Do the following if you wish to assign a different sound to your (right-hand) melody playing:

- (1) Press the [TONE] button.




The **TONE** icon appears in the display. You can now select Tones. There are two ways to select Tones on the EM-55.

In this example, we will select the Tone "B41<sub>9</sub> HeavenKey".

- (2) Press the [A/B] button to select the Tone group.


The "HeavenKey" Tone belongs to the "TONE B" group. You therefore need to press [A/B] once or twice to make the display read **b**.



Note: This is only necessary if the currently selected Tone belongs to the A group.


Note: The name ("Piano 2" in the illustration) still refers to the previously selected Tone.

- (3) Press the numeric button [4] to select bank "4".



**Note:** The name ("Piano 2" in the illustration) still refers to the previously selected Tone.

- (4) Press the numeric button [1] to select the "HeavenKey" Tone.



Notice how the Tone name in the display changes. If you now play in the right half of the keyboard, you will hear the "HeavenKey" Tone.

**Note:** See p. 28 for how to select Tone Variations.

**Note:** You can also press [TONE] repeatedly to scroll through all available Tones (excluding the Variations).


**Note:** In many cases, the EM-55 does not select exactly the Tone you asked for, but an even better one. See p. 28 for details.

### Tone selection via EZ Search

Your EM-55 contains 3,559 Tones (or sounds), which means that you have plenty of options – but it also means that you may have to spend several minutes before locating the desired Tone.

One way of doing that is by looking at the list on p. 59 and then entering the number via the BANK/NUMBER pad. Another, more intuitive, approach is this:

- (1) Press the [TONE] button. The **TONE** icon now appears in the display.
- (2) Press the [EZ SEARCH] button (indicator lights).



The display now shows the number and name of the currently selected Tone.

- (3) Look at the TONE list in the upper left part of the front panel to select a Tone bank (there are 16 banks), then press the [A/B] and a number button [1]~[8] to select that bank.

TONE LIST	
1 PIANO	1 REED
2 CHR PERC	2 PIPE
3 ORGAN	3 SYN LEAD
4 GUITAR	4 SYN PAD
5 BASS	5 SYN SFX
6 ORCHESTRA	6 ETHNIC
7 ENSEMBLE	7 PERCUSSIVE
8 BRASS	8 SFX

Example: if you need an Organ sound, select **R** and then press [3]. To be able to select solo synthesizer sound, press [A/B] to select group **b**, then press [3].

- (4) Use the [TEMPO/DATA] dial to select the desired Tone from that bank. You can now only select Tones that belong to the bank (and group) you selected above. This is very convenient for trying out different alternatives.


**Note:** It is also possible to use several sounds at a time. See pages 17 and 28.

**Note:** EZ Search also provides access to Tones that cannot be selected via the BANK/NUMBER keypad. (The keypad allows you to select up from among 1616 Tones.) Those additional Tones cannot be selected via SysEx.

## 5. Playing one sound (Piano)

Here is how to play one sound via the entire keyboard. This mode is automatically selected when you switch on the EM-55. As it was mainly meant to use the EM-55 like a digital piano, this mode is called "PIANO".

- (1) Press the [PIANO] button (its indicator lights).





- (2) See "Selecting sounds for the right hand" (p. 15) for selecting a different sound. At first, only the [UPPER 1] indicator lights, which means that the part of the same name is active. "Parts" are "containers" that you can assign Tones to, and play.

### Using the metronome

You can switch on the metronome when practising a new song.

- (1) Press the [METRONOME] button.




The  icon appears in the display and you hear the metronome sound.

- (2) Press and hold [METRONOME] to select the Metro TS function.
- (3) Use the [TEMPO/DATA] dial (notice the "VALUE" message in the display) to set another time signature. The possibilities are: 1/4, 2/4, 3/4, 4/4, 5/4, 6/4, 6/8, 9/8.
- (4) Press [SONG], [STYLE], [TONE], or [USER PROGRAM] to leave this function.


## Playing a different sound with the left hand (Split)

Here is how to split the keyboard without using the Arranger. This allows you to play separate sounds with your left and right hands:

- One sound in the right half (**Upper**).
- One sound in the left half (**Lower**). You can also add an automatic bass line (**M.Bass**). See p. 43.



- (1) Press the KBD MODE [ARRANGER] button to activate the Arranger mode. This is necessary to split the keyboard. You must not press [START/STOP], however. Otherwise, the Arranger will start playing.
- (2) Press the [LOWER] button.



Its indicator lights (as does the indicator of the [UPPER 1] button). You can now play one part with your left hand ("Lower"), and another with your right ("Upper 1").

To assign a different Tone to the Lower part, you need to press and hold [LOWER] (its indicator starts flashing). Then use the same procedure as for the Upper 1 part (see "Selecting sounds for the right hand" on page 15).


**Note:** If necessary, you can select a different split point. See "ArrSplit (Arranger Split)" (p. 43).

**Note:** You can also press the [START/STOP] button to add a rhythm accompaniment to your playing. This is based on the currently selected Music Style. See p. 14 for how to select a different one, and p. 21 for muting all Arranger parts except the drums.

## 6. Drumming on the keyboard

Here is how to assign drum and percussion sounds to the entire keyboard.

- (1) Press the [M.DRUMS] button.



Its indicator lights. Play a few notes on the keyboard. This time, every key is assigned to a different sound.

With the left-most key, you can play a bass drum sound (also called "kick"). The white key next to it triggers a snare drum sound, etc. Try it out by pressing several keys, either in succession or simultaneously.



### Selecting other Drum Sets

The sounds used in M.Drums mode ("M.Drums" is short for Manual Drums) are not produced by Tones but rather by a **Drum Set**. Drum Sets are collections of over 90 sounds, each assigned to a different key. The EM-55 provides 116 different Drum Sets.

BANK/NUMBER	74 KICK&SNARE 2	71 ORCHESTRA	41 ELECTRONIC
11 STANDARD 1	75 ASIA	72 ETHNIC	42 TR-808
12 STANDARD 2	76 CYMBAL&CLAP	73 KICK & SNARE	51 JAZZ
13 STANDARD L/R	77 GAMELAN 1	75 ASIA	61 BRUSH
14 V-Pop1	78 GAMELAN 2	76 CYMBAL&CLAP	71 ORCHESTRA
15 V-R&B	81 SFX	81 SFX	81 SFX
16 V-Fiesta	82 RHYTHM FX	82 RHYTHM FX	88 CM-64 / 32L
21 ROOM	83 RHYTHM FX 2	83 RHYTHM FX 2	
22 HIP HOP	84 RHYTHM FX 3	128 CM-64/32L	<b>CC32= 122</b>
23 JUNGLE	85 SFX 2		<b>(General MIDI 2)</b>
24 TECHNO	87 CYM&CLAPS 2		1 GM2 STANDARD
25 ROOM L/R	88 V-VoxDrum	11 STANDARD 1	9 GM2 ROOM
26 HOUSE	128 CM-64/32L	12 STANDARD 2	17 GM2 POWER
31 POWER		21 ROOM	25 GM2 ELECTRONIC
32 V-Rock1	<b>EZ SEARCH</b>	31 POWER	26 GM2 ANALOG
33 V-Rock2	11 STANDARD 1	41 ELECTRONIC	33 GM2 JAZZ
41 ELECTRONIC	12 STANDARD 2	42 TR-808/909	41 GM2 BRUSH
42 TR-808	13 STANDARD 3	43 DANCE	49 GM2 ORCHESTRA
43 DANCE	21 ROOM	51 JAZZ	57 GM2 SFX
44 CR-78	22 Hip-Hop	61 BRUSH	
45 TR-606	23 JUNGLE	71 ORCHESTRA	<b>CC32= 119 (XG)</b>
46 TR-707	24 TECHNO	72 ETHNIC	1 standard kit
47 TR-909	31 POWER	73 KICK&SNARE	2 standard kit2
51 JAZZ	41 ELECTRONIC	74 Oriental	9 room kit
52 JAZZ L/R	42 TR-808	81 SFX	17 rock kit
61 BRUSH	43 DANCE	82 RHYTHM FX	25 electro kit
62 BRUSH 2	44 CR-78	128 CM-64/32L	26 analog kit
63 BRUSH 2 L/R	45 TR-606		33 jazz kit
64 V-JazzBrush	46 TR-707		41 brush kit
71 ORCHESTRA	47 TR-909	11 STANDARD1	49 classic kit
72 ETHNIC	51 JAZZ	21 ROOM	121SFX 1 kit
73 KICK & SNARE	61 BRUSH	31 POWER	122SFX 2 kit

To select them, proceed as though you were calling up a Tone:


- (1) Press a number button [1]~[8] to select a Bank.
- (2) Press a number [1]~[8] button to select the desired Drum Set.  
Use the EZ Search function to have access to all Drum Sets except the ones preceded by "CC32=" (those Drum Sets can only be selected via MIDI).

**Note:** You can also press the [START/STOP] button to add a rhythm accompaniment to your playing. This is based on the currently selected Music Style. See p. 14 for how to select a different one.

## 7. Using the D Beam Controller

The D Beam Controller allows you to control various aspects of your performance, or to add something to the music, by moving your hand, head, etc., in the air. You only need to make sure that you do so over the two "eyes" and within a 40cm ( $\pm 16"$ ) range. Your movements are translated into musical expression.

- (1) Press the D BEAM CONTROLLER [ON/OFF] button (indicator must light).




Let's first try out the DJ GEAR functions.

- (2) Press the [ASSIGN] button (next to the [ON/OFF] button) until the DJ GEAR indicator lights.



- (3) Start the Arranger by pressing the [START/STOP] button.
- (4) Move your hand towards and away from the D Beam's "eyes".



What you hear now is the "VinylRPM" effect. Now let's do some scratching...

- (5) Press and hold the [ASSIGN] button until the display shows the VinylRPM message.
- (6) Use the [TEMPO/DATA] dial to select Scratch.

- (7) Again move your hand towards and away from the D Beam.

Now you should hear a scratch sound.

Try out the SOUND EFX (sound effects), INSTRUMENTS (play notes using a given sound) and CONTROLS (change Arranger playback).


**Note:** See p. 34 for details about the D Beam Controller.

## 8. Recording your music


Your EM-55 contains a 16-track Recorder you can use for recording your own songs. Feel free to use the Arranger to add an accompaniment to the melodies you record.

Here, you will learn how to record your melody and the Arranger accompaniment.

- (1) Press the [ARRANGER] button.  
The indicator lights. You can now use your left hand for transposing the Arranger's key in realtime.
- (2) Press the [STYLE] button.
- (3) Select a Music Style.  
See also page 14.
- (4) Press the [START/STOP] button.
- (5) Use the [TEMPO/DATA] dial to set desired tempo.
- (6) Press [START/STOP] again to stop Arranger playback.
- (7) Assign the desired Tone to the right half of the keyboard.  
Press [TONE], and use the [A/B] and [1]~[8] buttons (or the EZ Search function). See also page 15.  
**Note:** If necessary, you can also use the [VARIATION] button to select a Tone Variation. See p. 28 for details.
- (8) Press the [● REC] button.



The display should look as follows (if it doesn't, use the [TEMPO/DATA] dial to select ALL):



### Listening to your song

- (1) Press the [SONG] button.
- (2) Press [START/STOP] to start playback.
- (3) Press [START/STOP] once again to stop playback.
- (4) Press [ORIGINAL] | ◀ to return to the beginning of the song.


(The [RECORD] and [1]~[16] icons flash.)  
You are now in ALL mode, which means that everything you and the EM-55's Arranger play will be recorded.

**Note:** This will erase the song that currently resides in the EM-55's internal memory. You may want to save the current Song to floppy disk first (see p. 52).


- (9) Start recording in one of the following ways:
  - Press the [START/STOP] button to start Arranger playback with the selected Division.  
**Note:** If you start recording without the Arranger and want to bring it in at a later stage, it would be a good idea to switch on the metronome by pressing the [METRONOME] button.
  - Activate the SYNC START function and press one or several keys to the left of the Split point.  
**Note:** It is also possible to record in PIANO, and M.DRUMS modes (after pressing the buttons of the same name). In that case, you should use the metronome. The song's time signature can be set with the MetroTS function. See page 17.

- (10) Stop recording in one of the following ways:

- Press [START/STOP].



- Press the [ENDING] button to start the Ending phrase. As soon as it ends, recording stops.



## 9. Additional Music Style functions

Apart from the basic Music Style functions covered on page 13 and following, your EM-55 also provides the following functions.


The following are only available after pressing the [ARRANGER] button (its indicator must light).

### Session Partner functions

The EM-55's SESSION PARTNER section can also be used for "playing" with the Arranger parts, or adding a ninth accompaniment phrase to the Arranger's 8-part accompaniment. Let's have a look at these two functions:


#### Muting Arranger parts (Track)

The EM-55's Music Styles comprise eight accompaniment parts: Drums, Bass, and Accomp 1~6. If you take a close look at the SESSION PARTNER section, you will see that these names appear above the numeric buttons [1]~[8]:




The ACCOMP parts contain melodic accompaniments (piano riffs, sax parts, guitar chords, etc.). If you like, you can mute these Arranger parts during playback – and save these settings to a User Program (see p. 47). Here's how you do that:

- (1) Press the KBD MODE [ARRANGER] button (its indicator lights).



- (2) Select the desired Music Style (see p. 14).
- (3) Press [START/STOP] to start Arranger playback.
- (4) Press the [TRACK] button (the upper indicator lights).



Now take a look at the SESSION PARTNER [1/9]~[8/16] buttons. Some of them light, while others don't. There may be two reasons why a [1/9]~[8/16] indicator does not light:

- either because the corresponding Arranger track is switched off (something you did by pressing the button in question, or by selecting another Orchestrator level, see p. 25)...

- or because the corresponding track contains no data.

Not all eight Arranger tracks are indeed used by all Music Styles or Music Style divisions (Intro, Variation, etc.).

- (5) Use the SESSION PARTNER [1/9]~[8/16] buttons to switch the desired Arranger parts on/off.

**Note:** Once you start muting or switching on existing Arranger parts, the EM-55 leaves the currently selected Orchestrator level. Your realtime changes always have priority.

**Note:** The on/off status of the Arranger parts does not change if you select another Music Style while Arranger playback is running. If, however, you select another Music Style after stopping Arranger playback, all (existing) Arranger parts will be switched on again.

**Note:** You can also change the volume of certain Arranger parts. See "AccDrums, AccBass, Accomp: volume" (p. 43).


### Adding yet another Arranger part (Style Pad)

The *SESSION PARTNER* buttons can also be used for the "STYLE PAD" function. That allows you to add a part to Arranger playback, which is not part of the Music Style itself (either in ROM or on floppy).

Like the DJ PAD function (see p. 9), the STYLE PAD function provides eight different phrases you can access via the *SESSION PARTNER* buttons [1/9]~[8/16]. (And there are also sets, see below). And like for the DJ PAD function, the key of the phrases depends on the chords you play in the left half of the keyboard.


Here, however, you can only use one phrase at a time.

- (1) Press the KBD MODE [ARRANGER] button (its indicator lights).



- (2) Select the desired Music Style (see p. 14). This also determines which phrase set is selected automatically. See below for details.

- (3) Press the [STYLE PAD/DJ PAD] button. The STYLE PAD indicator must light.



- (4) Press [START/STOP] to start Arranger playback.
- (5) Use the *SESSION PARTNER* [1/9]~[8/16] buttons for starting playback of the desired additional Arranger phrase. Press it again to switch off Style Pad playback. Press another [1/9]~[8/16] button to start the phrase assigned to that button. The previously selected phrase will be switched off (if it is still running).


The Style Pad function is also available while Arranger playback is stopped. And even in that case, its key (pitch) changes as you play different chords in the left half of the keyboard.

**Note:** Do not press the [TRACK] button, because that would switch off the STYLE PAD function (and instead activate the mute on/off function, see above).


### Selecting another phrase set

As stated earlier, selecting an internal Music Style automatically specifies the set of eight phrases you can start/stop via the *SESSION PARTNER* [1]~[8] buttons. You can, however, override this automatic selection:

- (1) Press and hold the [FUNCTION] button, while pressing the BANK/NUMBER [3] button.



This selects the "PAD SELECT" function (indicated as "PAD" in the upper left corner of the display).



- (2) Use the [TEMPO/DATA] dial to select one of the following sets:

01 Rock	04 Dance	07 Rock'N	10 Latin 2
02 ShBallad	05 Pop 1	08 Swing	11 Waltz
03 Sl Rock	06 Pop 2	09 Latin 1	12 Tango



## One Touch


The One Touch function automates quite a few tasks:

- The Arranger selects the preset Style tempo.
- Suitable Reverb and Chorus settings.
- The EM-55 selects Tones for the Upper 1 and Upper 2 parts that are suitable for the selected Style.


**Note:** The M-FX settings (see p. 29) are not covered by the One Touch function.

There are 4 **One Touch memories** per Style with different settings for the above parameters. Here is how to select one:

- (1) Select the desired Music Style (see p. 14).
- (2) Press the ONE TOUCH [1-2] or [3-4] button.



The number field in the upper left corner reads "OT", followed by the number of the selected One Touch memory.




- (3) Press the same ONE TOUCH button again if you need "OT2" (1-2) or "OT4" (3-4). One Touch needs to be activated again every time you select a new Music Style.

**Note:** One Touch is also available for the Disk Link Styles (see also page 15), but it is less meaningful.


## Using the EM-55's Music Assistant

Another practical function for quickly making the right settings for a song you want to play is to take advantage of the EM-55's novel MUSIC ASSISTANT function. It prepares everything for you (Style, Tones, effects, etc.).


- (1) Press the [MUSIC ASSISTANT] button.



The following icon appears in the display, while the message line displays the name of the first Music Assistant registration:



- (2) Use the BANK/NUMBER [1]~[8] buttons to specify the initial character where the list should start.



Example: if you want to load the registrations for a song called "Thriller", press [7] button three times (to select the first song that starts with a "T"). If necessary, you can now continue your search among the "Ts" using the [TEMPO/DATA] dial.

In fact, [TEMPO/DATA] allows you to scroll through all Music Assistant settings.

- (3) Press [EXECUTE] to confirm your selection. Your EM-55 is ready to rock...



**Note:** If necessary, you can now change certain settings (e.g. select another Tone for Upper 1) and then save your version to a User Program (see p. 47).

## Melody Intelligence

The *Melody Intelligence* function adds a second voice (harmony notes) to the melodies you play with your right hand. In fact, MELODY INTELL uses both halves of the keyboard to determine which notes to play:

- It looks at the melody notes in the right half; and...
- It analyzes the chords you play in the left half to see which notes it must add to your melody.

Press the [MELODY INTELL] button so that the corresponding icon (see right illustration) appears in the display.



### Changing the MELODY INTELL harmony type

The EM-55 contains 18 different voicings (harmony types) for the MELODY INTELL function. These voicings specify the number of harmony notes and the way in which they are added to your melody.

To select a different harmony type, press and hold the [MELODY INTELL] button until the "MI" message appears in the upper left corner of the display. Then use the [TEMPO/DATA] dial to select the desired voicing. The available types are:

1 Duet	4 Strings	7 BigBand	10 Broadway	13 Latin	16 WltzOrg
2 Organ	5 Choir	8 Country	11 Gospel	14 CntrGuit	17 OctvTpe1
3 Combo	6 Block	9 Traditnl	12 Romance	15 CntrBald	18 OctvTpe2


## Bass Inversion (Bass Inv)

Use this function to change the way in which the Arranger reads the chords you play.


If the hand icon is not displayed, the A. Bass part plays the root of the chords that feed the Arranger. If you play a C (or C chord), the bass sounds a C; if you play an A minor chord (or if you press A and the C to its right), the bass sounds an A, etc.

By activating Bass Inversion, you can specify the note played by the A. Bass part (the lowest note of your chords). Switch on Bass Inversion for songs that rely on bass rather than on chord patterns (for example C - C/B - C/Bb, etc.).

(1) Press and hold the [FUNCTION] button.




- (2) Keep holding the [FUNCTION] button while pressing BANK/NUMBER [4] to select "Inversion".
- (3) Use the [TEMPO/DATA] dial to select "On".



The INVERSION icon appears to signal that the Bass Inversion function is switched on.

## Orchestrator

The Orchestrator function allows you to vary the accompaniment patterns played by the Arranger. You can leave out parts, thin out the drum part, or even use a totally different accompaniment – in realtime (i.e. while you are playing).



- (1) Select the Music Style you wish to use for playing.  
See page 14.
- (2) Press one of the following buttons to select the desired level of musical "complexity" (its indicator lights):

Drum & Bass	The simplest accompaniment that only contains the drum and bass lines.
Combo	Accompaniment pattern with only a few instruments (i.e. a band).
Big Band	Accompaniment pattern with a lush arrangement (several melodic instrument lines).

Note: Immediately after switching on the EM-55, the Orchestrator selects the "BIG BAND" level.



Note: The effect of these three levels also depends on whether the [VARIATION] or [ORIGINAL] button was pressed. In effect, the combination of the [ORIGINAL]/[VARIATION] and [DRUM & BASS]/[COMBO]/[BIG BAND] buttons provides 12 accompaniment patterns per Music Style.

The last selection you make can be saved to a User Program. See p. 47.

## Style Morphing

Style Morphing allows you to use one or several accompaniment parts of one Music Style and the others of a second Music Style. Each time you select a Music Style, the EM-55 automatically prepares a second Style in the background. The Style you select is called "STYLE A" (this is indicated by the **STYLE A** icon in the upper right corner of the display). The "covert" Style is called "STYLE B".

The link between "A" and "B" Styles is preset. This allows the EM-55 to automate the selection process and to prepare a suitable "B" Style. Feel free, however, to assign another Music Style to "B" if you want to explore new morphing combinations (see below).



There are three part groups per Style (A or B) that can be morphed:

**DRUMS:** The drums and percussion.

**BASS:** The bass line.

**ACCOMP:** Other melodic accompaniments (piano, guitar, strings, etc.).

The icons in the display keep you posted about the Style (A or B) whose drum, bass, and/or accompaniment lines are used.

- (1) Press the [DRUM A/B] button once to select the drum part of the "other" Style (A or B).  
Press it again to return to the previous drum part.
- (2) Press the [BASS A/B] button once to select the bass part of the "other" Style (A or B).  
Press it again to return to the previous bass part.
- (3) Press the [ACCOMP A/B] button once to select the melodic parts of the "other" Style (A or B).

### Selecting another "B" Style

As stated earlier, the "B" Style is prepared automatically whenever you select an "A" Style, so that the Style Morphing function is ready whenever you are.

If you do not agree with this preset selection (or want to experiment with other Styles), hold down the [STYLE] button and select the desired "B" Style using the [A/B] button and [1]~[8] keypad (the Disk Link memories are also available). This selection will also be written to a User Program.

**Note:** You can also select the STYLE DISK Style by pressing [VARIATION/STYLE DISK]. See below for details about the STYLE DISK function.

**Note:** The Intro and Ending patterns of Style A will be used in their original state for all Style Morphing combinations except the one where all parts are played by Style B (i.e. when no icon is displayed in the Style A column).

**Note:** You can also morph between Styles that use different time signatures.

**Note:** When you select a new Music Style with the numeric keypad, the Style Morphing function is reset to the "Style A only" status. The Style Morphing setting can, however, be written to a User Program. See p. 47.



## Working with Styles on floppy disk

### Style Disk

The EM-55 provides a special temporary memory that allows you to use one Music Style on a floppy disk as if it were an internal Style. The function in question is called STYLE DISK.


A Music Style you select via this function is not stored internally. It will be replaced when you select another Music Style on disk, or erased when you switch off the EM-55.

**Note:** See also page 3 for details about how to handle floppy disks.



Working with Styles on disk requires that you purchase a floppy disk containing Music Styles or that you use the floppy disks supplied with the EM-55. See your Roland dealer for details about the available floppy disks (MSA, MSD, or MSE series).

- (1) Insert a floppy disk with compatible Music Styles into the EM-55's disk drive.
- (2) Press the [STYLE] button (the [STYLE] icon appears).




- (3) Press the [VARIATION/STYLE DISK] button. The [STYLE DISK] icon appears in the display, while you will also see the "Sdk" message and the name of the Music Style name that is currently in the EM-55's RAM memory.
- (4) Press [VARIATION/STYLE DISK] again.

If the display now shows the message "Err - No Disk", you need to insert a floppy disk. If the drive contains a floppy disk with readable Music Styles, the name of the first Style on disk will be displayed.

- (5) Use the [TEMPO/DATA] dial to select the desired Music Style on the floppy disk. You can also press [STYLE DISK] to scroll through the Music Styles on disk.



- (6) Press [EXECUTE] in response to the flashing "EXE" message that appears after a brief interval to load the selected Music Style.



Press [VARIATION/STYLE DISK] if you want to select another Music Style on disk and load that one.

**Note:** If the Style on disk does not fit into the EM-55's RAM memory, the "Err - Too Big!" error message is displayed, and the Style will not be loaded.

- (7) Press [START/STOP] to start playback of the style on disk.

**Note:** The selection of the Style Disk memory will be written to a User Program (see p. 47). This, however refers to the memory address rather than its contents. Next time you recall such a User Program, the EM-55 will therefore use the last Style you loaded after switching it on. If you haven't yet loaded a User Style, the EM-55 selects a ROM Style.


**Note:** You can also assign the Music Style in the Style Disk memory to a Disk Link memory (see below).

### Assigning other Music Styles to the Disk Link memories

The EM-55 provides 64 memories (8 banks x 8 numbers) that refer to Music Styles on the supplied or any other floppy disk. The Disk Link memories can be accessed via group **b** (press [A/B] and then enter the bank and number using the [1]~[8] buttons).

Though these memories behave exactly like the memories of group A (that provides access to the internal Music Styles), the Disk Link memories only "work" if the disk in question has been inserted into the drive. Thanks to the EM-55's powerful software, loading a Disk Link Style is as swift as working with internal Styles. To assign a Music Style on floppy disk to a Disk Link memory, proceed as follows:

- (1) Start by loading the desired style using the STYLE DISK function.  
See above. If the EM-55's RAM memory already contains the desired Style, you just need to press [VARIATION/STYLE DISK].  
In any case, you need to insert a floppy disk into the drive.
- (2) Press and hold the [VARIATION/STYLE DISK] button.



The message line of the display should now look as follows:

b--- Link To <sup>TEMPO</sup> 120

As you see, group **b** is already selected. All you need to do now is...

- (3) Use the numeric keypad to select the desired Music Style bank (1~8).
- (4) Use the numeric keypad to select a Music Style memory of that bank (x1~x8).

As soon as you specify the number, the display indicates **Complete**.

Whenever you select that memory ("B32", for example), the EM-55 will load the assigned Style from the floppy disk into its STYLE DISK memory.

**Note:** If you forgot to insert the floppy disk (either while assigning or using the Disk Link memories), an error message will be displayed.

**Note:** If you change the name of a Style file on floppy disk (on your PC, for example), the Disk Link function no longer finds that Style.

## More Music Style functions

Here are yet other functions related to Music Styles. These can be set via the **FUNCTION** menu, or are covered elsewhere:

- Balance between the Keyboard parts and the Music Style parts (see p. 31)
- Volume of certain Music Style parts (see p. 43)
- Arranger split point (see p. 43)
- Hold function for the Arranger notes (see p. 43).


## 10. More Keyboard part functions

### Using the Upper 2 part

The EM-55's Upper 1 part is assigned to the right half of the keyboard (in ARRANGER mode) or to the entire keyboard (PIANO mode).

In all modes except M.DRUMS, you can add a second part (Upper 2) to Upper 1 by pressing the [UPPER 2] button. This allows you to play two sounds simultaneously (piano and strings, for example). It is also possible to switch off Upper 1 and only work with Upper 2. This allows for quick question-and-answer switches.

- (1) Select the desired KBD MODE (ARRANGER or PIANO).
- (2) Press the [UPPER 2] button (indicator must light) to switch on the Upper 2 part.



- (3) To use both Upper 1 and Upper 2, switch on both [UPPER 1] and [UPPER 2].

You can also add the Lower part if you like, so as to play three sounds simultaneously. If the KBD MODE [ARRANGER] indicator lights, however, the Lower part can be played via the left half, while Upper 1 and Upper 2 can be played via the right half.


- (4) To select another Tone for Upper 2, press and hold the [UPPER 2] button until its indicator starts flashing, then use the [A/B], [1]~[8] and possibly also the [VARIATION/STYLE DISK] button.

See p. 15 for selecting Tones and below for selecting Variations

### Selecting Tone Variations

Tone Variations are alternatives for the Tones you can select with the numeric keypad. The PIANO bank, for instance, contains a grand piano, an upright piano, an electric piano, etc. These are the Tones. If you also want to specify the kind of grand piano (mellow, bright, stereo/mono), you need to turn to the Variations (i.e. "Tone subcategories").


Variations are indicated by means of a smaller number in the upper left corner of the display (see the illustration).



- (1) Press the [TONE] button.
- (2) Select the desired Tone with [A/B] and [1]~[8] (see p. 15).

- (3) Press the [VARIATION/STYLE DISK] button to step through the available Variations. See the Tone list on page 59. The number of Variations depends on the Tone you select. Whenever the Variation entry in the address field is empty, the "main" Tone (called Capital) is selected.


You can also select Variations by holding down [VARIATION/STYLE DISK] while you press [7] (◀) or [8] (▶):



## Using the multi-effects processor (M-FX)

Your EM-55 contains a multi-effects processor that can be assigned to the Keyboard parts (Upper 1/2, Lower). You can select one type and decide which Keyboard part(s) should use the effect. The M-FX can be used simultaneously with the Reverb and Chorus effects.

- (1) Press the [M-FX EFFECTS] button.



Its indicator lights, and the Upper 1 part is now processed by the effect type currently assigned to the M-FX processor ("Rotary").

### Selecting another M-FX type


The Rotary effect that is assigned to the M-FX by default is a wonderful effect for organ and other sounds.

For a guitar sound, however, working with distortion can be more effective. In fact, the EM-55 provides 47 different M-FX types (see the list on p. 44), some of which are combinations of two effects for added flexibility. Here is how to select another M-FX type:

- (2) Press the [UPPER 1] button (indicator must light).  
 (3) Play a few notes in the right half of the keyboard, and switch the [M-FX EFFECTS] button on/off to hear the difference.  
 (4) Press the BENDER/MODULATION lever towards the back of the EM-55. The speed of the Rotary effect now changes (either slow or fast undulations).

**Note:** A Keyboard part that uses the M-FX cannot be processed by the Reverb or Chorus effect. But as you will see on p. 44, the M-FX also contains Reverb and Chorus algorithms (either in isolation or in combination with other effects).

- (1) Press and hold the [M-FX EFFECTS] button until the message line in the upper left-hand corner reads "M-FX":




- (2) Use the [TEMPO/DATA] dial to select another M-FX type.  
 (3) Again play a few notes and listen to what it sounds like.

**Note:** M-FX type selection can also be linked to Tone selection for the Upper 1 part. See "Tone MFX" (p. 45).

### Assigning the M-FX to other Keyboard parts


As stated above, the M-FX can be assigned not only to the Upper 1 part (default) but also to the Upper 2 and Lower parts. Doing so is easy (though you could also use the FUNCTION menu):

- (1) Switch on the M-FX (see above).
- (2) Press and hold the [M-FX EFFECTS] button.



The [UPPER 1] indicator starts flashing (signalling that the M-FX is currently active for the Upper 1 part).

- (3) While still holding [M-FX EFFECTS], press [LOWER] and/or [UPPER 2].



The indicator(s) of the PART SELECT button you press start flashing as well, while the message line of the display shows:



(This message means that the Lower part was assigned to the M-FX.) To switch off the M-FX assignment, repeat the above procedure (the indicator goes dark again), or simply turn the [TEMPO/DATA] towards the left.


- (4) Press [SONG], [STYLE], [TONES], [USER PROGRAM], or [MUSIC ASSISTANT] to leave this page.

## Reverb and Chorus

The EM-55 also provides digital Reverb and Chorus effects. The main thing you probably want to do with these effects is switch them on/off and select other types. Via the FUNCTION menu, you can also set the Send level (the amount of Reverb or Chorus) to be applied to the various parts. See p. 45. Please bear in mind that these effects cannot be combined with the M-FX for the Keyboard parts.

### Reverb

- (1) Press and hold the [FUNCTION] button, while pressing the BANK/NUMBER [6] button.



This selects the "REV" function:




- (2) Use the [TEMPO/DATA] dial to select one of the available types (see right). Select "OFF" if you do not need the Reverb effect.
- (3) Press [SONG], [STYLE], [TONES], [USER PROGRAM], or [MUSIC ASSISTANT] to leave this page.

Type	Explanation
Room 1~3	These types simulate the Reverb characteristics of a room. The higher the number (1, 2, or 3), the "bigger" the room becomes.
Hall 1, 2	These types simulate the Reverb of a small (1) or large (2) concert hall and thus sound far "bigger" than the Room types above.
Plate	Digital simulation of a metal plate that is sometimes used for creating Reverb effects. Works well for percussive sounds.
Delay	A Delay effect (no Reverb). Works a lot like an echo effect and thus repeats the sounds.
Pan Delay	This is a stereo version of the preceding Delay effect. It creates repetitions that alternate between the left and right channels.



## Chorus

- (1) Press and hold the [FUNCTION] button, while pressing the BANK/NUMBER [7] button.



This selects the "CHR" function:



- (2) Use the [TEMPO/DATA] dial to select one of the available types. Select "OFF" if you do not need the Chorus effect.

Off	Chorus 3	Flanger
Chorus 1	Chorus 4	S-Delay
Chorus 2	FB Chorus	SDelayFb

We could try to describe them, but you will get a better idea by selecting one after the other. Flanger or FB Chorus can be interesting for guitar Tones.

Again, there are two echo effects: Short Delay ("S-Delay") and Short Delay with Feedback ("SDelayFB"). They are, however, much shorter than those available for the Reverb effect processor.

- (3) Press [SONG], [STYLE], [TONES], [USER PROGRAM], or [MUSIC ASSISTANT] to leave this page.

**Note:** The Chorus Send Level of the Upper 1/2 and Lower parts is set to "0", which means that these parts are not automatically processed by the Chorus effect. See the Chr UP1, UP2, and LWR parameters on p. 45 and following for how to set them.

## Balance

The **BALANCE** [◀ACCOMP] and [KEYBOARD▶] buttons allow you to change the volume balance between the Arranger (or Song) parts and the Keyboard parts (the ones you can play yourself).

- (1) Press **BALANCE** [◀ACCOMP] if the Arranger (or Song parts) are too soft.
- (2) Press **BALANCE** [KEYBOARD▶] if you think your solo playing should be louder. Not all Keyboard parts are available at all times.


**Note:** See p. 43 for setting the volume of individual parts.



## Transpose

The Transpose function changes the pitch of the notes and chords you play. Instead of figuring out what other keys you need to press to accommodate the singer or an instrumentalist, you can set the required Transpose value and go on playing the song the way you practised it while sounding in a different key. See the example below.

- (1) Press the [TRANPOSE] button (indicator lights).



The default transposition interval is "1" (one semitone up).

### To change the interval:

- (1) Press and hold the [TRANPOSE] button until the "TrpValue" message appears in the display.
- (2) Use the [TEMPO/DATA] dial to select the desired transposition interval (-6~5 semi-tones).

Here's an example: if you want to hear a "D" every time you play a "C", select "2". All other notes will be shifted by the same amount so that you end up sounding in D major when you actually play in C major, etc.

No transposition (C major)



TrpValue= 4 (E major)



- (3) Release the [TRANPOSE] button.
- (4) Press the [TRANPOSE] button again to switch off the Transpose function (if it is still on).

The [TRANPOSE] indicator goes dark.

**Note:** There is also a function that allows you to specify which section(s) the Transpose function should apply to. See "Trp Mode" (p. 42).

## Other Keyboard part functions

Here are yet other functions related to the Keyboard parts. These can be set via the FUNCTION menu, or are covered elsewhere:

- Keyboard velocity (see p. 33)
- Octave transposition of the Upper 1, Upper 2, and Lower parts (see p. 43)
- Master Tune (see p. 42)
- Volume of the Keyboard parts (see p. 43)
- Intelligence function for the Lower part (see p. 44)
- Hold function for the Lower part (see p. 44).

## 11. Performance functions


### Keyboard Velocity

The EM-55 is velocity sensitive, which means that the volume and brightness of the Upper 1/2 and Lower notes depend on the force/speed with which you strike the keys.

All acoustic instruments (piano, violin, flute, drums, etc.) are velocity sensitive. The harder you play, the louder and brighter the resulting notes will be, which creates a perfectly natural effect. (That explains why the KEYBOARD VELOCITY function is on every time you power on the EM-55.)

If the EM-55 is your first musical instrument ever, you may feel distracted by the volume and timbre variations of the notes you play in the Upper section.

- (1) Press and hold the [FUNCTION] button, while pressing the BANK/NUMBER [1] button.



This selects the "KbdVelo" function:



- (2) Use the [TEMPO/DATA] dial to select one of the available options:

**Off:** The EM-55 does not respond to changes in playing dynamics. All notes you play will have the same volume and timbre (tone colour).

**Low:** Choose this setting if only significant differences in playing dynamics should produce noticeable changes.

**Med:** This setting corresponds to standard velocity sensitivity, i.e. the most natural response.

**Hig:** Choose this setting for maximum expression. Though you will have to hit the keys harder than usual to play loud and bright notes, this setting allows for precise control of the volume/timbre (even though it may require some training).

- (3) Press [SONG], [STYLE], [TONES], [USER PROGRAM], or [MUSIC ASSISTANT] to leave this page.


**Note:** Quite a few Tones use "velocity switching". This means that your striking force sometimes selects a different sound. So only switch off this parameter if doing so makes you feel more comfortable.

**Note:** Keyboard Velocity applies to all parts you can play yourself (the "Keyboard parts"): Upper 1/2, Lower, M.Bass (page 43), and M.Drums (page 18).

### Pitch Bend and Modulation

The BENDER/MODULATION lever to the left of the EM-55's keyboard can be used to add two kinds of effects to the Keyboard part notes. You can even use these effects simultaneously if you like.

- (1) Press the lever towards the rear of the EM-55 to add a vibrato effect ("wobble") to the notes you are playing.
- (2) Turn the lever to the left to temporarily lower the pitch of the notes you are playing. Turn it to the right to raise the pitch of your notes.
- (3) In either case, you can release the lever if you no longer need the effect.



The Modulation axis can also be used for switching between the slow and fast Rotary speeds (if the "Rotary" effect is assigned to the M-FX).

## Footswitch/Expression

The EM-55's FOOTSWITCH/EXPR socket (rear panel) allows you to connect optional DP-2, DP-6, or BOSS FS-5U footswitch, or an EV-5 expression pedal.

### Footswitch

An optional footswitch can be used for sustaining the notes you are playing (default), as Soft or Sostenuto pedal, to switch the Rotary effect speed (M-FX), and more. See "FSW (Footswitch Assign)" (p. 45).

### Expression


Instead of connecting a footswitch to the FOOTSWITCH/EXPR socket, you can also use an expression pedal. That would allow you to control the EM-55's volume by foot.

**Note:** Please note that you cannot connect both a footswitch and an expression pedal.

## D Beam functions

The D Beam Controller is no doubt the most exciting and spectacular performance function of your EM-55. You can use it to modify various aspects of your Interactive Keyboard. Let's have a look at how to do that.

The D Beam Controller has two sensors that detect motion (such as your hand or body movements) in front of it. These "sensed" positions are translated into MIDI messages that can be assigned to a variety of parameters.



(1) Press the D BEAM CONTROLLER [ON/OFF] button (indicator must light).

(2) Use the [ASSIGN] button to select the function the D Beam Controller should perform.

There are 4 groups (DJ GEAR, SOUND EFX, INSTRUMENTS, and CONTROLS). This means that you may have to press the [ASSIGN] button several times in order to select the desired function.

To assign another function to the D Beam Controller:

(3) Hold down [ASSIGN] until the currently assigned D Beam function appears in the message line of the display.

(4) Use the [TEMPO/DATA] dial to select the desired function (see below).

The assignments of all four groups (DJ GEAR, SOUND FX, INSTRUMENT, CONTROLS) will be saved to a User Program, so that you can also alternate between these groups while playing – and still use your favorite settings.

(5) Press [SONG], [STYLE], [TONES], [USER PROGRAM], or [MUSIC ASSISTANT] to leave this page.

### DJ GEAR

**Vinyl RPM:** allows you to simulate the sound you hear when manually turning a vinyl record to locate (cue) the position where you wish to start playback.

**Cutting:** this is very powerful filter effect that allows you to suppress the high frequencies in a rhythmic way (like a DJ does sometimes).

**TT Motor:** simulates the effect you hear when you suddenly stop a turntable: the playback speed decreases, while the pitch drops and the sound becomes muffled.

**Scratch:** the D Beam Controller can be used for adding scratch noises. You know what that is, don't you...?

**Tape RWD:** allows you add the sound you hear when you rewind a cassette tape without stopping playback (the music plays backwards and at a high speed).

### SOUND EFX

Here, you can select various "noises" to be added to your music simply by moving your hand over the D Beam. We will not try to describe them: just try them out!

Chimes, Boeeen, Buble, Pour Btle, Fng Snaps, Voice One, Voice Aou, Explsion, Gun Shot, Engine, Applause, Laughing, Train Hrn, Bird, Dog, Seashore, Rain.

## INSTRUMENTS

In this case, the D Beam will play musical notes. The pitch and chords of those patterns depend on the notes you play in the left half of the keyboard (in Arranger mode).

Harp, Marimba, Mandolin, Guitar 1, Guitar 2, JazzScat, Bell, BassDrum, LoFi Rave, Sweep, Beep.

## CONTROLS

All options marked with a "o" apply to the currently active Keyboard parts.

**Start:** Depending on the current condition of the Arranger (running or stopped), one move inside the D Beam's range stops (or starts) it. A second movement will start (or stop) it again.

**Fade Out:** By moving your hand over the D Beam's eyes, you start a fade-out (the CONTROLS indicator flashes, which means that the volume of all EM-55 parts gradually decreases). As soon as it reaches "0", Arranger playback will stop. After a few seconds, the volume then returns to normal. (If you like, you can stop the fade-out after triggering it by pressing [ON/OFF].)

**Fill:** Here, the D Beam performs two functions that depend on the currently selected Division (Original or Variation). The first time the D Beam senses your hand (or other limb), it activates the Fill-In TO VARIATION function. Upon completion of that Fill, the Arranger switches to the Variation pattern. The second time, the Fill-In TO ORIGINAL is activated.

**Drum Off:** This setting allows you to switch the Arranger's drum part on and off using the D Beam Controller. There are also combined on/off options (see below).

**Bass Off:** This setting allows you to switch the Arranger's bass part on and off using the D Beam Controller.

**Acc Off:** This setting allows you to switch the Accompaniment parts (ACC1~6) on and off using the D Beam Controller.

**Bst&Dr Off:** This setting allows you to use the D Beam for switching the Arranger drum and bass on and off.

**Acc&Bs Off:** This setting allows you to use the D Beam for switching on and off the bass and ACC1~6 parts.

**Acc&Dr Off:** This setting allows you to use the D Beam for switching on and off the Arranger drum and ACC1~6 parts.

**Tempo Up/Down:** Select one of these options if you want to increase (Up) or decrease (Down) the current Arranger or Song tempo. By moving your hand outside the D Beam's range, you return to the previous tempo value.

**Modulation:** Select this function if you want the D Beam to duplicate the modulation function of the Bender/Modulation lever.

**PBend Up:** By moving your hand over the D Beam, you can generate a value between "64" (no Pitch Bend) and "127" (maximum upward bend). As soon as you move your hand outside the D Beam's reach (higher than  $\pm 40$ cm above the "eyes" or further to the left or right), the value returns to "64" (no Pitch Bend). The extent to which a Keyboard part can be controlled depends on the PB Range setting (see p. 43).

**PBend Dwn:** By moving your hand over the D Beam, you can generate a value between "64" (no Pitch Bend) and "0" (maximum downward bend). As soon as you move your hand outside the D Beam's reach, the value returns to "64" (no Pitch Bend). The extent to which a Keyboard part can be controlled depends on the PB Range setting (see p. 43).

**Filter Up:** (Only for Upper1 and/or 2) By moving your hand over the D Beam, you can vary the brightness of the Upper1 and/or 2 part. This allows you to create some nifty filter effects that are particularly useful for Dance/Techno music. When you move your hand outside the D Beam's range, the sound returns to its normal value.

**Filter Dwn:** (Only for Upper1 or 2) By moving your hand over the D Beam, you can vary the brightness of the Upper1 and/or 2 part. This is the opposite of the above: you can make the sounds mellower.

**Arpeg Oct 1/2/3:** By moving your hand over the D Beam, you cause the Lower part to play arpeggios (broken chords) based on the notes you play in the left half of the keyboard (in Arranger mode). Depending on the setting you select here, the notes of the chord recognition area will be arpeggiated over 1, 2, or 3 octaves.

**Note:** Do not forget to assign a suitable Tone to the Lower part.

**Chord Oct 1/2/3:** By positioning your hand inside the D Beam's range, you cause the Lower part to sound the notes of the chords you play in the left half of the keyboard. You could use this function to add syncopated brass or guitar "hits" to your melody. The velocity value used for playing these notes is "100". The number (1, 2, or 3) bears on the octave of this "added chord": 1 = A $\flat$ 3~G4, 2 = A $\flat$ 4~G5, and 3 = A $\flat$ 5~G6. Move your hand outside the D Beam's range to stop the Lower part from sounding the chord.

**Note:** This function is only available while the Arranger is active.

## 12. Recorder functions

The EM-55 comes with a 16-track Recorder that can be used in several ways. On p. 20 we showed you the most straightforward way of using the Recorder. Here, you will get to know nuts and bolts.

### About the recording modes

#### Modes

The EM-55 provides two modes for recording new music, and two for adding parts or correcting passages of existing music:

#### Recording a new song:

- ALL** In this mode, you can record everything you and the EM-55 can play simultaneously:
- Arranger (accompaniment),
  - Keyboard parts (Upper 1/2, Lower, M.Bass – or M.Drums)
  - Style Pad performance (DJ PAD performance is also possible, but then the Arranger will not be available)
  - D Beam performance.

- Keyboard** In this mode, you can record using the Keyboard parts
- Upper 1/2, Lower, M.Bass – or M.Drums.

#### Adding parts to an existing song

- Single** In this mode you can record onto one track at a time. The track can be freely selected (unlike for the preceding modes).

- Punch I/O** This mode allows you to re-record a short section of an otherwise perfect part.

**Note:** Every time you select the ALL or KEYBOARD mode, anything you may have recorded previously will be erased.

#### What are tracks?

The term "track" is used only for your convenience. We borrowed it from tape recorders that allow for recording several musical parts by the same person (one part after the other).

In the case of the EM-55, the term is only used to indicate that we are dealing with separate musical parts. Here indeed (like with computer-based sequencers) what really counts are the MIDI channels.

Why are we telling you this? Just to suggest that you could also use external MIDI controllers (drum pads, etc.) for recording certain parts – you do not need to use the EM-55's keyboard all the time (and you could also transmit certain parts from a computer). The MIDI channels correspond to the track numbers.

#### Recorder memory

The EM-55 provides one Song memory, which means that it can contain one Song. After completing a Song, you must save it to floppy disk (see p. 52).

To keep you from accidentally erasing the Song in the EM-55's internal memory, the EM-55 automatically selects SINGLE mode after your first recording. Bear in mind that **selecting ALL or KEYBOARD will erase** the Song currently in the EM-55's memory. Do not select ALL or KEYBOARD for adding parts to an existing Song – use SINGLE or PUNCH I/O instead.


Conversely, it is impossible to select SINGLE or PUNCH I/O if the Song memory doesn't yet contain data.

And finally: playing back a Standard MIDI File erases the Song in the EM-55's memory. In return, the SMF data will be available (and can be supplemented with your own renditions in SINGLE or PUNCH I/O mode).

### More about ALL mode

In addition to what you learned on p. 20, here are a few considerations:

After pressing [● REC], the 16 track and [RECORD] icons start flashing, signalling that all 16 tracks are available for recording.



Here is what the tracks correspond to:

- |                 |                              |
|-----------------|------------------------------|
| 1 Accomp 1      | 9 Accomp 6                   |
| 2 Arranger bass | 10 Arranger drums            |
| 3 Accomp 2      | 11 ► Lower                   |
| 4 ► Upper 1     | 12 ► M. Bass                 |
| 5 Accomp 3      | 13 Style Pads (see p. 22)    |
| 6 ► Upper 2     | 14 D Beam part (see p. 34)   |
| 7 Accomp 4      | 15 Melody Intell (see p. 24) |
| 8 Accomp 5      | 16 ► M. Drum                 |

For your convenience, the Keyboard parts are flagged with a "►" symbol in the above graphic.

Parts you do not hear during recording will not be recorded. This applies to the Keyboard parts (Upper 1, 2, Lower, M. Bass, M. Drums), and to the Arranger parts (see p. 21), but also to the D Beam and the Style pads. The track icons 1 ~ 16 thus do not show you what will be recorded, but rather what can be recorded.

**Note:** If you activate the DJ PAD function (see p. 9), the Arranger is not available.

**Note:** If you select the M.DRUMS mode, Upper 1, 2, Lower and M.Bass are not available, while the Arranger can only play the Arranger drum part.


**Note:** See p. 43 for how to switch on the M.Bass part.

### KEYBOARD recording mode

In KEYBOARD mode, you can only record the Keyboard parts. The Arranger is not available. Essentially, this mode allows you to record either one layered part using up to four sounds (Upper 1, 2, Lower, M.Bass), or two parts (Lower & M. Bass to the left, Upper 1 & 2 to the right). If you select the M.Drums mode, you can only record a drum part.

**Note:** Selecting KEYBOARD mode means that the Song data in the EM-55's memory will be overwritten by your new recording.

- (1) Press the [● REC] button.
- (2) Use the [TEMPO/DATA] dial to make the display look as follows:



The indicated track icons flash to signal that those are the tracks you can record to.

- (3) To create a split between Lower (and possibly M. Bass) for your left hand, and Upper 1 and 2 for your right hand, press the KBD MODE [ARRANGER] button. The Arranger is not available as such, but pressing this button creates a split.
- (4) Activate the metronome (if necessary), and set the desired tempo with the [EXECUTE/TAP TEMPO] button.

You can also record without metronome if you like.

**Note:** The M.Bass part can be added to the Lower part. You must switch it on via the FUNCTION menu (see p. 42).


**Note:** In M.DRUMS mode, only the Keyboard part of the same name is available.

### SINGLE recording mode

This mode is only available if the EM-55's Song memory already contains data. When you press [● REC], the [RECORD] icon and icon of the first empty track flash. This means you could record a new part straight away. (If all tracks already contain data, Track 1 will be selected.)


You can, however, also substitute an already recorded part with a new version.

- (1) Press the [● REC] button.
- (2) Use the [TEMPO/DATA] dial to select "SINGLE".
- (3) Use the SESSION PARTNER PADS/TRACKS buttons [1/9]~[8/16] to select the track you wish to record to:



### Punch I/O

In this mode, you can re-record part of a track (the second chorus, for example). The important aspect of this mode is that newly recorded material does not erase the material before or after the passage you redo:



By contrast, in SINGLE mode, the entire track you record is replaced by your new material. (So if you don't play anything during recording, the entire track will be empty afterwards.)


Like the SINGLE mode, PUNCH I/O can only be selected if the EM-55's memory already contains Song data

As you will notice, there are "only" 8 track buttons in the SESSION PARTNER section. Use the [TRACK] button to the right to select either track group 1~8 (upper row) or 9~16 (lower row).


You can only select one track (hence the name "SINGLE") at a time. If you select a track that already contains data, your new version will overwrite the existing one.

- (4) If necessary, assign the desired Tone to the part you are about to record (see p. 15).  
If you select track [10], you can select Drum Sets rather than Tones. Track 10 is reserved for drum parts.
- (5) Press [START/STOP] to start recording. After a two-measure count-in (see p. 46), you will hear all parts that have already been recorded. Start playing (and recording) your new part.
- (6) Press [START/STOP] to stop recording.
- (7) Return to step (3) to record additional parts.

- (1) Press the [● REC] button.
- (2) Use the [TEMPO/DATA] dial to select "PUNCH I/O".



- (3) Use the [TRACK] and SESSION PARTNER [1/9]~[8/16] buttons to select the track you want to record to.
- (4) Use the [◀◀] or [▶▶] button to jump to a measure that lies a little ahead of the place where recording is to be started.




You thus do not have to start the Song from the beginning if that is too time-consuming. If you want to start recording in measure 25, for example, you could select measure 23.

- (5) Press [START/STOP] to start playback of the (old) Song data.




The [● REC] indicator, the **RECORD** icon and the icon of the selected track flash.

- (6) When the Recorder reaches the measure where you wish to start recording, press [● REC] again.



- (7) Play the passage you want to redo.  
 (8) Press [● REC] again to deactivate recording.



Song playback still continues, so...

- (9) Press [START/STOP] to stop playback.  
 (10) Press [◀◀] to return to the measure where you started recording, and press [START/STOP] to listen to the new version. If you are not satisfied, return to step (4).  
 Return to step (3) to correct another track.

### Using a footswitch for punching in/out

You can also use an optional footswitch for starting and stopping recording. That has the advantage that you can use both hands for playing (or the left hand for D Beam/ Pitch Bend/Modulation effects and the right for playing the melody.)

- Connect an optional DP-2, DP-6, or BOSS FS-5U footswitch to the FOOTSWITCH/EXPR socket on the EM-55's rear panel.
- Press and hold [FUNCTION] while pressing BANK/NUMBER [3].  
By doing so, you jump to the PAD function (see also p. 22).
- Press [FUNCTION] again and turn the [TEMPO/DATA] dial to the left to select the following function:



(Steps (2) and (3) are a short-cut for quickly selecting the desired function.)


- Wait until the VALUE message in the top left-hand corner starts flashing, then use the [TEMPO/DATA] dial to select **Punch I/O**.
- Press [● REC] to return to the recording function.
- Continue with step (2) under "Punch I/O". In steps (6) and (8), press the footswitch (rather than the [● REC] button).

## Playback functions


The [INTRO], [ORIGINAL], etc. buttons have two functions: one in Style mode (printed above the buttons), and another one in Song mode (printed below the buttons).

### Selecting the Song mode

The Style/Song control buttons have two functions: they can be used for selecting Music Style patterns (when the [ARRANGER] indicator lights), or for Song navigation (when the [SONG] indicator lights).



To select the Song mode (and the Song control functions), you need to press the [SONG] button. Only then will the following functions be available.



### Fast Forward, Rewind, and Reset

- To **fast forward** (jump to a measure later in the song), press [▶▶].
- To **rewind** (return to a measure that lies before the current position), press [◀◀]. The measure indication in the upper right corner of the display will help you locate the measure you need.
- Press [◀] (Reset) to jump back to the **first measure** of the song. You need to stop playback before using the [◀] button. **Note:** In certain cases, [▶▶] and [◀◀] may not be available. This is only the case for very large songs, however.

### Loop playback (Repeat)

Another clever feature of the EM-55's Recorder is that you can program playback loops. You can do so during playback or while the Recorder is stopped.

- (1) Press [MARKER A-B] where you want the loop to begin (the button's indicator flashes).



- (2) Fast forward to the measure where you want the loop to end and press [MARKER A-B] again (the indicator lights).



You can also program loops on the fly. Remember, however, that the Recorder always memorizes the beginning (down-beat) of the next measure.

- (3) To play back the loop you have just programmed, first press [SYNC START] and then [START/STOP].

At the end of the B measure, the Recorder immediately jumps back to the beginning of measure A.

**Note:** In certain cases, the Marker function may not be available. This only happens with very large songs, however.

### Live performance with song backing (Minus One)

Your EM-55 allows you to mute the solo part of the song you are playing back. This is called Minus One playback (because one part of the original song will not be played back).

- (1) Press the [SONG] button. You can now select a Song on disk, if you like (see p. 41).


- (2) Press the [MINUS ONE] button.
- (3) Press [◀] and [▶/■] to start playback.
- (4) You will now hear all parts except the melody, which can be played using the Upper 1 part.

**Note:** An even more powerful function is available via the SESSION PAD buttons. It allows you to mute several tracks (Minus One only mutes the melody).

### Muting tracks using the SESSION PARTNER buttons

If you like, you can also mute other Song parts, which is similar to the Minus One function:

Press the [1/9]~[8/16] buttons of tracks you do not want to hear (the corresponding indicators go dark).




Buttons assigned to tracks that contain data light. As you will notice, there are "only" 8 track buttons in the SESSION PARTNER section. Use the [TRACK] button to the right to select either track group 1~8 (upper row) or 9~16 (lower row).

## Playing back Standard MIDI Files

The EM-55 allows you to play back commercially available music data files (called Standard MIDI Files) or your own songs you saved to disk.

In fact, when you save a song to disk, it is saved as Standard MIDI Format 1 file and can also be played back using any other SMF compatible sequencer (or software).

- (1) Insert a floppy disk with Song/Standard MIDI File data into the drive.
- (2) Press the [SONG] button to switch to the Song mode.



This is necessary because, otherwise, pressing the [START/STOP] button will start Arranger playback.



- (3) Press [SONG] again to display the name of the first Standard MIDI File on disk. What is actually displayed depends on whether you have inserted a disk and whether it contains Standard MIDI Files. See below for what the various messages mean.

Message	Meaning
Empty	The Song memory does not contain data (you have neither recorded a song nor played back a song on disk).
No Disk	You forgot to insert a disk into the drive.
No Files	The disk you inserted into the drive does not contain Standard MIDI Files.
IntSong	You selected the Song you recorded yourself (internal memory).

- (4) Use the [TEMPO/DATA] dial to select the Standard MIDI file you want to listen to.  
**Note:** Please bear in mind that starting playback of the selected song on disk will erase your own song. Be sure to save it to disk before proceeding (see p. 52).
- (5) Press [START/STOP] to load the first data chunk and start playback.  
You can also wait for the flashing "EXE" message and press [EXECUTE]. You then need to start playback by pressing [START/STOP].

Press this button once again to stop playback. See also "Fast Forward, Rewind, and Reset" (p. 40) and "Loop playback (Repeat)" (p. 40) for other functions you can use during playback.

If one of the following error messages appears, either select another Standard MIDI File or insert another disk:

Message	Meaning
NoFormat	The inserted floppy disk has not been formatted for the EM-55.
File Err	The selected file cannot be read.
Over 18T	The Standard MIDI File contains more tracks than the EM-55 can handle.

### Changing the song tempo

You can change the song tempo with the [TEMPO/DATA] dial. Doing so, however, means that the tempo will still change if the song you are playing back contains tempo change messages. Furthermore, every time you jump back to the beginning of the song using [◀], the programmed song tempo will be set.


## 13. Function menu

The EM-55's Function mode contains more advanced settings you may not need every day. They allow you to fine-tune your instrument's response. It would therefore be a good idea to familiarize yourself with these parameters. All settings (except Mstr Tune, EP Chord, Local and Resume) can be written to a User Program (see p. 47).

### Editing parameters (general procedure)

You can edit the EM-55's FUNCTION parameters via the display. Here is a general outline to be used for all parameters discussed below:

- (1) Press [FUNCTION].



The name of the last function you selected appears in the display.

- (2) Use [FUNCTION] or the [TEMPO/DATA] dial to select the parameter you wish to edit (see below).
- (3) Wait until the VALUE message starts flashing.  
The "VALUE" message above the parameter value means you can change ("edit") the value of the selected parameter.
- (4) Use the [TEMPO/DATA] dial to modify the value of the selected parameter.

### General Function parameters

#### ■ Kbd Velo

(Off, Low, Med, Hig; Default setting: Med) Use this parameter to set the EM-55's velocity sensitivity. See p. 33.

**Note:** This parameter can also be selected by pressing [FUNCTION] + [1].

#### ■ MstrTune (Master Tune)

(427.4~452.6, Default setting: 440.0) This parameter allows you to change the EM-55's overall tuning, which may be necessary when you accompany a singer, an acoustic instrument, or when you play to a recording on CD or cassette.

#### ■ TrpValue (Transpose interval)

(-6~5, Default setting: 1) Use this parameter to transpose the EM-55 in semitones. If you're not sure what transposition is, see p. 32. This parameter can also be selected by holding down the [TRANPOSE] button.

#### ■ Trp Mode

(Default setting: Int+Song) This parameter allows you to specify which parts should be affected by the Transpose setting:

**Note:** To return to the default value of the currently selected parameter, press and hold [EXECUTE].

- (5) Press [FUNCTION] again and use the [TEMPO/DATA] dial to select another Function parameter.
- (6) To leave the Function mode, press [SONG], [TONE], [STYLE], or [USER PROGRAM].

### Shortcuts

The following functions can be selected directly by holding down [FUNCTION] and pressing the corresponding [1]~[8] button of the BANK/NUMBER keypad.

#### FUNCTION

- 1 KBD VELOCITY
- 2 PART VOLUME
- 3 PAD SELECT
- 4 INVERSION
- 5 LOWER INT
- 6 REVERB
- 7 CHORUS
- 8 MIDI

**Int:** The Keyboard and Arranger parts will be transposed. Notes received via MIDI, however, will be played without change.

**Song:** Only the Song parts will be transposed. This is only meaningful when you play back a Standard MIDI File or one of your own songs with the EM-55's Recorder.

**MIDI:** Only the notes received via MIDI IN will be transposed.

**Int+Sng, Int+MIDI, Sng+MIDI, All:** These are combinations of the above. Int could be useful to transpose only the Keyboard parts so that you can play to a Recorder song in "your" key but sound in the song's key.

#### ■ Metro TS (metronome time signature)

(1/4~6/4, 6/8, 9/8, Default setting: 4/4) This parameter allows you to set the metronome's time signature (number of beats per bar). Please bear in mind that this setting changes whenever you select a Music Style with a different time signature. See also p. 17 for how to use the metronome. This parameter can also be selected by holding down the [METRONOME] button.

■ **Metro Vol (metronome volume)**  
(0~127, Default setting: 100) Use this parameter whenever you think the metronome is too loud/soft with respect to the music. The default value is usually an appropriate setting.

■ **UP1 Octv, UP2 Octv, LWR Octv (octave up/down)**  
(-4~0~4, Default setting: 0) These three parameters allow you to shift the octave of the part in question (Upper1, Upper2, or Lower) up or down by up to four octaves. This can be useful for Techno/Dance songs where you need a piano sound that plays in two different octaves. To achieve this, assign two different (or the same) piano sounds to Upper1 and Upper2, activate Upper 2 part (see p. 15), and set UP2 Octv to "-1" (or "1").

■ **MDrShift**  
(-4~0~4, Default setting: 0). This parameter allows you to shift the EM-55's keyboard in order to play drum/percussion sounds that are currently not accessible. Remember that there are only 61 keys, while some Drum Sets provide drum/percussion sounds for all 128 notes supported by the MIDI standard.

■ **PB Range (Pitch Bend Range)**  
(0~24, Default setting: 2) This parameter allows you to set the interval that will be used when you push the BENDER/MODULATION lever fully to the left or to the right (Pitch Bend effect). You can set this parameter in semitone steps, with a maximum of 24 semitones (2 octaves), the default value being "2", which should be OK in most situations.

**Note:** Pitch Bend is only available for the Upper1, Upper2, Lower, and M.Drums parts. See also p. 33.

■ **Upper 1, Upper 2, Lower, Man Drums: volume**



(0~127, Default setting: 127 Upper 1/110 Upper 2/100 Lower, 127 Man Drums) These four parameters allow you to set the volume of the Upper 1, Upper 2, Lower, and Manual Drums (or M.Drums) parts respectively. Please note that the settings you make here will have no effect if you used BALANCE [◀ACCOMP] to set the maximum volume for the Arranger/Song parts.

**Note:** This parameter can also be selected by pressing [FUNCTION] + [2].

■ **ManBass: status and volume**  
(OFF, 0~127, Default setting: OFF) Whenever the Lower part is active, this parameter allows you to set the volume of the M.Bass part. The M.Bass part sounds bass notes based on the chords you play. If the Lower part is active while the KBD MODE [ARRANGER] indicator lights, it can only be played in the left half of the keyboard. If the Bass Inversion function (see p. 24) is off, the M.Bass part sounds the root notes (fundamentals) of the chords you play with your left hand (using the Lower part).

■ **AccDrums, AccBass, Accomp: volume**  
(0~127, Default setting: 90 AccDrums, 90 AccBass, 127 Accomp) These three parameters allow you to set the volume of three Music Style sections: the drums, the bass and the Accomp parts (1~6). In fact, the parts correspond exactly to what can be selected using the STYLE MORPHING function (see p. 25). "0" is probably not a value you need to select here, because there is an easy way to switch off Arranger parts you do not need. See page 21.

**Note:** The "Accomp" parameter does not have the same function as the BALANCE [◀ACCOMP] button. The button applies to all Arranger parts (thus also to the "AccDrums" and "AccBass" parameters).

■ **Style Pad: volume**  
(0~127, Default setting: 110) This parameter allows you to set the volume of the ninth Arranger part you can trigger via the SESSION PARTNER [1/9]~[8/16] buttons. See p. 22.

■ **Arr Chord (Arranger Chord intelligence)**  
(On/Off, Default setting: On) When switched on, EM-55's Chord Intelligence function allows you to play major chords by pressing just one key, minor chords by pressing two keys, and more complex chords by pressing three keys. If you are used to playing full chords, you can switch this function off.

■ **ArrSplit (Arranger Split)**  
(48~84, Default setting: 60) Use this parameter to set the split point for the Arranger mode. The note you set here is the lowest note you can play with the Upper1/2 parts. The number refers to a note. "60" refers to the note "C4" (the one below the [MUSICAL GAME] button).

**Note:** This parameter also determines the split between the Lower (and possibly M.Bass) and the Upper 1/2 parts when the KBD MODE [ARRANGER] indicator lights.

■ **ArrMem (Arranger Chord Memory)**  
(On/Off, Default setting: On) The Arranger Chord Memory function memorizes the chords you play with your left hand and keeps playing the corresponding notes until you play another chord. If you switch off Arr Mem, the melodic Arranger parts (A.Bass, Accomp) stop playing as soon as you release the key(s) in the left half of the keyboard, leaving you only with the drum accompaniment. For your convenience, this function is switched on every time you power on the EM-55.

■ **EP Chord (left-hand E. Piano + bass)**  
(On/Off, Default setting: On) The EP Chord function activates an electronic piano and monophonic bass sound whenever (a) the [ARRANGER] indicator lights and (b) the Arranger is stopped. This allows you to play chords (and a bass line) with your left hand in Arranger mode - without using the EM-55's accompaniment function. If you select "Off", however, the left half of the keyboard will be muted when conditions (a) and (b) are met and if the [LOWER] indicator does not light.

### ■ LWR Mem (Lower Chord Memory)

(On/Off, Default setting: Off) The Lower Chord Memory function memorizes the chords you play while the Lower part is on and holds the corresponding notes until you play another chord. If you need this Hold function for the Lower part, switch it on.

### ■ LWR Int (Lower Chord Intelligence)

(On/Off, Default setting: Off) When you activate the [LOWER] button, the EM-55's Lower Chord Intelligence function allows you to play major chords by pressing just one key, minor chords by pressing two keys, and more complex chords by pressing three keys. This system thus follows Arranger control, which is why it would be a good idea to select "On" whenever you are using the Lower part while the KBD MODE [ARRANGER] indicator lights.

### ■ Bass Inv

(On/Off) Use this parameter to change the way in which the Arranger reads the chords you play. See p. 24.

## Rev (Reverb Type)



(Default setting: Hall 2) Use this parameter to select the kind of Reverb that best suits your musical purposes. See p. 30.

**Note:** This parameter can also be selected by pressing [FUNCTION] + [6].

### ■ Chr (Chorus Type)

(Default setting: Chorus 3) This parameter allows you to specify the sound of the Chorus effect. See p. 31.

**Note:** This parameter can also be selected by pressing [FUNCTION] + [7].

### ■ MI (Melody Intelligence harmony type)

(Default setting: Traditnl) This parameter allows you to select the desired harmony type for the Melody Intelligence function.

**Note:** This parameter can also be selected by pressing and holding the [MELODY INTELL] button. See p. 24.

### ■ MFX (M-FX type)

(Default setting: Rotary) This parameter allows you to select the desired M-FX type. See p. 29 for details about the M-FX. Keyboard parts that use the M-FX are no longer processed by the Reverb and Chorus effects. Selecting "Thru" means that the M-FX is off. Also note that you will only hear the M-FX if the [M-FX EFFECTS] indicator lights.

**Note:** This parameter can also be selected by pressing and holding the [M-FX EFFECTS] button.

**Note:** M-FX type selection can also be linked to Tone selection for the Upper 1 part. See "Tone MFX" (p. 45).

**Thru:** The M-FX is off.

**Enhancer:** An Enhancer controls the overtone structure of the high frequencies, adding sparkle and tightness to the sound.

**Overdrv1~4:** Overdrive creates a soft distortion similar to that produced by tube amplifiers. Several types of overdrive are available: (1) Small combo amp, (2) Combo amp, (3) Large double-stack amp (2 cabinets), (4) Large double-stack amp (3 cabinets).

**Distort1~4:** This effect produces a more intense distortion than Overdrive. The numbers refer to different kinds of distortion.

**Phaser:** Adds a phase-shifted sound to the original sound, producing a twisting modulation that creates spaciousness and depth.

**AutoWah:** The Auto Wah cyclically controls a filter to create cyclic change in timbre.

**Rotary:** Simulates the sound of a classic rotary speaker. This effect is most suitable for electric organ.

**StFlangr:** This is a stereo Flanger. It produces a metallic resonance that rises and falls like a jet airplane taking off or landing.

**SpFlangr:** A Step Flanger is a Flanger effect with clearly noticeable steps rather than continuous pitch changes.

**Compress:** A compressor reduces signal peaks and boosts low levels, smoothing out unevenness in volume.

**Limiter:** A limiter prevents the volume from exceeding a certain level without boosting low levels.

**HexaCho:** Hexa Chorus uses six layers of chorused sound to give richness and spatial spread to the sound.

**Trem Cho:** Tremolo Chorus is a Chorus effect with added Tremolo (cyclic modulation of the volume).

**StChorus:** This is a stereo Chorus.

**Space-D:** A multiple Chorus that gives no impression of modulation, but produces a transparent Chorus effect (the perfect "stereo maker").

**StDelay:** Delay is an effect that allows you repeat the input signal, thus creating echoes (repetition).

**Mod Delay:** This effect adds modulation to the delayed sound, producing an effect similar to a Flanger.

**3Tap Dly:** The Triple Tap Delay produces three delay sounds; center, left and right.

**4Tap Dly:** Delay with four repetition lines.

**TmCtrDly:** This effect controls the delay time and pitch in realtime. Lengthening the delay time will lower the pitch, and shortening it will raise the pitch.

**Reverb:** A nice Reverb effect.

**GteRevNr:** Gate Reverb is a special type of Reverb in which the reverberant sound is suddenly cut off (and does not gradually decrease).

**GteRevRv:** A gated Reverb effect that sounds "backwards".

**GteRevS1:** The reverberant sound moves from right to left.

**GteRevS2:** The reverberant sound moves from left to right.

**2PtchShf:** A Pitch Shifter changes the pitch of the original sound. This 2-voice effect has two pitch shifters, and adds two transposed copies to the original sound.

**FbPtchShf:** Pitch Shifter with several echoes.

**OD►Chors:** This effect connects an Overdrive and a Chorus in series. ("Series" means that the first effect is also processed by the second.)

**OD►Flgr:** This effect connects an Overdrive and a Flanger in series.

**OD►Delay:** This effect connects an Overdrive and a Delay in series.

**DS►Chors:** This effect connects distortion and a Chorus in series.

**DS►Flgr:** This effect connects distortion and a Flanger in series.

**DS►Delay:** This effect connects distortion and a Delay in series.

**EH►Chors:** This effect connects an Enhancer and a Chorus in series.

**EH►Flgr:** This effect connects an Enhancer and a Flanger in series.

**EH►Delay:** This effect connects an Enhancer and a Delay in series.

**Cho►Dly:** This effect connects a Chorus and a Delay in series.

**FL►Delay:** This effect connects a Flanger and a Delay in series.

**Cho►Flgr:** This effect connects a Chorus and a Flanger in series.

**Cho/Dly:** This effect connects a Chorus and a Delay in parallel. ("Parallel" means that the input signal is processed by two effects that do not interact.)

**FL/Delay:** This effect connects a Flanger and a Delay in parallel.

**Cho/Flgr:** This effect connects a Chorus and a Flanger in parallel.

**■ M-FX UP1, UP2, LWR**  
(On/Off, Default setting: UP1: On, UP2/LWR: Off)  
These parameters allow you to specify whether or not the Upper 1, Upper 2, or Lower part should be processed by the M-FX. See also p. 29.

**■ Rev UP1**  
(0~127, Default setting: 100) This parameter allows you to set the Reverb Send Level for Upper 1 (i.e. how much Reverb should be added to the Upper 1 notes). This parameter is not used when "M-FX UP1" is set to "On".

**■ Chr UP1**  
(0~127, Default setting: 0) This parameter allows you to set the Chorus Send Level for Upper 1 (i.e. how much Chorus should be added to the Upper 1 notes). If you want this part to be processed by the Chorus effect, you need to select a value different from "0". This parameter is not used when "M-FX UP1" is set to "On".

**■ Pan UP1**  
(0~127, Default setting: 64) This parameter allows you to set the stereo position of the Upper 1 part (i.e. its placement between the left and right speakers). "0" means that the stereo position changes randomly for each note you play. Values between "1" and "63" correspond to the left speaker. "64" refers to the center, and values between "65" and "127" correspond to the right speaker ("1"= hard left, "127"= hard right).

**■ Rev UP2**  
(0~127, Default setting: 100) This parameter allows you to set the Reverb Send Level for Upper 2 (i.e. how much Reverb should be added to the Upper 2 notes). This parameter is not used when "M-FX UP2" is set to "On".

**■ Chr UP2**  
(0~127, Default setting: 0) This parameter allows you to set the Chorus Send Level for Upper 2 (i.e. how much Chorus should be added to the Upper 2 notes). If you want this part to be processed by the Chorus effect, you need to select a value different from "0". This parameter is not used when "M-FX UP2" is set to "On".

**■ Pan UP2**  
(0~127, Default setting: 64) This parameter allows you to set the stereo position of the Upper 2 part (i.e. its placement between the left and right speakers). "0" means that the stereo position changes randomly for each note you play. Values between "1" and "63" correspond to the left speaker. "64" refers to the center, and values between "65" and "127" correspond to the right speaker ("1"= hard left, "127"= hard right).

**■ Rev LWR**  
(0~127, Default setting: 100) This parameter allows you to set the Reverb Send Level for the Lower part. This parameter is not used when "M-FX LWR" is set to "On".

**■ Chr LWR**  
(0~127, Default setting: 0) This parameter allows you to set the Chorus Send Level for the Lower part. If you want this part to be processed by the Chorus effect, you need to select a value different from "0". This parameter is not used when "M-FX LWR" is set to "On".

**■ Pan LWR**  
(0~127, Default setting: 64) This parameter allows you to set the stereo position of the Lower part (i.e. its placement between the left and right speakers). "0" means that the stereo position changes randomly for each note you play. Values between "1" and "63" correspond to the left speaker. "64" refers to the center, and values between "65" and "127" correspond to the right speaker ("1"= hard left, "127"= hard right).

**■ Tone MFX**  
(On/Off, Default setting: On) This parameter allows you to link the selection of an M-FX type to the Tone you assign to the Upper 1 part. That way, a Distortion/Overdrive effect will be selected for a rock guitar sound, Rotary for an organ, etc.

**■ FSW (Footswitch Assign)**

VALUE  
FSW Sustain

(Default setting: Sustain) After connecting an optional DP-2, DP-6, or BOSS FS-5U to the FOOT-SWITCH/EXPR socket on the rear panel, you can use this parameter for assigning a function to the foot-switch.

**Note:** This function is not available if you connect an optional EV-5 expression pedal instead.

**Sustain:** Also called "Hold" or "Damper", this function allows you to use the footswitch to hold the notes you play on the keyboard in much the same way as on an acoustic piano.

**Sostenut:** In this case, the footswitch functions as Sostenuto pedal (another pedal found on grand and digital pianos that allows you to sustain only those notes you played at the time you pressed the pedal).

**Note:** This function only applies to the Keyboard parts.

**Soft:** In this case, the footswitch functions as Soft pedal (a pedal found on grand and digital pianos that reduces the volume).

**Note:** This function only applies to the Keyboard parts.

**Rotary S/F:** Allows you to select the slow or fast speed of the Rotary effect. This only works, if the Rotary effect is currently assigned to the M-FX.

**UsrPrgUp:** Selects the next User Program (i.e. 12 if 11 is currently active).

**UsrPrgDw:** Selects the previous User Program (i.e. 64 if 11 is currently active).

**Start/Stop:** Starts and stops Arranger or Song playback. Same function as the [START/STOP] button.

**Exc UP1/2:** Allows you to switch off the Upper1 part and activate the Upper2 part, and vice versa.

**Bass Inv:** Switches the Bass Inversion function on and off (see p. 24).

**Punch I/O:** The footswitch can be used to activate and switch off punch in/out recording of the EM-55's sequencer (see p. 39).

#### ■ PAD (Style Pad set)

(Default setting: depends on the selected Music Style) This parameter allows you to select a different set of phrases when the SESSION PARTNER function is used in STYLE PAD mode. See p. 22.

#### ■ Pad Sync

(On/Off, Default setting: On) This parameter allows you to switch the synchronization of pad triggering on/off. When on, phrases you start by pressing the assigned [1/9]~[8/16] button will always begin at the first beat of the following bar. So even if you press a button on the second beat, playback will only start on the first beat of the following measure.

If you do not want this forced synchronization, select "Off". That may mean, however, that playback may be slightly offset with respect to the other phrases (DJ PAD mode) or Arranger playback (STYLE PAD mode).

#### ■ Count-In

(On/Off, Default setting: On) This parameter allows you to switch the count-in function for punch-in and normal recording (see p. 38) on or off. When on, the metronome will count down two measures (8 beats for a Song with a 4/4 time signature).

#### ■ Scale C~Scale B (Scale Tune)

(-64~63, Default setting: 0 for all notes) These parameters allow you to stray away from the usual semitone-interval scale (used in western music) by changing the pitch of the notes so as to accommodate other musical cultures or tuning methods (oriental, baroque music, etc.).

As you will notice, you can change the pitch of every note of one octave (C, C#, D, Eb, E...). The settings you make here apply to all notes of the same name (i.e. to every C, every C#, etc.). Most of the time, you will probably select the value "50" or "-50" as they correspond exactly to half a semitone up or down (quarter tone). Other settings may also be interesting, though.

#### ■ Sel Mode

(UP, ALL, Default setting: UP) This parameter allows you to specify which parts the Scale settings (see above) should apply to: only Upper 1 & 2 ("UP") or all parts ("ALL"). In some cases, choosing "ALL" may produce a more satisfactory result.

#### Resume

Select this function to recall the EM-55's factory Function settings.

**Note:** Resume does not reset the MIDI parameters of the FUNCTION mode (see p. 49).

Press [EXECUTE] in response to the flashing "EXE" message. After showing the "Complete" message, the display returns to the RESUME message. Press [SONG], [STYLE], [TONE], or [USER PROGRAM] to leave the FUNCTION mode.

**Note:** There is no "Sure?" question that gives you time to think. Only press [EXECUTE] if you are certain you want to recall ALL factory Function settings.



## 14. Working with User Programs


The EM-55 is equipped with 64 User Program memories that allow you to store almost all settings (or registrations) you make on the front panel and via the Function menu (see p. 42).

**Note:** MIDI settings (see p. 49) are not saved to a User Program because the EM-55 memorizes them automatically.

### Writing your settings to a User Program

It is a good idea to write your settings frequently, even if you still need to do some editing afterwards. Those intermediary saves allow you to return to the previous stage whenever you do not like your last modifications.


- (1) Press and hold the [USER PROGRAM/ WRITE] button.



The EM-55 now displays "Write ?".

- (2) Keep holding the [USER PROGRAM/ WRITE] button while pressing one numeric button [1]~[8] to select the bank.

The number you select appears in the USER PROGRAM field ("3" in the example below).



- (3) Keep holding the [USER PROGRAM/ WRITE] button while pressing another (or the same) numeric button [1]~[8] to select the memory.  
The display now responds with the "Complete" message and the memory number (your settings have been stored).
- (4) Release the [USER PROGRAM/ WRITE] button.

### Notes about writing User Programs


#### Leaving the User Program environment

Press [USER PROGRAM] to leave the User Program environment. The User Program field in the display will go blank again.

#### Mode selection

The mode (Arranger, p. 13, M.Drums, p. 18, Piano, p. 17) is also memorized when you write a User Program.

#### Meaning of the "Edit" message



At some stage, you may come across an "Edit" message next to the User Program number.

It means that the last User Program you selected is still in effect but that the current settings no longer correspond to the ones in that memory. Such changes may include the status of the Reverb or Chorus effect, a changed volume value, etc.

Before selecting another User Program or switching off the EM-55, you should therefore write these settings to the same (or a different) User Program if you want to keep them. Otherwise, you lose these changes. Please also see p. 48.


#### User Programs and Disk Links & Style Disk

The address of the last Music Style you selected before writing a User Program is also memorized. This even applies to the Style RAM memory that may contain a so-called Style Disk Style (see p. 26). The EM-55 only remembers the memory address—not the name of the Style it contained when you wrote your settings to a User Program. This also applies to the Disk Link memories in group B.

## Selecting a User Program

Though the User Program memory you specified above is already selected, there will be times when you need to select another memory. In that case, here is what you need to do:

- (1) Briefly press [USER PROGRAM/WRITE]. Do not hold this button down because doing so will start the Write procedure (see above).




The User Program field now indicates the number of the User Program you selected last, or "11" if you have not yet selected a User Program since switching on the EM-55. The important thing to note here is the "Edit" message.

It indicates that the EM-55 is still using the last manual changes you may have made before selecting the User Program function. The User Program number therefore only means "this is the last memory you selected".

None of its settings are being used for the time being. By pressing [USER PROGRAM/WRITE] again, you can leave the User Program mode without changing your manual settings. This may be important to remember if you were about to write your settings and accidentally pressed the wrong button (or didn't press it long enough).

To actually select a User Program...

- (2) Press one numeric button [1]~[8] to select the bank.



- (3) Press another (or the same) numeric button [1]~[8] to select the memory. The settings of the selected User Program will be recalled.

**Note:** As soon as you modify any setting (on the front panel or in the FUNCTION menu), the "Edit" message appears next to the User Program number.

- (4) Once again press [USER PROGRAM/WRITE] to leave the User Program mode.  
**Note:** You can also press [STYLE] and [TONE] to leave this mode.


## 15. MIDI functions

*MIDI is short for Musical Instrument Digital Interface. The word refers to many things, the most obvious being a connector type that is used by musical instruments and other devices to exchange messages relating to the act of making music.*

Each time you play on the EM-55's keyboard or start the Arranger (or Song), your instrument transmits MIDI data to its MIDI OUT socket. If you connect this socket to the MIDI IN socket of another instrument, that instrument may play the same notes as one of the EM-55's parts, select sounds, etc.

MIDI is a universal standard, which means that musical data can be sent to and received by instruments of different types and manufacturers. Furthermore, MIDI allows you to connect your EM-55 to a computer or hardware sequencer.

Connect your EM-55 as shown below.



### Channels

MIDI can simultaneously transmit and receive messages on 16 channels, so that up to 16 instruments can be controlled. Nowadays, most instruments –like your EM-55– are multitimbral, which means that they can play several musical parts with different sounds.

**Note:** All EM-55 parts are set to receive MIDI messages. If they do not seem to respond to the messages you send from the external controller, you should check whether the external controller's MIDI OUT is connected to the MIDI INput of your EM-55.

The EM-55's transmit and receive channels of all parts have been set in keeping with a tacit Roland standard and are therefore

shared by all recent E, G, and RA series instruments. You cannot change them. They also correspond to the track assignments of the 16-track Recorder:

- |                 |                   |
|-----------------|-------------------|
| 1 Accomp 1      | 9 Accomp 6        |
| 2 Arranger bass | 10 Arranger drums |
| 3 Accomp 2      | 11 ►Lower         |
| 4 ►Upper 1      | 12 ►M. Bass       |
| 5 Accomp 3      | 13 Style Pads     |
| 6 ►Upper 2      | 14 D Beam part    |
| 7 Accomp 4      | 15 Melody Intell  |
| 8 Accomp 5      | 16 ►M. Drum       |

## MIDI Function parameters

See "Editing parameters (general procedure)" (p. 42) for how to select and set these Function parameters (they belong to the same Function menu as the "General Function parameters").

### ■ MIDI TxRx (MIDI transmission and reception)

This parameter allows you to specify which EM-55 parts should transmit and receive MIDI messages:

Option	Meaning
ALL	All parts.
KBD	Only the Keyboard parts (see ► in the table above).
STL	Only the Arranger parts (A.Drums~Accomp 6).
OFF	None of the EM-55's parts transmits/receives MIDI messages.

### ■ Sync Rx (MIDI synchronization)

Use this parameter to specify how the EM-55 should be synchronized (as slave) to an external MIDI sequencer, computer, drum machine, etc. "Synchronization" is a learned term for the fact that one device (or function) is set to start and stop at the same time as another device (or function), and to run at the same tempo (BPM). Please note that synchronization is only possible when you connect the external device's MIDI OUT socket to the EM-55's MIDI IN socket (though you can also work the other way around; in that case, see the sequencer's manual for details).

- 
- Off In this case, the EM-55 is not synchronized with other MIDI devices. It is thus impossible to start/stop it via MIDI.
- 
- On Arranger playback and Song recording/playback are synchronized if the EM-55 receives MIDI Start and Stop messages followed by MIDI Clock signals. If the EM-55 receives only a Start message, it will wait a moment to see if there are also MIDI Clock messages coming. If there are, it will synchronize to them. If there are no MIDI Clock messages, it will follow its own tempo. In either case, you can stop playback or recording with a MIDI Stop message.
- 

■ **Style PC (Style Select TxRx Channel)**  
(1~16, Off, Default setting: 10) As its name implies, the Style Select channel is used to receive and transmit program changes that cause the EM-55 or the external instrument to select another Music Style.

■ **Lyrics Tx (Transmit Lyrics messages)**  
(On/Off, Default setting: On) The EM-55 is capable of transmitting Lyrics messages contained in Format 0 Standard MIDI Files you playback. It cannot display them but it allows you to transmit them to a device capable of displaying Lyrics messages (such as the Roland LVC-1). This filter allows you to enable (On) or disable (Off) the transmission of Lyrics data.

■ **NTA Rx14 (Note-to-Arranger reception on/off)**  
(On/Off, Default setting: On) NTA is short for "Note-to-Arranger", or the notes you play in the left half of the keyboard to feed the Arranger with chord information. These notes can also be received via MIDI (from an accordion, a digital piano, an organ, for example). If you want to use the Arranger without playing on the EM-55's keyboard, you must transmit these notes on MIDI channel 14 (from your computer or external MIDI instrument to the EM-55) and select "On" here.

NTA notes can only be received (they are not transmitted). The notes you play on the EM-55's keyboard are indeed transmitted to the Arranger, from there to the Arranger parts, and used to play the accompaniment in the right key. Since all Music Style notes are transmitted via MIDI, there is no need to send the NTA notes separately.

■ **PitchBnd (Pitch Bend)**  
(On/Off, Default setting: On) This filter allows you to enable (On) or disable (Off) the transmission and reception of Pitch Bend messages. These messages are used to temporarily increase or decrease the pitch of the notes (Upper1, Upper2, Lower, or M.Drums parts).

■ **Modulatn (Modulation)**  
(On/Off, Default setting: On) This filter allows you to enable (On) or disable (Off) the transmission and reception of Modulation messages. These messages are used to add vibrato to the notes you play (control change CC01).

■ **ProgChng (Program Change)**  
(On/Off, Default setting: On) This filter allows you to enable (On) or disable (Off) the transmission and reception of Program Change messages. These messages are used to select Tones, Styles, or User Programs.

■ **Velo Rx (Receive Velocity)**  
(On, 1~127, Default setting: On) This filter allows you to enable (On) or disable the reception of Velocity messages. This only applies to note messages received via MIDI. Choose the velocity value to be substituted for the actual values the EM-55 receives (1~127), or select "On" to use the velocity values as is.


■ **Clock Tx**  
(On/Off, Default setting: On) This option allows you to determine whether (On) or not (Off) the Arranger and Recorder send MIDI Clock messages when you start them. These messages are necessary for synchronizing external MIDI instruments/sequencers/software to the EM-55.

■ **StartStp (Start/Stop/Continue)**  
(On/Off, Default setting: On) This option allows you to specify whether or not the Arranger and Recorder send Start/Stop/Continue messages when you start or stop them. Select "Off" when you wish to control the tone generator of a MIDI organ, etc., without starting or stopping its automatic accompaniment.

■ **Song Pos P (Song Position Pointer)**  
(On/Off, Default setting: On) The EM-55's Recorder also sends and receives Song Position Pointer messages that indicate the exact location of the notes that are being played back. Select "Off" if you don't want the Recorder to send or receive these messages.

■ **Local**  
(On/Off, Default setting: On) The Local parameter allows you to establish or remove the connection between the EM-55's keyboard/Recorder and the internal tone generator.

When set to "ON" (default), playing on the EM-55's keyboard or playing back a Recorder song will cause the corresponding notes to sound. If you select "OFF", the corresponding MIDI messages are no longer sent to the internal tone generator - but they are still transmitted to the MIDI OUT port and hence to external MIDI instruments.




**Note:** The setting of this parameter is not memorized when you switch the EM-55 off.

**Note:** You can also select this parameter by pressing and holding the [SONG] button.

## 16. Using the outputs and an optional pedal

If you like, you can also record your performance (or the Recorder song) to cassette, MD, etc. To this end, you need to connect the EM-55's STEREO OUTPUT sockets to the external device's REC IN jacks.



Use a standard 1/4" phone cable for doing so. Another use for these outputs is to connect the EM-55 to your HiFi or keyboard amplifier (such as the Roland KC-500/300/100). Using a HiFi amplifier requires the use of an adaptor plug (phono/RCA→ 1/4" jack). If you like, you can also purchase two Roland PJ-1M cables.


**Note:** By connecting the OUTPUT jacks, you do not switch off the EM-55 amplification system.

You can connect an optional DP-2, DP-6, or BOSS FS-5U footswitch to the FOOTSWITCH/EXPR jack in order to hold the notes even after releasing the keys, or to perform other functions (see p. 45). If you connect an EV-5 expression pedal instead, you can control the EM-55's volume by foot (in which case it is no longer possible to connect a footswitch).

## 17. Disk functions

The EM-55's Disk functions allow you to save the Recorder Song in the internal Song RAM memory to disk, to save and load your User Programs to and from disk, to format floppy disks, to delete files on a floppy disk, and to copy disks.

Though you can use 2DD or 2HD floppies, 2HD disks have twice the capacity of 2DD disks, so use 2HDs whenever you can.


Whenever the disk drive writes data to or reads data on disk, the Disk icon (DISK ) flashes in the display. Do not remove the floppy disk while this icon is displayed as that may damage both the disk drive and the disk (so that it becomes unreadable).

### Loading User Programs from disk

This load function is called LOAD UPr. It allows you to transfer a set of 64 User Programs (i.e. for all memories) to the EM-55's internal memory. This will overwrite the User Programs that currently reside in the internal memories.

**Note:** If you wish to use the User Programs in the internal memory at a later stage, first save them to disk before proceeding. See p. 52.

- (1) Insert a disk into the drive.
- (2) Press [DISK] to select the Disk mode.



The "LOAD UPr" function is already selected, so there is nothing else you need to do.

- (3) Wait until the VALUE message starts flashing, then use the [TEMPO/DATA] dial to select the file whose contents you wish to load (example: "USPR\_000").
- (4) Press the [EXECUTE] button (next to [DISK]) to load the selected file.

**Note:** Press [DISK] if you do not want to load the selected file after all.

If you pressed [EXECUTE], the display now shows the message "Loading". Once the data have been loaded, the "Complete" message briefly appears.

- (5) Press [MUSICAL GAME], [TONE], [STYLE], or [FUNCTION] to select another mode.

#### Possible error messages

No Disk	You forgot to insert a floppy disk into the drive.
No Files	The disk you insert contains no User Program data.
Disk Err	The disk is probably damaged and cannot be used.
File Err	The file you selected is damaged and cannot be loaded.

### Saving files to disk

The EM-55 provides the following Save functions:

**SAVE UPr:** Use this function to save the contents of the internal User Program memories (all 64 of them) to a floppy disk.

**SAVE Sng:** This allows you to save the Song in the internal memory to a floppy disk. A Song saved to disk becomes a Standard MIDI File.

**Note:** There is no LOAD Sng function. All you need to do to transfer the Song data back to the internal Song memory is play back the Standard MIDI File in question.

- (1) Insert a disk into the drive.

Every floppy contains a square tab that allows you to "close" a little window. With the tab in that position, you can save data to the disk. Do not forget to write-enable the disk by closing this little window prior to inserting the floppy disk.


- (2) Press [DISK] and use the [TEMPO/DATA] dial to select "SAVE Sng" or "SAVE UPr".
- (3) Wait until the VALUE message starts flashing, then use [TEMPO/DATA] dial to move the flashing cursor to the character position you want to change (the "0" in the illustration below).



- (4) Enter the character with [A/B], the numeric keypad, and [VARIATION]. You may have to press the same button several times.

Though you could save the file with the current default name ("SONG\_001", or "USPR\_000"), a proper name will help you identify the file at all times. We therefore suggest you take the time to specify a meaningful name.

**Note:** If you select "SPACE" ([A/B] button), the display will insert a "\_". This is because MS-DOS® does not allow you to use spaces.

- (5) If necessary, use the [TEMPO/DATA] dial to move the cursor to the next position.
- (6) Repeat steps (4) and (5) to enter the remaining characters.
- (7) Press [EXECUTE] to save the file to disk. The display now responds with the message "Saving" as well as a flashing disk icon (DISK ). When the file is saved, the "Complete" message appears.  
If the message "DiskProt" appears, you forgot to switch off the disk's Write protection. Press the EJECT button of the disk drive, remove the floppy and close the tab, insert the disk again and press [EXECUTE].
- (8) Press [MUSICAL GAME], [TONE], [STYLE], or [FUNCTION] to select another mode.

#### Possible error messages

No Disk	You forgot to insert a floppy disk into the drive.
Disk Prot	See above.
Disk Full	The remaining disk capacity does not allow to save your data to this disk.
Disk Err	The disk is probably damaged and cannot be used.
Empty	There is no Recorder song in the internal memory. Consequently, there is nothing to save.
Imppsble	The song in the EM-55's memory is bigger than the RAM actually supports, and can therefore not be saved to disk. (This is because the EM-55 only loads specific blocks for playback.)
OverWrt?	The name you assigned to the data already exists on the floppy disk you inserted. If you press [EXECUTE] to continue, the file on disk will be overwritten (and the corresponding data will be erased). Either insert another floppy disk, or press [DISK] and enter another name for the data you want to save.

## Deleting files on disk

*The Delete functions allow you to delete a file from the inserted floppy disk. This may be necessary to make room for a new file (e.g. when the "Disk Full" message appears). Be careful, though, to only delete files you are absolutely (positively) sure you will never need again. Once a file has been deleted, it is gone forever.*

**Note:** As a rule, you should first make a backup copy of your disk (see p. 54). After all, files really only become indispensable once they are no longer available...

**DEL Sng:** This allows you to delete a song file on disk.

**DEL UPr:** Use this function to delete a User Program file from disk. Be aware that by doing so, you actually erase 64 User Program settings.

- (1) Insert the disk with the file you want to delete into the drive.
- (2) Press [DISK] to select the Disk mode.
- (3) Use the [TEMPO/DATA] dial to select "DEL Sng" or "DEL UPr".
- (4) Wait until the VALUE message starts flashing and use the [TEMPO/DATA] dial to select the file you want to delete (example: "USPR\_005").
- (5) Press the [EXECUTE] button.  
To be on the safe side, the EM-55 now asks you whether you really want to delete the file ("Sure?").
- (6) Press [EXECUTE] to delete the file, or [DISK] to abort the operation.

If you pressed [EXECUTE], the display now shows the message "Deleting". Once the data have been deleted, the "Complete" message briefly appears.

- (7) Press [MUSICAL GAME], [TONE], [STYLE], or [FUNCTION] to select another mode.

#### Possible error messages

No Disk	You forgot to insert a floppy disk into the drive.
Disk Prot	You forgot to switch off the disk's Write protection. Press the EJECT button of the disk drive, remove the floppy and close the tab, insert the disk again and press [EXECUTE].
Disk Err	The disk is probably damaged and cannot be used.
No Files	The disk contains no files of the selected type. Insert another disk.

## Disk Copy (copying an entire disk)

This function allows you to make backup copies of important disks.

**WARNING:** The Disk Copy function uses the RAM memory and erases the Recorder song and its Style Disk memory. Before using Disk Copy, save your song to disk if you haven't already done so (see p. 52).

Disk Copy copies all files of the Source disk (see below) to the Destination disk.

- (1) Press [DISK] to select the Disk mode.
- (2) Use the [TEMPO/DATA] dial to select "DISKCOPY".
- (3) In response to the "DISKCOPY" message, press the [EXECUTE] button.

The EM-55 now tells you something you already know but may tend to forget at times:

Improper use of copy infringes  
Copyright!! For personal back-up  
use only! Song and Style Disk  
will be erased.

Copying Songs from commercially available Standard MIDI File disks is OK as long as you keep the copy (as safeguard against possible disk errors). Under no circumstances, however, may you give copies of copyright-protected material to your friends.

Also, the display tells you that the Disk Copy function needs the available RAM memory – i.e. the memory set aside for the Recorder song and for the Style Disk function. Be aware that really activating the Disk Copy function (which you haven't done so far), erases the song in the internal memory. Save it to disk before proceeding.

This message is followed by "Sure?" (do you want to proceed?).

**Note:** You can abort the process at any time by pressing the [DISK] button.

- (4) If you are sure you wish to make a backup copy of a disk, press [EXECUTE] (otherwise, press [DISK]).

The display now asks you to insert the original (or "Source") disk into the drive.

**Note:** Before doing so, you must write-protect it, otherwise the display tells you to do so ("No Prot"). In that case, remove the disk from the drive, set its WRITE tab to the PROTECT position (to open "the little window"), and insert the disk into the drive again.

- (5) Insert the original (Source) disk into the drive.

The display now informs you that the EM-55 is reading the first part of the data to be copied ("Read xx%").

Depending on the number of files on disk, you may encounter this message several times. Note also the indication of the disk type (in our example, the Source disk is a 2HD floppy):



When the first part is loaded, the display switches to the "Destinat" message. It means that you need to insert a blank disk into the disk drive. That disk will contain a copy of the original data. Be sure to use a disk of the same type. If the "Source" disk is a 2DD type ("dd"), use a blank 2DD disk, otherwise use a blank 2HD disk. Failure to use the right disk type will result in the "Incompat" message being displayed.

- (6) Remove the Source disk from the drive and insert the Destination disk.  
If the Destination disk isn't formatted, you are given the opportunity to do so now ("Format?").

Next, the "Writ xx%" message appears to inform you that the first (or entire) data chunk is being copied to disk.

As stated above, the Source message may be displayed again. If so...

- (7) Remove the Destination disk from the drive and proceed with step (5) until the display tells you "Complete".  
The display now returns to the Disk Copy message.

### Possible error messages when using Disk Copy

No Prot	The Source disk is not protected. Remove it from the drive and set the Write Protect tab to the PROTECT position.
NoFormat	The Destination disk is not formatted. Press [EXECUTE] to format it and to continue.
DiskErr	The disk is probably damaged and cannot be used.
DiskProt	The Destination disk is write-protected. Remove it and disable the protection.
Incompat	See above.



## Format

*Before being able to save files to a disk, you need to prepare a floppy disk. This is called "formatting". If the floppy you are about to use is IBM PC formatted, there is no need to format it, though disk access is faster with EM-55 formatted disks. Otherwise proceed as follows:*

- (1) Press [DISK] to select the Disk mode.
- (2) Use the [TEMPO/DATA] dial to select "FORMAT".
- (3) Wait for the "EXE" message to flash, then press [EXECUTE].  
**Note:** If you do not want to format your floppy, press [DISK] to return to the first Disk function ("LOAD Upr").  
**Note:** By formatting a disk, you erase all files it contains. It would be a good idea to first check what it contains (e.g. on your PC).
- (4) Press [EXECUTE] again in response to the "Sure?" message.  
The value to the left of the "Formatng" message now counts down from "80" to "1" while the disk icon flashes to indicate that the disk is being accessed. When the disk is formatted, the message "Complete" is briefly displayed.

## 18. Miscellaneous

### Functions for educational purposes

*The EM-55 provides two functions that may come in handy for music teachers or for those who use the EM-55 in class:*

#### Deactivating or activating the Demo function

The EM-55's Demo function can be switched off so that pressing the [DEMO] button will have no effect at all. This may be useful in situations where the EM-55 is used in class. Here is how to deactivate the Demo function:

- (1) Switch off the EM-55.
- (2) Hold down the [DEMO] button while switching the EM-55 back on again. This setting is remembered, so that next time you want to listen to a demo song, you have to repeat the above procedure.

#### Deactivating the Arranger

Use the following procedure to ensure that the Arranger cannot be started or stopped:

- (1) Switch off the EM-55.
- (2) Hold down the [STYLE] button while you switch the EM-55 back on again.

It will now be impossible to start/stop the Arranger using the [START/STOP] button, or to use the SESSION PARTNER buttons (STYLE PAD & DJ PAD).

Repeat the above procedure when you want to use the Arranger again.

#### Deactivating both the Arranger and the Demo function

A third "educational" option is to switch off both the Demo and the Arranger functions in one go:

- (1) Switch off the EM-55.
- (2) Hold down the [START/STOP] button while you switch the EM-55 back on again.

It will now be impossible to start/stop the Arranger STYLE PAD, DJ PAD, or demo song playback.

Repeat the above procedure when you want to use the Arranger and Demo function again.

### Initializing your EM-55 (Factory)

*After working extensively with your EM-55, you may want to recall the original factory settings. Note that the Recorder song and User Program memories will be empty after initializing your EM-55.*

Here is how to initialize your EM-55:

- (1) Power off your EM-55.
- (2) Hold down the [USER PROGRAM/WRITE] button while turning your EM-55 back on again.

The message "Factory!" will inform you that the EM-55 has been initialized.

## 19. Specifications

### *EM-55 Interactive Keyboard*

**Keyboard:** 61 keys, velocity sensitive

**EZ Search:** Function for quick Tone & Music Style location

**Sound Source:** 64-voice polyphonic  
3,559 Tones, 116 Drum Sets  
32-part multitimbral  
GM2/GS compatible

**Display:** Newly designed large backlit custom display  
Adjustable contrast

### **Panel controls & performance functions**

Alpha dial/Tempo, Pitch Bend/ Modulation, D Beam Controller, Master Volume, Balance, Session Partner/Tracks (Style Pad: 12 sets/8 pads, DJ Pad: 8 sets/8 pads, Accompaniment on/off: 8, Track on/mute: 1~8/9~16)

**Music Styles:** 64 in ROM,  
64 Disk Link (via floppy disk)  
4 x 64 One Touch settings  
Style Orchestrator (3 levels)  
Style Morphing  
Melody Intelligence (18 types)

**User Programs:** 64 internal memories

**Music Assistant:** 100 via Database (ROM)

### **Effects:**

Reverb: 8 types, Chorus : 8 types  
MFX: 47 types

**Metronome:** Time signature, volume

**Education functions (Games):** Chord Finder, Guess Note, Guess Chord

**Recorder:** Realtime SMF Player

16-track recorder  
4 recording modes (All, Keyboard, Single, Punch-In/Out)

**Data storage:** 3,5" floppy disk (2DD/2HD)

File management: Styles, Songs (SMF), User Programs

**Connections:** MIDI (In, Out), Output (L/Mono, R), Footswitch/Expr, Phones (2 connectors)

### **Others:**

Output power: 2 x 7W  
Speakers: 2 x 12cm (Bass Port)  
Power supply: 12V/2A adapter (included)  
Dimensions: 1016 (W) x 398 (D) x 153 (H) mm  
Weight: 9.5kg

**Supplied accessories:** ACJ adapter, Owner's manual, Music data disks, Music Rest

**Options:** PK-5 Dynamic MIDI Pedal  
MSA/MSD/MSE-series Music Style Disks  
RH-25/50 Headphones  
DP-2 Pedal Switch  
DP-6 Pedal Switch  
EV-5 Expression Pedal  
BOSS FV-300L Volume Pedal

**Note:** Specifications subject to change without prior notice.

## 20. Index

### A

Acc Off 35  
 Accomp 31  
 All 37  
 Arabic tuning 46  
 Arpg 35  
 Arr  
   Chord 43  
   Mem 43  
   Split 43  
 Arranger 43, 56  
   Mode 13  
   Split 43  
   Stop 14

### B

Balance 31  
 Bass Off 35  
 BsEtDr Off 35

### C

Chord  
   Finder 11  
   Intelligence 43  
   Memory 43  
   Oct 35  
 Chorus 31  
 Clock Tx 50  
 Contrast 7  
 Controls 35  
 Copy 54  
 Count-In 46  
 Cutting 34

### D

D Beam 34  
   Using 19  
 Delete 53  
 Demo 8, 56  
 Destinac 54  
 Disk  
   Copy 54  
   Functions 52  
   Link 15  
 DJ  
   Gear 34  
   Pad 9  
 Drum  
   Off 35  
   Sets 18  
 Drums 18

### E

Education 56  
 Effects 29  
 Ending 13  
 EP Chord 43  
 EXPR 34  
 Expression 34  
 EZ Search 15, 16

### F

Factory 56  
 Fade Out 35  
 Fill 13  
   D Beam function 35  
 Filter 35  
 Footswitch 34, 39, 45  
 Front panel 5  
 Functions 5

### G

Groovebox 9  
 Guess  
   Note 11  
   Style 11

### H

Hold 34

### I

Initialize 56  
 Instruments 35  
 Intro 13  
 Inversion 46

### K

Kbd Velo 33, 42  
 Keyboard 31  
   Recorder (mode) 37  
   Velocity 33

### L

LCD Contrast 7  
 Load 52  
 Local 50  
 Loop 40  
 Lower 17  
 LWR  
   Int 44  
   Mem 44  
   Octv 43  
 Lyrics Tx 50

### M

M.Drums 18  
 ManBass 43  
 Marker A/B 40  
 MDr Shift 43  
 Metro  
   TS 17, 42  
   Vol 43  
 Metronome 17  
 M-FX 29  
 MIDI 49  
   Sync 49  
   TxRx 49  
 Minus One 40  
 Modulation 33  
   Filter 50  
 Mstr Tune 42  
 Music Style 14  
 Musical Games 10

### N

Note to Arranger 50  
 NTA Rx14 50

### O

Octave 35, 43  
 Original 13

### P

Pad  
   DJ 9  
   Sync 46  
 Pan 45  
 PBend 35  
 PBRange 43  
 Phrases 9  
 Piano 17  
 Pitch Bend 33  
   Filter 50  
   Range 43  
 ProgChng 50  
 Punch I/O 38

### Q

Quarter tones 46

### R

Range 43  
 Rear panel 7  
 Recorder 20, 36  
 Repeat 40  
 Resume 46  
 Reverb 30  
 Root 11  
 Rotary Slow/Fast 46

### S

Save 52  
 Scale 46  
 Scl Mode 46  
 Scratch 34  
 Sel Mode 46  
 Single 38  
 SMF 41  
 Soft 46  
 Song Pos P. 50  
 Sostenuato 46  
 Sound EFX 34  
 Source 54  
 Specifications 57  
 Split  
   Arranger 43  
   Lower 17  
 Standard MIDI File 41  
 Start 35  
 StartStp 50  
 Style 14  
   Demo 9  
   Pad 43  
   Pad Set 46  
   PC 50  
 Sustain 34

### Sync

Rx 49  
 Start 14

### T

Tempo 14  
   Up/Down 35  
 Tone 15  
   Demo 8  
   Left 17  
   MFX 45  
 Tracks 37  
 Transpose 32  
   Value 42  
 Trp  
   Mode 42  
   Value 32, 42  
 TT Motor 34  
 Tune 42  
 Type 11

### U

UP1/2 Octv 43  
 User Program 47  
   Footswitch 46

### V

Variation 13  
 Velo RX 50  
 Velocity 33, 42  
   Filter 50  
 Vinyl RPM 34  
 Volume 8, 43

# 21. Tone List

Tones that can be selected via the BANK/NUMBER/VARIATION buttons

GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name
A11	1	1	0	4	Piano 1	A21	1	9	0	4	Celesta	A32	6	18	6	4	JazzOrg5	A43	2	27	0	4	Jazz Gt
	2	1	2	4	Upright		2	9	1	4	PopCele		7	18	7	4	JazzOrg6		3	27	8	4	PedalStl
	3	1	8	4	MildPno		3	9	47	4	CelBell		8	18	8	4	DetunOr2		4	27	48	4	vJazzGt
	4	1	9	4	UprightW		4	9	126	4	Cho EPno		9	18	9	4	OctaveOr		5	27	50	4	vPedalSt
	5	1	16	4	MildPnoW		4	9	127	4	ElecOrg1		10	18	32	4	Organ 5		6	27	126	4	Picked
	6	1	24	4	European								11	18	33	4	PercOrg2		7	27	127	4	SynBras3
	7	1	25	4	Pno+Str1	A22	1	10	0	4	Glockens		12	18	34	4	PercOrg3	A44	1	28	0	4	Clean Gt
	8	1	26	4	Pno+Str2		2	10	126	4	EPiano2		13	18	35	4	PercOrg4		2	28	1	4	CleanHal
	9	1	27	4	Pno+Cho1		2	10	127	4	ElecOrg2		14	18	126	4	SlapBas1		3	28	2	4	OpenHar1
	10	1	45	4	Pno+Cho2	A23	1	11	0	4	MiscBox	A33	1	19	0	4	Organ 3		4	28	3	4	OpenHar2
	11	1	46	4	AcPiano2		1	11	1	4	MiscBox2		2	19	16	4	Rotary 5		5	28	4	4	JC Clean
	12	1	47	4	BritePno		2	11	8	4	StMscBox		3	19	17	4	RockOrg1		6	28	5	4	AtkClean
	13	1	126	4	AcPiano1		3	11	126	4	SteelStr		4	19	18	4	RockOrg2		7	28	9	4	ChorusGt
	14	1	127	4	Piano 2		4	11	127	4	ElecOrg3		5	19	24	4	Rotary F		8	28	16	4	JCChorus
					Acou P1							6	19	47	4	L-Organ		9	28	17	4	TCFront	
A12	1	2	0	4	Piano 2	A24	1	12	0	4	Vibraph		7	19	126	4	SlapBas1		10	28	18	4	TCRear
	2	2	1	4	PopPno		2	12	8	4	PopVibe		8	19	127	4	Harpsi 3		11	28	19	4	TCClean
	3	2	8	4	RockPno		3	12	9	4	VibW							12	28	20	4	TCClean2	
	4	2	9	4	PopPno W		4	12	126	4	Vibraps							13	28	21	4	LPRear	
	5	2	16	4	RockPnoW		5	12	127	4	SteelStr	A34	1	20	0	4	Church 1		14	28	22	4	LPRear2
	6	2	16	4	Dance P							2	20	16	4	Church 2		15	28	23	4	LPRear3	
	7	2	127	4	Acou P2	A25	1	13	0	4	Marimba		3	20	24	4	Church 3		16	28	24	4	Mid Tone
A13	1	3	0	4	Piano 3		2	13	16	4	MarimbaW		4	20	32	4	OrgFlute		17	28	48	4	vCleanGt
	2	3	1	4	EG+Rhod1		3	13	17	4	Barafon		5	20	33	4	TremFlut		18	28	49	4	vCleanH
	3	3	2	4	EG+Rhod2		4	13	24	4	Barafon2		6	20	126	4	Theater		19	28	50	4	vHard1
	4	3	8	4	Piano 3w		5	13	126	4	Log drum		7	20	127	4	SlapBas2		20	28	51	4	vHard2
	5	3	47	4	Stacked		6	13	127	4	12Str Gt							21	28	52	4	vJCClean	
	6	3	126	4	Piano 2						A35	1	21	0	4	ReedOrg		22	28	53	4	vAtkClean	
					Acou P3	A26	1	14	0	4	Xyloph		2	21	8	4	WindOrg		23	28	54	4	vChrusGt
A14	1	4	0	4	Honky-T1		2	14	8	4	Xyloph W		3	21	16	4	PuffOrg		24	28	55	4	vJCChrus
	2	4	8	4	Honky-T2		3	14	126	4	FunkGt		4	21	126	4	SlapBas2		25	28	56	4	vTCFront
	3	4	126	4	Honky-T												26	28	57	4	vTCRear		
					ElecPno1	A27	1	15	0	4	PipeOrg2	A36	1	22	0	4	Clavi 1		27	28	58	4	vTCClean
A15	1	5	0	4	EPiano1		2	15	8	4	TubulB		2	22	8	4	Accord F		28	28	59	4	vLPRear
	2	5	8	4	StSoftEP		3	15	9	4	Church8		3	22	16	4	Accord I		29	28	60	4	vLPRear2
	3	5	10	4	Cho EPno		4	15	10	4	Carillon		4	22	24	4	Dist Acc		30	28	61	4	vLPRear3
	4	5	16	4	SilentRh		5	15	16	4	ChurchB2		5	22	25	4	Cho Acc		31	28	126	4	Fretless
	5	5	17	4	FM+SA EP		6	15	126	4	TubulB W		6	22	47	4	Hard Acc		32	28	127	4	SynBras4
	6	5	24	4	Dist EP							7	22	126	4	Soft Acc	A45	1	29	0	4	MutedGt	
	7	5	25	4	Wurly	A28	1	16	0	4	MutedGt		8	22	127	4	ITMusett		2	29	2	4	TCMuted
	8	5	26	4	HardRhod		2	16	2	4	PipeOrg3							3	29	8	4	Funk Gt	
	9	5	44	4	MellowRh		3	16	8	4	Santur	A37	1	23	0	4	Harmonc		4	29	16	4	Funk Gt2
	10	5	45	4	PhaseRh		4	16	2	4	Santur 2		2	23	1	4	Harmonc2		5	29	24	4	Jazz Man
	11	5	46	4	SA EP		5	16	8	4	Santur 3		3	23	8	4	BHarpBsc		6	29	48	4	vMutedGt
	12	5	47	4	TremDyno		6	16	16	4	Cimbalom		4	23	9	4	BHarpSpl		7	29	49	4	vMuteDis
	13	5	126	4	Dynorh		7	16	17	4	Zither 1		5	23	126	4	Zither 2		8	29	50	4	vTCMuted
	14	5	127	4	Piano 1		8	16	24	4	Zither 2		6	23	126	4	SlapBas2		9	29	51	4	vFunkPop
					ElecPno2							7	23	127	4	SlapBas2		10	29	52	4	vFunkGt2	
A16	1	6	0	4	EPiano2	A29	1	17	0	4	SlapBas	A38	1	24	0	4	Clavi 3		11	29	126	4	Ac Bass
	2	6	8	4	EPiano3		2	17	25	4	Accord		2	24	8	4	Bandeon		12	29	127	4	SynBass1
	3	6	9	4	DetunEP2		3	17	2	4	Organ 1		3	24	16	4	Bandeon2	A46	1	30	0	4	Overdr
	4	6	10	4	DetunEP3		4	17	2	4	Organ101		4	24	126	4	Bandeon3		2	30	2	4	Overdr2
	5	6	16	4	EPLegend		5	17	3	4	FulOrg1							3	30	3	4	Overdr3	
	6	6	24	4	St FM EP		6	17	4	4	FulOrg2	A41	1	25	0	4	NylonStr		4	30	4	4	MoreDriv
	7	6	32	4	Hard FM		7	17	4	4	FulOrg3		2	25	8	4	Ukulele		5	30	5	4	GT Pinch
	8	6	47	4	EP Phase		8	17	6	4	FulOrg4		3	25	16	4	NylonGtO		6	30	8	4	AtkDrive
A17	1	7	0	4	Harpsi		9	17	7	4	FulOrg5		4	25	24	4	NylonGtO		7	30	9	4	LPOverDr
	2	7	1	4	Harpsi 2		10	17	8	4	FulOrg6		5	25	32	4	VeloHrmx		8	30	10	4	LPOverD
	3	7	2	4	Harpsi 3		11	17	10	4	DetOrg1		6	25	40	4	NylonGt2		9	30	11	4	LPDrive
	4	7	8	4	Coupled		12	17	11	4	Organ 0		7	25	48	4	Requit		10	30	12	4	LPDrive2
	5	7	16	4	HarpsiW		13	17	12	4	FulOrg7		8	25	49	4	vFl Gtr1		11	30	48	4	LPChorus
	6	7	24	4	HarpsiO		14	17	12	4	FulOrg8		9	25	50	4	vFl Gtr2		12	30	49	4	vOverdr
	7	7	32	4	SynHarps		15	17	16	4	FulOrg9		10	25	51	4	vFl Gtr3		13	30	50	4	vOverdr2
	8	7	126	4	Piano 2		16	17	17	4	60'sOrg1		11	25	52	4	vFl GtrR		14	30	51	4	vOverdr3
					ElecPno4		17	17	18	4	60'sOrg2		12	25	126	4	vRequGt2		15	30	52	4	vMoreDrv
A18	1	8	0	4	Clav		18	17	19	4	60'sOrg1							16	30	53	4	vLPOverd	
	2	8	1	4	Clav2		19	17	25	4	FarfOrg							17	30	54	4	vLPDriv	
	3	8	2	4	AtkClav1		20	17	24	4	CheeseOr							18	30	55	4	vLPChrus	
	4	8	3	4	AtkClav2		21	17	27	4	D-50 Org							19	30	126	4	ChoirAhs	
	5	8	16	4	CompClav		22	17	28	4	HybridOr							20	30	127	4	SynBass2	
	6	8	17	4	ResoClav		23	17	29	4	V5 Organ						A47	1	31	0	4	Dist Gt1	
	7	8	24	4	PhasClav		24	17	30	4	DigiChur							2	31	1	4	Dist Gt2	
	8	8	32	4	Clav O		25	17	31	4	JX-8POrg							3	31	2	4	Dazed GT	
	9	8	33	4	AnlgClav		26	17	32	4	FM Organ							4	31	3	4	Distort	
	10	8	35	4	JPBClav1		27	17	33	4	Organ 4							5	31	4	4	DistFast	
	11	8	36	4	JPBClav2		28	17	40	4	Even Bar							6	31	8	4	Feedbck	
	12	8	37	4	SynRingC		29	17	48														



GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name
A76	38	54	127	4	Violin 2	A85	7	61	24	4	FHornRip	B21	73	0	4	Piccolo	B32	18	82	18	4	CSawLd	
A77	55	0	4	SynVox	A86	1	62	0	4	Brass 1	B22	74	0	4	Flute	B33	83	0	4	SynCall			
1	55	1	4	SynVox 2	2	62	2	4	BnesSect	1	74	1	4	Flute 2	2	83	2	4	PurePanL				
2	55	2	4	SynVox 3	3	62	3	4	StBrassf	2	74	2	4	FluteExp	3	83	8	4	LMPureLd				
3	55	8	4	SynVoic	4	62	4	4	QuaBras1	3	74	3	4	Traverso	4	83	9	4	LMBlowLd				
4	55	9	4	SilNight	5	62	5	4	QuaBras2	4	74	4	4	FluteVln	5	83	127	4	Clarinet1				
5	55	10	4	SynVoic2	6	62	6	4	Brass 2	5	74	5	4	PipeReed	B34	84	0	4	ChifferL				
6	55	16	4	VP330Ch	7	62	7	4	Brass 3	6	74	6	4	TronFlut	2	84	2	4	HybridLd				
7	55	17	4	VinyCho	8	62	8	4	Brass 4	7	74	7	4	IndiFlut	3	84	3	4	UnSqrLd				
8	55	18	4	JX-8PVox	9	62	9	4	Brass 5	8	74	8	4	vFlute	4	84	4	4	FatSoloL				
9	55	19	4	AnalogVo	10	62	10	4	Brass 6	9	74	9	4	vTravers	5	84	5	4	Forceful				
10	55	126	4	Alto Sax	11	62	11	4	FatPopBr	10	74	10	4	vTronFit	6	84	6	4	OctUnison				
11	55	127	4	Cello 1	12	62	12	4	Br Fall	11	74	11	4	Flute 2	7	84	7	4	UnisonSw				
A78	56	0	4	Orch Hit	13	62	13	4	TP Fall	12	74	12	4	Flute 2	8	84	8	4	Crowding				
1	56	1	4	Bass Hit	14	62	14	4	Br Reed	13	74	13	4	Recorder	9	84	9	4	Double5q				
2	56	2	4	6th Hit	15	62	15	4	Fat Reed	14	74	14	4	Piccolo1	10	84	10	4	PureFlat				
3	56	3	4	Euro Hit	16	62	16	4	OrchBrs	15	74	15	4	Recorder	12	84	127	4	Clarinet2				
4	56	8	4	Impact	17	62	17	4	OrchBrs2	B23	75	0	4	Recorder	B35	85	0	4	Charang				
5	56	9	4	Philly	18	62	18	4	StFatPop	1	75	127	4	Piccolo1	1	85	1	4	WireLead				
6	56	10	4	Double	19	62	19	4	StOrchB1	B24	76	0	4	PanFlute	2	85	2	4	FBChrang				
7	56	11	4	PerchHit	20	62	20	4	StOrchB2	1	76	8	4	Kawala	3	85	3	4	FatGRLd				
8	56	12	4	ShockWav	21	62	21	4	StOrchB3	2	76	16	4	Zampona	4	85	4	4	WindGRLd				
9	56	13	4	Bounce	22	62	22	4	2TpsTb	3	76	17	4	Zamp Atk	5	85	5	4	MellGRLd				
10	56	14	4	DrillHit	23	62	23	4	2TpsTb5x	4	76	24	4	TinWhist	6	85	6	4	GR&Pulse				
11	56	15	4	Thrill	24	62	24	4	BigBand	5	76	25	4	TWhstNm	7	85	7	4	DistLead				
12	56	16	4	LoFiRave	25	62	25	4	PowerBrs	6	76	26	4	TWhstOr	8	85	8	4	AcidGtr1				
13	56	17	4	TechnoHit	26	62	26	4	Brass 2	7	76	27	4	TWhstLd	10	85	11	4	DancCst				
14	56	18	4	Dist Hit	27	62	27	4	Brass 2	8	76	28	4	PanFlut2	11	85	12	4	DancCst2				
15	56	19	4	Bam Hit	28	62	28	4	ElecGtr1	9	76	127	4	Piccolo2	12	85	16	4	P5SynclL				
16	56	20	4	Bit Hit	A87	63	0	4	SynBras1	B25	77	0	4	BotBlow	13	85	17	4	FatSynclL				
17	56	21	4	Bim Hit	3	63	3	4	SH-SBras	1	77	46	4	TheBottl	14	85	18	4	RockLead				
18	56	22	4	Technorg	5	63	5	4	JumpBrs	2	77	47	4	BotBlow2	15	85	19	4	5thDecaS				
19	56	23	4	Rave Hit	6	63	6	4	ProBrass	3	77	47	4	Recorder	17	85	21	4	DualIncl				
20	56	24	4	StrngHit	7	63	7	4	P5Brass	4	77	47	4	BotBlow2	19	85	24	4	JUNOSubO				
21	56	25	4	StackHit	8	63	8	4	OrSynBrs	5	81	5	4	Shmoog	20	85	25	4	2600SubO				
22	56	26	4	Industry	9	63	9	4	HybridBr	6	81	6	4	LMSquare	21	85	26	4	JPFdOsc				
23	56	27	4	Clap Hit	10	63	10	4	Brass 1	7	81	7	4	JPB000TW	22	85	127	4	Oboe				
24	56	126	4	TenorSax	11	63	11	4	BPFBrass	8	81	8	4	2600Sine	B36	86	0	4	SoloVox				
25	56	127	4	Cello 2	13	63	13	4	Brass 1	9	81	9	4	SineLead	1	86	1	4	SoloVox2				
A81	57	0	4	Trumpet	14	63	14	4	ElecGtr2	10	81	10	4	KGLead	2	86	2	4	VoxLead				
1	57	1	4	Trumpet2	A88	64	0	4	SynBras2	11	81	11	4	TwinSine	3	86	3	4	LFO Vox				
2	57	2	4	Trumpet:	3	64	3	4	SynBras3	12	81	12	4	P5Square	4	86	4	4	VoxLead2				
3	57	3	4	Dark Tp	6	64	6	4	DeepSynB	13	81	13	4	OB5Square	5	86	127	4	EnglHorn				
4	57	4	4	Tp&Nz	10	64	10	4	DisSqrB	14	81	14	4	JPSquare	B37	87	0	4	5thSawW				
5	57	8	4	FlgHorn	11	64	11	4	JPB000Sw	16	81	16	4	DisSqua	1	87	1	4	BigFives				
6	57	16	4	4th Tps	13	64	13	4	Transbrs	17	81	17	4	303Squa1	2	87	2	4	5th Lead				
7	57	24	4	BrightTp	15	64	15	4	Henry IV	18	81	18	4	303Squa2	3	87	3	4	5th Pulse				
8	57	25	4	WarmTp	16	64	16	4	OrchHit	19	81	19	4	2Sqr&Saw	4	87	4	4	JP5thSaw				
9	57	26	4	WarmTp2	17	64	17	4	Sitar	21	81	21	4	JPBPls1	5	87	5	4	JPB000St				
10	57	27	4	Twin Tp	B11	65	0	4	SoprSax	22	81	22	4	JPBPls2	6	87	6	4	4th Lead				
11	57	28	4	v Trump	1	65	8	4	SoprExp	23	81	23	4	MGResPls	7	87	7	4	Bassoon				
12	57	29	4	vRomtCtp	2	65	127	4	AcouBas1	24	81	24	4	JPBPls3	8	87	127	4					
13	57	30	4	vMariach	B12	66	0	4	Alto Sax	25	81	25	4	260Ring	B38	88	0	4	BassLead				
14	57	31	4	vRomtMar	1	66	8	4	AltoExp	26	81	26	4	303Dist	1	88	1	4	Big&Raw				
15	57	32	4	vMarShk	2	66	9	4	Grow Sax	27	81	27	4	JPB000 D	2	88	2	4	FatPerky				
16	57	33	4	vTpShake	3	66	16	4	Alto+Tp	28	81	28	4	HipHopSn	3	88	3	4	JUNORave				
17	57	34	4	v Trump2	4	66	17	4	SaxSect	29	81	29	4	HipHopSq	4	88	4	4	JPB8Ld1				
18	57	35	4	vFlgHorn	5	66	16	4	AltoSoft	30	81	30	4	HipHopPl	5	88	5	4	JPB8Ld2				
19	57	36	4	v4thTpts	6	66	17	4	AltoSax2	31	81	31	4	FluxPuls	6	88	6	4	SH-5BdL				
20	57	37	4	BaritSax	7	66	17	4	AcouBas2	32	81	127	4	Sax3	7	88	7	4	DelayedL				
21	57	126	4	Contrabs	B13	67	0	4	TenorSax	B32	82	0	4	SawWave	8	88	127	4	Harmonic				
22	57	127	4		1	67	1	4	Tenor:	1	82	1	4	OB2 Saw	B41	89	0	4	Fantasia				
A82	58	0	4	Trombon	2	67	8	4	BreathTn	2	82	2	4	PulseSaw	1	89	1	4	Fantasi2				
1	58	1	4	Trombon2	3	67	9	4	St Tenor	3	82	3	4	Big Lead	2	89	2	4	NewAge				
2	58	2	4	TwinBnes	4	67	44	4	Latin Tn	4	82	5	4	VeloLead	3	89	3	4	BellHeavn				
3	58	3	4	BnesTuba	5	67	45	4	Tenor F	5	82	6	4	GR-300	4	89	4	4	Fantasi3				
4	58	8	4	BrightTb	6	67	46	4	Blown Tn	6	82	7	4	LA Saw	5	89	5	4	Fantasi4				
5	58	8	4	BsTromb	7	67	47	4	Super Tn	7	82	8	4	DocSolo	6	89	6	4	After D!				
6	58	16	4	Euphnum	8	67	127	4	ElecBas1	8	82	8	4	JPB000 5	7	89	7	4	260Harm				
7	58	48	4	v Tromb	B14	68	0	4	Baritone	9	82	9	4	DS0FatSaw	8	89	8	4	EPHeaven				
8	58	49	4	v Tromb2	1	68	1	4	Bari Sax	10	82	10	4	OBDbiSaw	9	89	9	4	HeavnKey				
9	58	50	4	vTwbones	2	68	8	4	Bari&Tn	11	82	11	4	JPDBiSaw	10	89	10	4	BriteSaw				
10	58	51	4	v Bs Tbn	3	68	127	4	ElecBas2	12	82	12	4	FatSawL2	11	89	11	4	SugarKey				
11	58	52	4	v Euph	B15	69	0	4	Oboe	13	82	13	4	JPDBiSaw	12	89	127	4	Trumpet1				
12	58	126	4	Alto Sax	1	69	8	4	Oboe Exp	14	82	14	4	FatSawL2									
13	58	127	4	Harp 1	2	69	16	4	MitiReed	15	82	15	4	JPDBiSaw									
A83	59	0	4	Tuba	3	69	127	4	SlapBas1	16	82	16	4	WaspSyn									
1	59	1	4	Tuba 2	B16	70	0	4	EnglHorn														
2	59	8	4	TubaHorn	1	70	127	4	SlapBas2														
3	59	47	4	Tuba 3	B17	71	0	4	Bassoon														
4	59	126	4	Brass 1	1	71	127	4	Fretles1														
5	59	127	4	Harp 2	B18	72	0	4	Clarinet														
A84	60	0	4	Mute Tp	1	72	8	4	BsClarinet														
1	60	1	4	CupMuteT	2	72	16	4	MitiWind														
2	60	2	4	MutedTp2</																			

Tone List

GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name
B42	1	90	0	4	Warm Pad	B48	14	96	47	4	SawSweep	B56	27	102	27	4	DancDril	B71	1	113	0	4	TinkBell
	2	90	1	4	ThickMtx		15	96	127	4	BrSsect1		28	102	28	4	DirStck		2	113	9	4	Bonang
	3	90	2	4	Horn Pad	B51		97	0	4	Ice Rain		29	102	29	4	Big Blue		3	113	10	4	Gender
	4	90	3	4	RotarStr		1	97	1	4	HarmRain		30	102	30	4	StatcHit		4	113	11	4	GmlanGng
	5	90	4	4	OBSfPad		2	97	2	4	AfrcWood		31	102	31	4	AtlModFX		5	113	12	4	StGmelan
	6	90	5	4	Sine Pad		3	97	3	4	AnklungP		32	102	32	4	AcidCopt		6	113	13	4	Jang Gu
	7	90	6	4	OBSfPad2		4	97	4	4	RattlePd		33	102	127	4	Glock		7	113	14	4	Jegogan
	8	90	7	4	OctavPad		5	97	5	4	Simpulse	B57		103	0	4	EchoDrop		8	113	15	4	Jublag
	9	90	8	4	StackPad		6	97	6	4	StrangeS		1	103	1	4	EchoBell		9	113	16	4	Pernade
	10	90	9	4	HumanPad		7	97	7	4	FstfWDPd		2	103	2	4	EchoPan		10	113	17	4	RamaCymb
	11	90	10	4	SyncBrsP		8	97	8	4	ClaviPad		3	103	3	4	EchoPan2		11	113	18	4	Kajar
	12	90	11	4	OctPWM		9	97	9	4	EP Pad		4	103	4	4	BigPnner		12	113	19	4	Kelontk
	13	90	12	4	JPSfPad		10	97	10	4	TambraPd		5	103	5	4	ResPnner		13	113	20	4	KelontkM
	14	90	13	4	PWMSfPad		11	97	11	4	CP Pad		6	103	6	4	WaterPno		14	113	21	4	KelontkS
	15	90	14	4	LFOsweep		12	97	127	4	BrSsect2		7	103	7	4	EchoSyBs		15	113	22	4	KopyakOp
	16	90	15	4	Stacked	B52		98	0	4	Soundtrk		8	103	8	4	PanSeque		16	113	23	4	KopyakMT
	17	90	16	4	SawStrng		1	98	1	4	Ancestrl		9	103	9	4	Aqua		17	113	24	4	CengCeng
	18	90	17	4	WarmPst		2	98	2	4	Prolog		10	103	10	4	PnningLd		18	113	25	4	Reyoung
					Trumpet2		3	98	3	4	Prolog 2		11	103	11	4	PnningBr		19	113	32	4	Kempur
B43	1	91	0	4	PolySyn		4	98	4	4	HolsStrg	B58		104	0	4	StarThm		20	113	40	4	JnglCrsh
	2	91	1	4	80PolySy		5	98	5	4	HistoryW		1	104	1	4	StarThm2		21	113	41	4	CrshMenu
	3	91	2	4	PolySyn2		6	98	6	4	Rave		2	104	2	4	StarMind		22	113	42	4	RidCymM
	4	91	3	4	PolyKing		7	98	127	4	Vibe 1		3	104	3	4	StarDust		23	113	47	4	RidBellM
	5	91	4	4	SuperPly	B53		99	0	4	Crystal		4	104	4	4	RepTrnce	B72		114	0	4	CymbRol
	6	91	5	4	PowStack		1	99	1	4	SMallet		5	104	5	4	Etherly		1	114	8	4	Timpani
	7	91	6	4	OctStack		2	99	2	4	SCrystal		6	104	6	4	MysticPd		2	114	16	4	Agogo
	8	91	7	4	ResStack		3	99	3	4	RoundGlk		7	104	7	4	DreamPd		3	114	127	4	Atarigan
	9	91	8	4	TecStack		4	99	4	4	LoudGlk		8	104	8	4	SilkyPad		4	114	16	4	Tambourn
	10	91	9	4	PulStack		5	99	5	4	GlkChime		9	104	9	4	DreamPd2		5	114	20	4	MelodTom
	11	91	10	4	TwinOctR		6	99	6	4	ClearBel		10	104	10	4	SilkyPd2	B73		115	0	4	SteelDrm
	12	91	11	4	Oct.Rave		7	99	7	4	XmasBell		11	104	11	4	Ncentury		1	115	1	4	IslandMl
	13	91	12	4	HappySyn		8	99	8	4	VbraBell		12	104	12	4	7thAtmos		2	115	127	4	DeepSnr
	14	91	13	4	FFMSweep		9	99	9	4	DigBells		13	104	13	4	GalaxWay	B74		116	0	4	Woodblck
	15	91	14	4	FFMSweep		10	99	10	4	MiscBell		14	104	14	4	RisngOSC		1	116	8	4	Castants
	16	91	15	4	REVSweep		11	99	11	4	AnlgBell		15	104	127	4	Xylophon		2	116	16	4	Angklung
	17	91	16	4	MinorRav		12	99	12	4	BlowBell	B61		105	0	4	Sitar		3	116	17	4	AngkRthm
	18	91	17	4	UnsonSaw		13	99	13	4	HyperBel		1	105	1	4	Sitar 2		4	116	24	4	FngsSnap
					SuperSaw		14	99	14	4	ChorBell		2	105	2	4	DetSitar		5	116	32	4	909HClap
					Trombne1		15	99	15	4	AirBells		3	105	3	4	Sitar 3		6	116	40	4	HndClapM
							16	99	16	4	BellHarp		4	105	4	4	Sitar Drn		7	116	127	4	ElcPerc1
B44	1	92	0	4	SpaceVce		17	99	17	4	Gmelimba		5	105	5	4	Sitar 4	B75		117	0	4	Taiko
	2	92	1	4	Heavenil		18	99	18	4	JUNOBell		6	105	6	4	Tambra		1	117	1	4	SmlTaiko
	3	92	2	4	SHeaven		19	99	19	4	JP Bell		7	105	7	4	Tamboura		2	117	8	4	ConcrtBd
	4	92	3	4	WaterSpc		20	99	20	4	PizzBell		8	105	127	4	Marimba		3	117	9	4	ConcBdMt
	5	92	4	4	ColdSpc		21	99	21	4	Bot Bell		8	105	127	4	Marimba		4	117	16	4	JungleBD
	6	92	5	4	NoisePk	B54		100	0	4	Atmosph		1	106	1	4	Banjo		5	117	17	4	TechnoBD
	7	92	6	4	BmbooHit		1	100	1	4	WarmAtm		2	106	2	4	MutBanjo		6	117	18	4	Bounce
	8	92	7	4	CosmcVce		2	100	2	4	NylnHarp		3	106	3	4	Rabab		7	117	24	4	KendingWd
	9	92	8	4	Auh Vcx		3	100	3	4	Harpvox		4	106	4	4	San Xian		8	117	25	4	Bebarngn
	10	92	9	4	AuhAuh		4	100	4	4	HlReleas		5	106	5	4	Gopichnt		9	117	26	4	Pelegong
	11	92	10	4	Vocrdman		5	100	5	4	NylnRhod		6	106	6	4	Oud		10	117	27	4	Dholak 1
	12	92	11	4	HolyVoic		6	100	6	4	AmbntPad		7	106	7	4	Oud+Strg		11	117	28	4	Dholak 2
	13	92	12	4	JPBHntng		7	100	7	4	Invisibl		8	106	127	4	Koto		12	117	32	4	JnglRoi
	14	92	13	4	JPBHollo		8	100	8	4	PulseKey	B62		106	0	4	Banjoo		13	117	40	4	KickMnu1
	15	92	14	4	SquarePd		9	100	9	4	NoisePno		1	106	1	4	MutBanjo		14	117	41	4	KickMnu2
	16	92	15	4	Pipe Pad		10	100	10	4	HeavenAt		2	106	2	4	Rabab		15	117	42	4	KickMnu3
	17	92	16	4	WarmSqrP		11	100	11	4	TambraAt		3	106	3	4	San Xian		16	117	43	4	KickMnu4
	18	92	17	4	Trombne2		12	100	127	4	SyMallet		4	106	127	4	Sho		17	117	127	4	ElcPerc2
						B55		101	0	4	Bghtness	B63		107	0	4	Shamisen	B76		118	0	4	MeloTom1
B45	1	93	0	4	BowedGls		1	101	1	4	ShinStar		1	107	1	4	Tsugaru		1	118	1	4	RealTom
	2	93	1	4	SoftBell		2	101	2	4	OB Stab		2	107	2	4	SynShams		2	118	2	4	RealTom2
	3	93	2	4	JPBSqrPd		3	101	3	4	BrasStar		3	107	3	4	Sho		3	118	3	4	Jazz Tom
	4	93	3	4	7thBelPd		4	101	4	4	ChoirStb		4	107	4	4	Kanoon		4	118	4	4	BrushTom
	5	93	4	4	SteelGls		5	101	5	4	D50Rtour		5	107	5	4	KanoonCh		5	118	8	4	MeloTom2
	6	93	5	4	BottleSk		6	101	6	4	SouthWnd		6	107	6	4	Oct Harp		6	118	9	4	Rock Tom
	7	93	6	4	Gr Pad		7	101	7	4	SymbBell		7	107	7	4	Shakuhac		7	118	16	4	Rash SD



GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name
878	11	120	27	4	RevTom 4	885		125	0	4	Teleph 1
	12	120	40	4	RevSDMn1		1	125	1	4	Teleph 2
	13	120	41	4	RevSDMn2		2	125	2	4	DoorCrkg
	14	120	42	4	RevSDMn3		3	125	3	4	Door
	15	120	43	4	RevBDMn1		4	125	4	4	Scratch
	16	120	44	4	RevBDMn2		5	125	5	4	WindChim
	17	120	45	4	RevBDMn3		6	125	7	4	Scratch2
	18	120	46	4	RevClpMn		7	125	8	4	ScratchK
	19	120	127	4	Cymbal		8	125	9	4	TapeRew
							9	125	10	4	Phono Nz
881		121	0	4	GFretNz		10	125	11	4	MCS00Bep
	1	121	1	4	GCutNz		11	125	12	4	Scratch3
	2	121	2	4	StrgSlap		12	125	13	4	Scratch4
	3	121	3	4	GCutNz2		13	125	14	4	Scratch5
	4	121	4	4	DistCutN		14	125	15	4	Scratch6
	5	121	5	4	BassSlid		15	125	16	4	Scratch7
	6	121	6	4	PckScrap	16	125	127	4	BirdTwtet	
	7	121	8	4	GfFXMenu						
	8	121	9	4	BartkPlz	886		126	0	4	Helicptr
	9	121	10	4	Gtr Slap		1	126	1	4	CarEngin
	10	121	11	4	ChrdsStrk		2	126	2	4	CarStop
	11	121	12	4	BiwaStrk		3	126	3	4	CarPass
	12	121	13	4	BiwaTrem		4	126	4	4	CarCrash
	13	121	16	4	ABsNzMen		5	126	5	4	Siren
	14	121	17	4	DGNzMen		6	126	6	4	Train
	15	121	18	4	EGiNzMn1		7	126	7	4	Jetplane
	16	121	19	4	EGiNzMn2		8	126	8	4	Starship
	17	121	20	4	GStrkMen		9	126	9	4	Burst Nz
	18	121	21	4	GSlideMn		10	126	10	4	Calculat
	19	121	22	4	ABsMutNz		11	126	11	4	PercBang
	20	121	23	4	ABsTchNz		12	126	12	4	Burner
	21	121	24	4	ABsAtkNz		13	126	13	4	GlassGim
	22	121	25	4	TC Up Nz		14	126	14	4	Ice Ring
	23	121	26	4	TCDownMNz		15	126	15	4	OverBlow
	24	121	27	4	TCUpMNz		16	126	16	4	CrckBttl
	25	121	28	4	TCDownNz		17	126	17	4	PourBttl
	26	121	29	4	DsGUpNz		18	126	18	4	Soda
	27	121	30	4	DsGDwnNz1		19	126	19	4	OpCDTray
	28	121	31	4	DsGDwnNz2		20	126	20	4	AudioSwt
	29	121	32	4	DsGMutNz		21	126	21	4	KeyTypng
	30	121	34	4	GStrkNz5		22	126	22	4	SL 1
	31	121	35	4	SGSlidNz1		23	126	23	4	SL 2
	32	121	36	4	SGSlidNz2		24	126	24	4	CarEngn2
33	121	37	4	SGSlidNz3	25		126	25	4	Car Horn	
34	121	38	4	SGSlidNz4	26		126	26	4	Boeeeen	
35	121	39	4	GStrkNz1	27		126	27	4	RCrossng	
36	121	40	4	GStrkNz2	28		126	28	4	Compress	
37	121	41	4	GStrkNz3	29		126	29	4	Swrdboom	
38	121	42	4	GStrkNz4	30		126	30	4	SwordX	
39	121	44	4	EGiNzMen	31		126	31	4	Stab! 1	
40	121	45	4	AGiNzMen	32		126	32	4	Stab! 2	
41	121	46	4	BasNzMen	33	126	127	4	1NoteJam		
42	121	47	4	BassSlid							
43	121	127	4	Castanet	887		127	0	4	Applause	
882		122	0	4		BreathNz	1	127	1	4	Laughing
	1	122	1	4		FKeyClk	2	127	2	4	Screamng
	2	122	2	4		BrthNzMn	3	127	3	4	Punch
	3	122	3	4		FBreath1	4	127	4	4	HeartBt
	4	122	4	4		FBreath2	5	127	5	4	FootStps
	5	122	5	4		FBreath3	6	127	6	4	Applaus2
	6	122	6	4		VBreath1	7	127	7	4	SmallCib
	7	122	7	4		VBreath2	8	127	8	4	ApplWave
	8	122	8	4		Tromb Nz	9	127	9	4	BbyLaugh
	9	122	9	4		Trump Nz	10	127	16	4	VoiceOne
	10	122	47	4	BrthNzMn	11	127	17	4	VoiceTwo	
11	122	127	4	Triangle	12	127	18	4	VoicThre		
883		123	0	4	Seashore	13	127	19	4	VoiceTah	
	1	123	1	4	Rain	14	127	20	4	VoicWhey	
	2	123	2	4	Thunder	15	127	22	4	VoicKitt	
	3	123	3	4	Wind	16	127	23	4	VcComeOn	
	4	123	4	4	Stream	17	127	24	4	VoiceAou	
	5	123	5	4	Bubble	18	127	25	4	VoiceOou	
	6	123	6	4	Wind 2	19	127	26	4	VoiceHie	
	7	123	7	4	Cricket	20	127	127	4	WterBell	
	8	123	16	4	Pink Nz	888		128	0	4	Gun Shot
	9	123	17	4	White Nz		1	128	1	4	MchinGun
	10	123	47	4	WindsHit		2	128	2	4	Lasergun
11	123	127	4	OrcheHit	3		128	3	4	Explos	
884		124	0	4	Bird		4	128	4	4	Eruption
	1	124	1	4	Dog		5	128	5	4	Big Shot
	2	124	2	4	HorseGlp		6	128	6	4	Explos 2
	3	124	3	4	Bird 2	7	128	127	4	JungleTn	
	4	124	4	4	Kilty						
	5	124	5	4	Growl						
	6	124	6	4	Growl 2						
	7	124	7	4	FancyAn						
8	124	8	4	Seal							
9	124	127	4	Teleph 1							





Tone List

GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name		
D53	1	99	0	3	Crystal	D64	1	108	0	3	Koto	D82	1	122	0	3	BreathNz	E11	1	0	2	2	Piano 1		
	2	99	1	3	SMallet		2	108	8	3	Gu Zheng		2	122	127	3	FIKeyClk		1	1	8	2	2	UprightW	
	3	99	2	3	SCrystal		3	108	16	3	TaishKot		3	122	127	3	Triangle		2	1	16	2	2	European	
	4	99	3	3	RoundGik		4	108	19	3	KanoonCh		4	1	127	2	Castanet		3	1	126	2	2	Piano 2	
	5	99	4	3	LoudGik		5	108	24	3	Oct Harp		5	2	0	2			4	1	127	2	2	Acou P1	
	6	99	5	3	GikChime		6	108	27	3	Shakuhac		6	1	122	1	3			1	2	8	2	2	Piano 2
	7	99	6	3	ClearBel	D65	1	109	0	3	Kalimba		7	2	122	127	3			2	2	126	2	2	PopPno W
	8	99	7	3	XmasBell		2	109	127	3	Whistle1		8	3	2	127	2			3	2	127	2	2	Acou P2
	9	99	8	3	VbraBell		3	109	8	3	Kalimba		9	1	123	1	3			1	3	0	2	2	Piano 3
	10	99	9	3	DigBells		4	110	0	3	Bagpipe		10	2	123	2	3			2	3	2	2	2	EG+Rhod1
	11	99	10	3	MiscBell		5	110	8	3	Didgerid		11	3	123	4	3			3	3	8	2	2	EG+Rhod2
	12	99	11	3	AnigBell		6	111	0	3	Whistle2		12	4	123	4	3			4	3	8	2	2	Piano 3w
	13	99	12	3	ChorBell		7	111	8	3	Fiddle		13	5	123	5	3			5	3	126	2	2	Piano 2
	14	99	13	3	AirBells		8	111	9	3	Er Hu		14	6	123	6	3			6	3	127	2	2	Acou P3
	15	99	14	3	BellHarp		9	111	127	3	Gao Hu		15	7	123	16	3			7	4	0	2	2	Honky-T1
	16	99	15	3	Gmelimba		10	112	0	3	BottleBl		16	8	123	17	3			8	4	0	2	2	Honky-T2
	17	99	16	3	JUNOBell		11	112	8	3	Shanai		17	9	123	127	3			9	4	126	2	2	Honky-T
	18	99	17	3	Vibe 2		12	112	127	3	Shanai 2		18	1	124	1	3			10	4	127	2	2	ElecPno1
D54	1	100	0	3	Atmosph	D68	1	112	0	3	Pungi		19	2	124	2	3			11	5	0	2	2	EPiano1
	2	100	1	3	WarmAtm		2	112	8	3	Hichirik		20	3	124	3	3			12	5	8	2	2	StSoftEP
	3	100	2	3	NylnHarp		3	112	16	3	Mizmar		21	4	124	4	3			13	5	9	2	2	SAEPiano
	4	100	3	3	Hargvox		4	112	24	3	Suona 1		22	5	124	5	3			14	5	16	2	2	FM+SA EP
	5	100	4	3	HiReleas		5	112	32	3	Suona 2		23	6	124	127	3			15	5	17	2	2	StikyRho
	6	100	5	3	NylnRhod		6	112	40	3	BreathPi		24	7	124	127	3			16	5	24	2	2	Wurly
	7	100	6	3	AmbntPad		7	113	0	3	TinkBell		25	8	125	0	3			17	5	25	2	2	HardRhod
	8	100	7	3	Invisibi		8	113	8	3	Bonang		26	9	125	1	3			18	5	26	2	2	Mellowrth
	9	100	8	3	PulseKey		9	113	16	3	Gender		27	10	125	2	3			19	5	27	2	2	60's EP2
	10	100	9	3	NoisePno		10	113	24	3	GmlanGng		28	11	125	3	3			20	5	126	2	2	Piano 1
	11	100	10	3	SyMallet		11	113	32	3	StGmlan		29	12	125	4	3			21	5	127	2	2	ElecPno2
D55	1	101	0	3	Bghtness		12	113	40	3	Jang Gu		30	13	125	5	3			22	6	0	2	2	EPiano2
	2	101	1	3	ShinStar		13	113	8	3	RamaCymb		31	14	125	6	3			23	6	8	2	2	DetunEP2
	3	101	2	3	OB Scab		14	113	16	3	Timpani		32	15	125	7	3			24	6	16	2	2	St FM EP
	4	101	3	3	Org Bell		15	114	0	3	Agogo		33	16	125	8	3			25	6	24	2	2	Hard FM
	5	101	4	3	Windbell		16	114	8	3	Atarigan		34	17	125	9	3			26	6	126	2	2	Piano 2
D56	1	102	0	3	Goblin		17	114	16	3	Tambourn		35	18	125	10	3			27	6	127	2	2	ElecPno3
	2	102	1	3	Goblins		18	114	24	3	MelodTom		36	19	125	11	3			28	6	127	2	2	
	3	102	2	3	50sSciFi		19	115	0	3	SteelDrm		37	20	126	0	3			29	7	0	2	2	Harpsi
	4	102	3	3	Abductn		20	115	8	3	IslandMl		38	21	126	1	3			30	7	8	2	2	Coupled
	5	102	4	3	Auhbient		21	115	16	3	DeepSnar		39	22	126	2	3			31	7	16	2	2	HarpsiW
	6	102	5	3	LFO Pad		22	115	24	3	Woodbick		40	23	126	3	3			32	7	24	2	2	HarpsiO
	7	102	6	3	Rnd Str		23	116	0	3	Castants		41	24	126	4	3			33	7	126	2	2	Piano 2
	8	102	7	3	Rnd Pad		24	116	8	3	Angklung		42	25	126	5	3			34	7	127	2	2	ElecPno4
	9	102	8	3	LowBirds		25	116	16	3	Castants		43	26	126	6	3			35	7	127	2	2	
	10	102	9	3	FallDown		26	116	24	3	AngkRthm		44	27	126	7	3			36	8	126	2	2	Clav
	11	102	10	3	LFO RAVE		27	116	32	3	FingSnap		45	28	126	8	3			37	8	126	2	2	EPiano1
	12	102	11	3	LFOHrrr		28	116	40	3	909HClap		46	29	126	9	3			38	8	127	2	2	Honky-T
	13	102	12	3	LFOChno		29	116	8	3	ElcPerc1		47	30	126	10	3			39	9	0	2	2	Celesta
	14	102	13	3	Alternat		30	116	16	3	ElcPerc2		48	31	126	11	3			40	9	126	2	2	Cho EPno
	15	102	14	3	UFO FX		31	116	24	3	MeloTom1		49	32	126	12	3			41	9	127	2	2	ElecOrg1
	16	102	15	3	GarglMan		32	116	32	3	MeloTom2		50	33	126	13	3			42	9	127	2	2	
	17	102	16	3	Sweep FX		33	116	40	3	Rock Tom		51	34	126	14	3			43	10	126	2	2	Glockens
	18	102	17	3	Glock		34	116	48	3	Rash SD		52	35	126	15	3			44	10	127	2	2	EPiano2
D57	1	103	0	3	EchoDrop		35	116	56	3	House SD		53	36	126	16	3			45	10	127	2	2	ElecOrg2
	2	103	1	3	EchoBell		36	116	64	3	JungleSD2		54	37	126	17	3			46	11	0	2	2	MiscBox
	3	103	2	3	EchoPan		37	117	0	3	909 SD		55	38	126	18	3			47	11	126	2	2	StMiscBox
	4	103	3	3	EchoPan2		38	117	8	3	Taiko		56	39	126	19	3			48	11	127	2	2	ElecOrg3
	5	103	4	3	BigPnner		39	117	16	3	SynthDrm		57	40	126	20	3			49	11	127	2	2	
	6	103	5	3	ResPnner		40	117	24	3	808 Tom		58	41	126	21	3			50	11	127	2	2	
	7	103	6	3	WaterPno		41	117	32	3	ElcPerc		59	42	126	22	3			51	11	127	2	2	
	8	103	7	3	PanSeque		42	117	40	3	ElcPerc		60	43	126	23	3			52	11	127	2	2	
	9	103	8	3	Aqua		43	117	48	3	909 Tom		61	44	126	24	3			53	11	127	2	2	
	10	103	9	3	TubeBell		44	117	56	3	808 Tom		62	45	126	25	3			54	11</				

GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	
E31	8	17	32	2	Organ 4	E47	4	31	9	2	Feedbck2	E68		48	0	2	Timpani	E88		64	0	2	SynBras2	
	9	17	33	2	Even Bar		5	31	16	2	PowerGT		1	48	126	2	Trumpet		4	64	17	2	TransBras	
	10	17	40	2	Org Bass		6	31	17	2	PowerGT2		2	48	127	2	Square		5	64	126	2	OrchHit	
	11	17	48	2	Org Oct1		7	31	18	2	5th Dist								6	64	127	2	Sitar	
	12	17	126	2	SlapBas1		8	31	24	2	RckRhyt2	E71		49	0	2	Strings							
	13	17	127	2	Harpsi 1		9	31	25	2	RckRhyt		1	49	1	2	Bright							
							10	31	126	2	ChoirAhs		2	49	8	2	Orchest	F11		65	0	2	SoprSax	
E32		18	0	2	Organ 2		11	31	127	2	SynBass3		3	49	9	2	Orchest2		1	65	127	2	AcouBas1	
	1	18	1	2	JazzOrg	E48		32	0	2	Harmonix		4	49	10	2	Tremolo							
	2	18	8	2	DetOrg2		1	32	8	2	Feedbck		5	49	11	2	ChoirStr	F12		66	0	2	Alto Sax	
	3	18	32	2	Organ 5		2	32	16	2	ACHarmnx		6	49	16	2	StStrng		1	66	8	2	AltoExp	
	4	18	126	2	SlapBas1		3	32	126	2	ChoirAhs		7	49	24	2	VeloStrg		2	66	9	2	Grow Sax	
	5	18	127	2	Harpsi 2		4	32	127	2	SynBass4		8	49	32	2	StrgsOct		3	66	17	2	FolkASax	
E33		19	0	2	Organ 3	E51		33	0	2	Acoustic		9	49	126	2	Trombone		4	66	18	2	FolkASxV	
	1	19	8	2	Rotary		1	33	126	2	ChoirAhs		10	49	127	2	StrSect1		5	66	127	2	AcouBas2	
	2	19	16	2	Rotary 5		2	33	127	2	Fantasy	E72		50	0	2	SlowStr	F13		67	0	2	TenorSax	
	3	19	24	2	Rotary F								1	50	1	2	SlowStr2		1	67	1	2	Tenor:	
	4	19	126	2	SlapBas1								2	50	8	2	LegatStr		2	67	8	2	BreathTn	
	5	19	127	2	Harpsi 3	E52		34	0	2	JazzBas		3	50	9	2	WarmStrg		3	67	127	2	ElecBas1	
E34		20	0	2	Church 1		1	34	1	2	JazzBas2		4	50	10	2	StSlow							
	1	20	8	2	Church 2		2	34	2	2	JazzBass		5	50	126	2	Trombone	F14		68	0	2	Baritone	
	2	20	9	2	OrganOc2		3	34	126	2	SlowStrg		6	50	127	2	StrSect2		1	68	127	2	ElecBas2	
	3	20	16	2	Church 3		4	34	127	2	HarmoPan	E73		51	0	2	SynStrg1							
	4	20	24	2	OrgFlute								1	51	1	2	OBString	F15		69	0	2	Oboe	
	5	20	32	2	TremFlut	E53		35	0	2	PickBass		2	51	8	2	SynStrg3		1	69	127	2	SlapBas1	
	6	20	126	2	SlapBas2		1	35	8	2	MutedPck		3	51	126	2	Trombone	F16		70	0	2	EnglHorn	
	7	20	127	2	Clavi 1		2	35	126	2	Strings		4	51	127	2	StrSect3		1	70	127	2	SlapBas2	
							3	35	127	2	Chorale	E74		52	0	2	SynStrg2							
E35		21	0	2	ReedOrg	E54		36	0	2	Fretles		1	52	126	2	Trombone	F17		71	0	2	Bassoon	
	1	21	126	2	SlapBas2		1	36	1	2	Fretles2		2	52	127	2	Pizzicat		1	71	127	2	Fretles1	
	2	21	127	2	Clavi 2		2	36	2	2	Fretles3													
							3	36	3	2	Fretles4	E75		53	0	2	ChoirAhs	F18	72	0	2	Clarinet		
E36		22	0	2	Accord F		4	36	4	2	SynFless		1	53	8	2	StChoirA		1	72	8	2	BsClarIn	
	1	22	8	2	Accord 1		5	36	5	2	MrSmooth		2	53	9	2	StCholAhs		2	72	16	2	FolkClar	
	2	22	16	2	DetunAcc		6	36	126	2	SynStrg3		3	53	32	2	ChoAahs		3	72	17	2	FolkClrV	
	3	22	24	2	Accord 1		7	36	127	2	Glasses		4	53	126	2	Trombone		4	72	127	2	Fretles2	
	4	22	25	2	Accord 2	E55		37	0	2	Slap 1		5	53	127	2	Violin 1	F21		73	0	2	Piccolo:	
	5	22	126	2	SlapBas2		1	37	8	2	ResoSlap									1	73	8	2	Nay
	6	22	127	2	Clavi 3		2	37	126	2	SynStrg3	E76		54	0	2	VoiceOhs		2	73	9	2	Nay Oct	
E37		23	0	2	Harmonc		3	37	127	2	Soundtrk		1	54	126	2	Trombone		3	73	127	2	Flute 1	
	1	23	1	2	Harmonc2	E56		38	0	2	SlapBas2		2	54	127	2	Violin 2	F22		74	0	2	Flute	
	2	23	126	2	SlapBas2		1	38	126	2	Organ 1									1	74	127	2	Flute 2
	3	23	127	2	Celesta1		2	38	127	2	Atmosph	E77		55	0	2	SynVox							
E38		24	0	2	Bandeon	E57		39	0	2	SynBass1		1	55	8	2	SynVoic	F23		75	0	2	Recorder	
	1	24	8	2	AJuno106		1	39	1	2	Synth101		2	55	126	2	Alto Sax		1	75	127	2	Piccolo1	
	2	24	16	2	Det Acc2		2	39	8	2	AcidBass	E78		56	0	2	Orch Hit	F24		76	0	2	PanFlute	
	3	24	17	2	ftMusett		3	39	9	2	TB303Bas		1	56	8	2	Impact		1	76	8	2	Kawala	
	4	24	126	2	Fingered		4	39	10	2	TeknoBas		2	56	9	2	Philly		2	76	9	2	Kawala 2	
	5	24	127	2	Celesta2		5	39	16	2	ResoHBs		3	56	10	2	Double		3	76	10	2	KawalaOc	
E41		25	0	2	NylonStr		6	39	126	2	Organ 1		4	56	16	2	LoFIRave		4	76	127	2	Piccolo2	
	1	25	8	2	Ukulele		7	39	127	2	WarmBell		5	56	126	2	TenorSax	F25		77	0	2	BotBlow	
	2	25	16	2	NylonGtO	E58		40	0	2	SynBass2		6	56	127	2	Cello 2		1	77	127	2	Recorder	
	3	25	24	2	VeloHrmx		1	40	1	2	SynB201	E81		57	0	2	Trumpet	F26		78	0	2	Shakuhac	
	4	25	32	2	NylonGt2		2	40	2	2	Modular		1	57	1	2	Trumpet2		1	78	127	2	PanPipes	
	5	25	40	2	Requint		3	40	3	2	Seq Bass		2	57	8	2	FlgHorn							
	6	25	126	2	Fingered		4	40	8	2	BeeffMBs		3	57	17	2	FolkTp	F27		79	0	2	Whistle	
	7	25	127	2	SynBras1		5	40	9	2	XWireBas		4	57	18	2	FolkTpVb		1	79	127	2	Sax 1	
E42		26	0	2	SteelStr		6	40	16	2	RuberB2		5	57	24	2	BrightTp	F28		80	0	2	Ocarina	
	1	26	8	2	12Str Gt		7	40	17	2	SH101Bs1		6	57	25	2	WarmTp		1	80	127	2	Sax 2	
	2	26	9	2	Nylon+St		8	40	18	2	SH101Bs2		7	57	126	2	BaritSax							
	3	26	16	2	Mandolin		9	40	19	2	SmoothBs		8	57	127	2	Contrabs							
	4	26	17	2	Mandolin2		10	40	126	2	Organ 1	E82		58	0	2	Trombon	F31		81	0	2	Square W	
	5	26	18	2	MandTrem		11	40	127	2	FunnyVox		1	58	1	2	Trombon2		1	81	1	2	MGSquare	
	6	26	32	2	SteelGt2								2	58	126	2	Alto Sax		2	81	2	2	Hollow M	
	7	26	126	2	Picked	E61		41	0	2	Violin		3	58	127	2	Harp 1		3	81	3	2	MellowFM	
	8	26	127	2	SynBras2		1	41	8	2	SViolin									4	81	4	2	CC Solo
E43		27	0	2	Jazz Gt		2	41	16	2	FkVioln									5	81	5	2	Shmoog
	1	27	8	2	PedalStl		3	41	17	2														

Tone List

GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name
F24		76	0	2	PanFlute	F51		97	0	2	Ice Rain	F71		113	0	2	TinkBell	F88		128	0	2	Gun Shot
	1	76	8	2	Kawala		1	97	1	2	HarmRain		1	113	8	2	Bonang		1	128	1	2	MchinGun
	2	76	9	2	Kawala 2		2	97	2	2	AfricWood		2	113	9	2	Gender		2	128	2	2	Lasergun
	3	76	10	2	KawalaOc		3	97	8	2	ClaviPad		3	113	10	2	GmlanGng		3	128	3	2	Explos
	4	76	127	2	Piccolo2		4	97	127	2	BrsSect2		4	113	11	2	StGmelan		4	128	127	2	JungleTn
F25		77	0	2	BotBlow	F52		98	0	2	Soundtrk	F72		114	0	2	Agogo	G11		1	0	1	Piano 1
	1	77	127	2	Recorder		1	98	1	2	Ancestrl		1	114	8	2	Atarigan		1	1	8	1	UprightW
F26		78	0	2	Shakuhac		2	98	2	2	Prolog		1	114	8	2	Atarigan		2	1	16	1	European
	1	78	127	2	PanPipes		3	98	8	2	Rave		2	114	127	2	MelodTom		3	1	126	1	Piano 2
F27		79	0	2	Whistle	F53		99	0	2	Crystal	F73		115	0	2	SteelDrm		4	1	127	1	Acou P1
	1	79	127	2	Sax 1		1	99	1	2	SMallet		1	115	127	2	DeepSnar	G12		2	0	1	Piano 2
F28		80	0	2	Ocarina		2	99	2	2	SCrystal	F74		116	0	2	Woodbck		1	2	8	1	PopPno W
	1	80	127	2	Sax 2		3	99	3	2	RoundGlk		1	116	8	2	Castants		2	2	126	1	Piano 2
F31		81	0	2	Square W		4	99	4	2	LoudGlk	F75		117	0	2	Taiko	G13		3	0	1	Piano 3
	1	81	1	2	MGSquare		5	99	5	2	GlkChime		1	117	8	2	ConcrtBd		1	3	8	1	Piano 3w
	2	81	2	2	Hollow M		6	99	6	2	ClearBel		1	117	8	2	ConcrtBd		2	3	126	1	Piano 2
	3	81	3	2	MellowFM		7	99	7	2	XmasBell		2	117	127	2	ElcPerc2		3	3	127	1	Acou P3
	4	81	4	2	CC Solo		8	99	8	2	VbraBell	F76		118	0	2	MeloTom1		4	0	1	Honky-T1	
	5	81	5	2	Shmoog		9	99	9	2	DigBells		1	118	1	2	RealTom		1	4	8	1	Honky-T2
	6	81	6	2	LMSquare		10	99	16	2	ChorBell		2	118	8	2	MeloTom2		2	4	126	1	Honky-T
	7	81	8	2	2600Sine		11	99	17	2	AirBells		3	118	9	2	Rock Tom		3	4	127	1	ElcPno1
	8	81	127	2	Sax3		12	99	18	2	BellHarp		4	118	127	2	Taiko		5	5	127	1	ElcPno2
F32		82	0	2	SawWave	F54		100	0	2	Atmosph	F77		119	0	2	SynthDrm	G15		5	0	1	EPiano1
	1	82	1	2	OB2 Saw		1	100	1	2	WarmAtm		1	119	8	2	808 Tom		1	5	8	1	StSoftEP
	2	82	2	2	PulseSaw		2	100	2	2	NylnHarp		1	119	8	2	808 Tom		2	5	16	1	FM+SA EP
	3	82	3	2	FelineGR		3	100	3	2	HarpSaw		2	119	9	2	ElcPerc		3	5	24	1	Wurlly
	4	82	4	2	Big Lead		4	100	4	2	HlReleas		3	119	127	2	TaikoRim		4	5	126	1	Piano 1
	5	82	5	2	VeloLead		5	100	5	2	NylnRhod	F78		120	0	2	Rev Cym		5	5	127	1	ElcPno2
	6	82	6	2	GR-300		6	100	6	2	AmbntPad		1	120	1	2	Rev Cym2	G16		6	0	1	EPiano2
	8	82	8	2	DocSolo		7	100	127	2	SyMallet		2	120	8	2	RevSnar1		1	6	8	1	DetunEP2
	9	82	16	2	WaspySyn	F55		101	0	2	Bghtness		3	120	9	2	RevSnar2		2	6	16	1	St FM EP
	10	82	127	2	Sax 4		1	101	127	2	Windbell		4	120	16	2	RevKck1		3	6	126	1	Piano 2
F33		83	0	2	SynCall	F56		102	0	2	Goblin		5	120	17	2	RevConBD		4	6	127	1	ElcPno3
	2	83	2	2	PurePanL		1	102	1	2	Goblinsn		6	120	24	2	RevTom 1	G17		7	0	1	Harpsi
	3	83	127	2	Clarint1		2	102	2	2	50sSciFi		7	120	25	2	RevTom 2		1	7	8	1	Coupled
F34		84	0	2	ChifferL		3	102	127	2	Glock		8	120	127	2	Cymbal		2	7	16	1	HarpsiW
	1	84	127	2	Clarint2	F57		103	0	2	EchoDrop	FB1		121	0	2	GFretNz		3	7	24	1	HarpsiO
F35		85	0	2	Charang		1	103	1	2	EchoBell		1	121	1	2	GCutNz		4	7	126	1	Piano 2
	1	85	8	2	DistLead		2	103	2	2	EchoPan		2	121	2	2	StrgSlap		5	7	127	1	ElcPno4
	2	85	127	2	Oboe		3	103	3	2	EchoPan2		2	112	8	2	Pungi	G18		8	0	1	Clav
F36		86	0	2	SoloVox		4	103	4	2	BigPrner		3	112	16	2	Hichirik		1	8	126	1	EPiano1
	1	86	127	2	EnglHorn		5	103	5	2	ResPrner		5	121	5	2	BassSlid		2	8	127	1	Honky-T
F37		87	0	2	5thSawW	F58		104	0	2	StarTtm	FB2		122	0	2	BreathNz	G21		9	0	1	Celesta
	1	87	1	2	BigFives		1	104	1	2	StarTtm2		1	122	1	2	FlKeyClk		1	9	126	1	Cho EPno
	2	87	127	2	Bassoon		2	104	127	2	Xylophon		2	122	127	2	Triangle		2	9	127	1	ElcOrg1
F38		88	0	2	BassLead	F61		105	0	2	Sitar	FB3		123	0	2	Seashore	G22		10	0	1	Glockens
	1	88	1	2	Big&Raw		1	105	1	2	Sitar 2		1	123	1	2	Rain		1	10	126	1	EPiano2
	2	88	2	2	FatPerky		2	105	2	2	DetSitar		2	123	2	2	Thunder		2	10	127	1	ElcOrg2
	3	88	127	2	Harmonic		3	105	8	2	Tambra		3	123	3	2	Wind	G23		11	0	1	MiscBox
F41		89	0	2	Fantasia		4	105	16	2	Tamboura		4	123	4	2	Stream		1	11	126	1	SteelStr
	1	89	1	2	Fantasi2		5	105	127	2	Marimba		5	123	5	2	Bubble		2	11	127	1	ElcOrg3
	2	89	127	2	Trumpet1	F62		106	0	2	Banjo	FB4		124	0	2	Bird	G24		12	0	1	Vibraph
F42		90	0	2	Warm Pad		1	106	1	2	MutBanjo		1	124	1	2	Dog		1	12	8	1	VibW
	1	90	1	2	ThickMtx		2	106	8	2	Rabab		2	124	2	2	HorseGlp		2	12	126	1	SteelStr
	2	90	2	2	Warm Pad		3	106	16	2	Gopichnt		2	124	2	2	Bird 2		3	12	127	1	ElcOrg4
	3	90	3	2	RotarStr		4	106	24	2	Oud		3	124	3	2	Bird 2	G25		13	0	1	Marimba
	4	90	4	2	OBSfPad		5	106	25	2	Oud2		4	124	4	2	Kitty		1	13	8	1	MarimbaW
	5	90	127	2	Trumpet2		6	106	28	2	Oud+Strg		5	124	5	2	Growl		2	13	126	1	12Str Gt
F43		91	0	2	PolySyn	F63		107	0	2	Shamisen	FB5		125	0	2	Teleph 1		3	13	127	1	PipeOrg1
	1	91	1	2	80PolySy		1	107	1	2	Tsugaru		1	125	1	2	Teleph 2	G26		14	0	1	Xyloph
	2	91	127	2	Trombone1		2	107	127	2	Sho		2	125	2	2	DoorCrkg		1	14	126	1	FunkGt
F44		92	0	2	SpaceVce	F64		108	0	2	Koto		3	125	3	2	Door		2	14	127	1	PipeOrg2
	1	92	1	2	Heavenll		1	108	8	2	TaishKot		4	125	4	2	Scratch	G27		15	0	1	TubulB
	2	92	127	2	Trombone2		2	108	16	2	Kanoon		5	125	5	2	WindChim		1	15	8	1	Church8
F45		93	0	2	BowedGls		3	108	17	2	Kanoon2		6	125	7	2	Scratch2		2	15	9	1	Carillon
	1	93	127	2	Fr Horn1		4	108	18	2	KanoonOc		7	125	127	2	BirdTwt		3	15	126	1	MutedGt
F46		94	0	2	MetalPad		5																

GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name
G33		19	0	1	Organ 3	G45		29	0	1	MutedGt	G74		52	0	1	SynStrg2	H28		80	0	1	Ocarina
	1	19	126	1	SlapBas1		1	29	8	1	Funk Gt		1	52	126	1	Trombone		1	80	127	1	Sax 2
	2	19	127	1	Harp3 3		2	29	16	1	Funk Gt2		2	52	127	1	Pizzicat	H31		81	0	1	Square W
G34		20	0	1	Church 1		3	29	126	1	Ac Bass	G75		53	0	1	ChoirAhs		1	81	1	1	MGSquare
	1	20	8	1	Church 2		4	29	127	1	SynBass1		1	53	32	1	ChoAhs		2	81	8	1	2600Sine
	2	20	16	1	Church 3	G46		30	0	1	Overdr		2	53	126	1	Trombone		3	81	127	1	Sax3
	3	20	126	1	SlapBas2		1	30	126	1	ChoirAhs		3	53	127	1	Violin 1	H32		82	0	1	SawWave
	4	20	127	1	Clavi 1		2	30	127	1	SynBass2	G76		54	0	1	VoiceOhs		1	82	1	1	DB2 Saw
G35		21	0	1	ReedOrg	G47		31	0	1	Dist Gt		1	54	126	1	Trombone		2	82	8	1	DoctSolo
	1	21	126	1	SlapBas2		1	31	8	1	Feedbck		2	54	127	1	Violin 2		3	82	127	1	Sax 4
	2	21	127	1	Clavi 2		2	31	126	1	ChoirAhs	G77		55	0	1	SynVox	H33		83	0	1	SynCall
G24		12	0	1	Vibraph		3	31	127	1	SynBass3		1	55	126	1	Alto Sax		1	83	127	1	Clarint1
	1	12	8	1	VibW	G48		32	0	1	Harmonix		2	55	127	1	Cello 1	H34		84	0	1	ChifferL
	2	12	126	1	SteelStr		1	32	8	1	Feedbck	G78		56	0	1	Orch Hit		1	84	127	1	Clarint2
	3	12	127	1	ElecOrg4		2	32	126	1	ChoirAhs		1	56	126	1	TenorSax	H35		85	0	1	Charang
G25		13	0	1	Marimba		3	32	127	1	SynBass4		2	56	127	1	Cello 2		1	85	127	1	Oboe
	1	13	8	1	MarimbaW	G51		33	0	1	Acoustic	G81		57	0	1	Trumpet		1	86	0	1	SoloVox
	2	13	126	1	12Str Gt		1	33	126	1	ChoirAhs		1	57	126	1	BaritSax		1	86	127	1	EnglHorn
	3	13	127	1	PipeOrg1		2	33	127	1	Fantasy	G82		58	0	1	Trombon	H37		87	0	1	5thSawW
G26		14	0	1	Xyloph		1	34	126	1	SlowStrg		1	58	1	1	Trombon2		1	87	127	1	Bassoon
	1	14	126	1	FunkGt		2	34	127	1	HarmoPan		2	58	126	1	Alto Sax	H38		88	0	1	BassLead
	2	14	127	1	PipeOrg2		1	35	0	1	PickBas		3	58	127	1	Harp 1		1	88	127	1	Harmonc
G27		15	0	1	TubulB	G53		35	0	1	Strngs		1	59	126	1	Brass 1	H41		89	0	1	Fantasia
	1	15	8	1	ChurchB		1	35	126	1	Strings		2	59	127	1	Harp 2		1	89	127	1	Trumpet1
	2	15	9	1	Carillon		2	35	127	1	Chorale	G83		59	0	1	Tuba	H42		90	0	1	Warm Pad
	3	15	126	1	MutedGt		1	36	126	1	SynStrg3		1	60	126	1	Brass 1		1	90	127	1	Trumpet2
	4	15	127	1	PipeOrg3		2	36	127	1	Glasses	G84		60	0	1	Mute Tp		2	90	127	1	Guitar 1
G28		16	0	1	Santur		1	37	0	1	Slap 1		1	60	126	1	Brass 1	H43		91	0	1	PolySyn
	1	16	126	1	SlapBas		2	37	126	1	SynStrg3	G85		61	0	1	Fr Horns		1	91	127	1	Trombne1
	2	16	127	1	Accord		1	37	126	1	SynStrg3		2	61	126	1	Brass 2		1	92	0	1	SpaceVce
G31		17	0	1	Organ 1		2	37	127	1	Soundtrk		3	61	127	1	Guitar 2	H44		92	0	1	Trombne2
	1	17	8	1	DetOrg1	G56		38	0	1	SlapBas2		1	62	0	1	Brass 1	H45		93	0	1	BowedGls
	2	17	16	1	60'sOrg1		1	38	126	1	Organ 1		2	62	126	1	Brass 2		1	93	127	1	Fr Horn1
	3	17	32	1	Organ 4		2	38	127	1	Atmosph	G86		62	0	1	Brass 1	H46		94	0	1	MetalPad
	4	17	126	1	SlapBas1		1	39	0	1	SynBass1		1	62	8	1	Brass 2		1	94	127	1	Fr Horn2
	5	17	127	1	Harp3 1		2	39	1	1	Synth101		2	62	126	1	Brass 2	H47		95	0	1	Halo Pad
G32		18	0	1	Organ 2		3	39	126	1	Organ 1		3	62	127	1	ElecGtr1		1	95	127	1	Tuba
	1	18	8	1	DetOrg2		1	39	1	1	AcidBass	G87		63	0	1	SynBras1		1	96	0	1	SweepPad
	2	18	32	1	Organ 5		2	39	8	1	AcidBass		1	63	8	1	ProBrass	H48		96	0	1	Dog
	3	18	126	1	SlapBas1		3	39	126	1	Organ 1		3	63	126	1	Brass 1		2	124	2	1	HorseGlp
	4	18	127	1	Harp3 1		4	39	127	1	WarmBell		4	63	127	1	ElecGtr2		3	124	3	1	Bird 2
G33		19	0	1	Organ 3	G58		40	0	1	SynBass2		4	64	127	1	Sitar		4	124	127	1	Teleph
	1	19	126	1	SlapBas1		1	40	8	1	BeefFMBs	G88		64	0	1	SynBras2	H51		97	0	1	Ice Rain
	2	19	127	1	Harp3 3		2	40	16	1	RuberBs2		3	64	126	1	OrchHit		1	97	127	1	BrSect2
G34		20	0	1	Church 1		3	40	126	1	Organ 1		4	64	127	1	Sitar	H52		98	0	1	Soundtrk
	1	20	8	1	Church 2	G61		41	0	1	Violin		1	65	0	1	SoprSax		1	98	127	1	Vibe 1
	2	20	16	1	Church 3		1	41	8	1	SViolin	H11		65	127	1	AcouBas1		1	99	0	1	Crystal
	3	20	126	1	SlapBas2		2	41	126	1	Organ 2		1	66	127	1	AcouBas2		2	103	2	1	EchoPan
	4	20	127	1	Clavi 1		3	41	127	1	EchoBell	H12		66	0	1	Alto Sax		3	103	127	1	TubeBell
G35		21	0	1	ReedOrg		1	42	0	1	Viola	H13		67	0	1	TenorSax		1	103	1	1	EchoBell
	1	21	126	1	SlapBas2		1	42	126	1	Organ 1		1	67	127	1	ElecBas1		2	99	127	1	Vibe 2
	2	21	127	1	Clavi 2		2	42	127	1	Ice Rain	G63		67	0	1	Brass 1	H53		99	0	1	Crystal
G36		22	0	1	Accord F		1	43	0	1	Cello		1	68	0	1	Baritone		1	99	1	1	SMallet
	1	22	8	1	Accord 1		1	43	126	1	Organ 1		1	68	127	1	ElecBas2		2	99	127	1	Vibe 2
	2	22	126	1	SlapBas2		2	43	127	1	Oboe2001	G64		68	0	1	Brass 2	H54		100	0	1	Atmosph
	3	22	127	1	Clavi 3		1	44	0	1	Contrabs		1	69	0	1	Oboe		1	100	127	1	SyMallet
G37		23	0	1	Harmonc		1	44	126	1	Organ 2		1	69	127	1	SlapBas1	H55		101	0	1	Windbell
	1	23	126	1	SlapBas2		2	44	127	1	Echo Pan		1	70	0	1	EnglHorn		1	101	127	1	Windbell
	2	23	127	1	Celesta 1	G65		45	0	1	TremStrg		1	70	127	1	SlapBas2	H56		102	0	1	Goblin
G38		24	0	1	Bandeon		1	45	126	1	Organ 2		1	71	0	1	Bassoon		1	102	127	1	Glock
	1	24	126	1	Fingered		2	45	127	1	DoctSolo		1	71	127	1	Fretles1		1	103	0	1	EchoDrop
	2	24	127	1	Celesta2	G66		46	0	1	Pizzicat		1	72	0	1	Clarinet		1	103	1	1	EchoBell
G41		25	0	1	NylonStr		1	46	126	1	Organ 2		1	72	127	1	Fretles2		2	103	2	1	EchoPan
	1	25	8	1	Ukulele		2	46	127	1	ScholDaz	H18		72	0	1	Clarinet		3	103	127	1	TubeBell
	2	25	16	1	NylonGtO		1	47	0	1	Harp		1	73	0	1	Piccolo	H58		104	0	1	StarThm
	3	25	32	1	NylonGt2		1	47	126	1	Trumpet		1	73	127								

## Tone List

GBN	Var	PC	CC00	CC32	Name	GBN	Var	PC	CC00	CC32	Name
H66		110	0	1	Bagpipe	H83		123	0	1	Seashore
	1	110	127	1	Whistle2		1	123	1	1	Rain
							2	123	2	1	Thunder
H67		111	0	1	Fiddle		3	123	3	1	Wind
	1	111	127	1	Bottlebl		4	123	4	1	Stream
							5	123	5	1	Bubble
H68		112	0	1	Shanai		6	123	127	1	OrcheHit
	1	112	127	1	BreathPi	H84		124	0	1	Bird
							1	124	1	1	Dog
H71		113	0	1	TinkBell		2	124	2	1	HorseGlp
	1	113	127	1	Timpani		3	124	3	1	Bird 2
							4	124	127	1	Teleph
H72		114	0	1	Agogo	H85		125	0	1	Teleph 1
	1	114	127	1	MelodTom		1	125	1	1	Teleph 2
							2	125	2	1	DoorCrkg
H73		115	0	1	SteelDrum		3	125	3	1	Door
	1	115	127	1	DeepSnar		4	125	4	1	Scratch
							5	125	5	1	WindChim
H74		116	0	1	Woodblck		6	125	127	1	BirdTwet
	1	116	8	1	Castants	H86		126	0	1	Helicptr
	2	116	127	1	ElcPerc1		1	126	1	1	CarEngin
							2	126	2	1	Car-Stop
H75		117	0	1	Taiko		3	126	3	1	Car-Pass
	1	117	8	1	ConcrtBd		4	126	4	1	CarCrash
	2	117	127	1	ElcPerc2		5	126	5	1	Siren
							6	126	6	1	Train
H76		118	0	1	MeloTom1		7	126	7	1	Jetplane
	1	118	8	1	MeloTom2		8	126	8	1	Starship
	2	118	127	1	Taiko		9	126	9	1	Burst Nz
							10	126	127	1	NoteJam
H77		119	0	1	SynthDrum	H87		127	0	1	Applause
	1	119	8	1	808 Tom		1	127	1	1	Laughing
	2	119	9	1	ElcPerc		2	127	2	1	Screamng
	3	119	127	1	TaikoRim		3	127	3	1	Punch
							4	127	4	1	HeartBt
H78		120	0	1	Rev Cym		5	127	5	1	FootStps
	1	120	127	1	Cymbal		6	127	127	1	WterBell
						H88		128	0	1	Gun Shot
H81		121	0	1	GFretNz		1	128	1	1	MchinGun
	1	121	1	1	GCutNz		2	128	2	1	LaserGun
	2	121	2	1	StrgSlap		3	128	3	1	Explos
	3	121	127	1	Castanet		4	128	127	1	JungleTn
H82		122	0	1	BreathNz						
	1	122	1	1	FlKeyClk						
	2	122	127	1	Triangle						



## 22. Music Style list

No.	Name	TimeSign	BPM
-----	------	----------	-----

### ROCK

A11	LightRk	4/4	73
A12	PowerRk1	4/4	116
A13	PowerRk2	4/4	128
A14	PowerRk3	4/4	132
A15	ShRock	4/4	120
A16	Sh Bald1	4/4	88
A17	Sh Bald2	4/4	107
A18	SI Rock	6/8	96

### CONTEMPORARY

A21	House	4/4	132
A22	Dance	4/4	140
A23	Techno	4/4	144
A24	TwoStep	4/4	134
A25	HipHop	4/4	82
A26	70s&80s	4/4	114
A27	LtDance	4/4	105
A28	Contemp	4/4	96

### POP

A31	Pop 1A	4/4	56
A32	Pop 2A	4/4	70
A33	Pop 3A	4/4	108
A34	Pop 4A	4/4	78
A35	Pop 1B	4/4	74
A36	Pop 2B	4/4	82
A37	Pop 3B	4/4	98
A38	Pop 4B	4/4	100

### 50's & 60's

A41	Rock'N1	4/4	143
A42	Rock'N2	4/4	160
A43	Rock'N3	4/4	197
A44	PopRock	4/4	140
A45	Foxtrot	4/4	185
A46	Boogie	4/4	186
A47	Charlest	4/4	193
A48	Twist	4/4	160

No.	Name	TimeSign	BPM
-----	------	----------	-----

### SWING

A51	SI Swing	4/4	55
A52	MedSwng	4/4	100
A53	ScatSwng	4/4	125
A54	CoolSwng	4/4	135
A55	FstBlues	4/4	126
A56	R&B	4/4	106
A57	Big Band	4/4	140
A58	Shuffle	4/4	143

### LATIN

A61	Bossa 1	4/4	125
A62	Bossa 2	4/4	173
A63	Samba	4/4	104
A64	DscSamba	4/4	132
A65	Mambo	4/4	90
A66	Mereng	4/4	130
A67	Salsa	4/4	98
A68	ChaCha	4/4	123

### VARIETY

A71	Son	4/4	152
A72	Island	4/4	105
A73	ArgTango	4/4	120
A74	Rhumba	4/4	97
A75	SIWaltz	3/4	90
A76	OrchWltz	3/4	180
A77	March	4/4	112
A78	PolkaPop	4/4	132

### ACOUSTIC

A81	G Slow	4/4	65
A82	G Bossa	4/4	100
A83	G FstPop	4/4	90
A84	G Ballad	4/4	130
A85	P Night	4/4	60
A86	P Slow	4/4	64
A87	P Jazz	4/4	150
A88	P Shuffl	4/4	150

# 23. Drum Sets

	PC: 1 [CC32: 4]	PC: 2 [CC32: 4]	PC: 3 [CC32: 4]	PC: 4 [CC32: 4]	PC: 5 [CC32: 4]	PC: 6 [CC32: 4]	PC: 9 [CC32: 4]	PC: 10 [CC32: 4]	PC: 11 [CC32: 4]	PC: 12 [CC32: 4]
	STANDARD 1	STANDARD 2	STANDARD L/R	V-Pop1	V-R&B	V-Flute	ROOM	HIP HOP	JUNGLE	TECHNO
1	Std.1 Kick1	Std.1 Kick1	---	Hiphop BD1	Hiphop BD1	Hiphop BD1	Std.1 Kick1	Elec Kick 2	Elec Kick 2	Elec Kick 2
2	Std.1 Kick2	Std.1 Kick2	---	Jazz Kick 1	Jazz Kick 1	Jazz Kick 1	Std.1 Kick2	Elec Kick 1	Elec Kick 1	Elec Kick 1
3	Std.2 Kick1	Std.2 Kick1	---	Mex_Kik36	Mex_Kik36	Mex_Kik36	Std.2 Kick1	CR78 BD 1	CR78 BD 1	CR78 BD 1
4	Std.2 Kick2	Std.2 Kick2	---	BS5RmBDrum1B	BS5RmBDrum1B	BS5RmBDrum1B	Std.2 Kick2	CR78 BD 2	CR78 BD 2	CR78 BD 2
5	Kick 1	Kick 1	---	BS5RmBDrum2B	BS5RmBDrum2B	BS5RmBDrum2B	Kick 1	TR-606 BD1	TR-606 BD1	TR-606 BD1
6	Kick 2	Kick 2	---	909 BD	909 BD	909 BD	Kick 2	TR-707 BD	TR-707 BD	TR-707 BD
7	Jazz Kick 1	Jazz Kick 1	---	909 BD 2	909 BD 2	909 BD 2	Jazz Kick 1	808 Kick	808 Kick	808 Kick
8	Jazz Kick 2	Jazz Kick 2	---	Jngl BD 2	Jngl BD 2	Jngl BD 2	Jazz Kick 2	TR-808 Kick	TR-808 Kick	TR-808 Kick
9	Room Kick 1	Room Kick 1	---	Hiphop BD	Hiphop BD	Hiphop BD	Room Kick 1	808 BD	808 BD	808 BD
10	Room Kick 2	Room Kick 2	---	Hiphop BD 2	Hiphop BD 2	Hiphop BD 2	Room Kick 2	TR-909 Kick	TR-909 Kick	TR-909 Kick
11	Power Kick1	Power Kick1	---	BS5BDrum1B	BS5BDrum1B	BS5BDrum1B	Power Kick1	Dance Kick 2	Dance Kick 2	Dance Kick 2
12	Power Kick2	Power Kick2	---	NewJzKik	NewJzKik	NewJzKik	Power Kick2	909 Comp BD	909 Comp BD	909 Comp BD
13	Elec Kick 2	Elec Kick 2	---	NewRockKik	NewRockKik	NewRockKik	Elec Kick 2	TR-909 BD2	TR-909 BD2	TR-909 BD2
14	TR-909 Kick	TR-909 Kick	---	CymbalRoll	CymbalRoll	CymbalRoll	TR-909 Kick	Hiphop BD2	Hiphop BD2	Hiphop BD2
15	TR-909 Kick	TR-909 Kick	---	NewRkCStk1Mn	NewRkCStk1Mn	NewRkCStk1Mn	TR-909 Kick	JungleBD Set	JungleBD Set	JungleBD Set
16	Dance Kick 2	Dance Kick 2	---	BS5Snare1B	BS5Snare1B	BS5Snare1B	Dance Kick 2	Techno BD1	Techno BD1	Techno BD1
17	Voice One	Voice One	Voice One	BS5Snare2B	BS5Snare2B	BS5Snare2B	Voice One	Bounce	Bounce	Bounce
18	Voice Two	Voice Two	Voice Two	BS5Snare1B	BS5Snare1B	BS5Snare1B	Voice Two	Voice One	Voice One	Voice One
19	Voice Three	Voice Three	Voice Three	BS5Snare2B	BS5Snare2B	BS5Snare2B	Voice Three	Voice Two	Voice Two	Voice Two
20	BS5Rm BDrum1	---	---	NewJzSn2	NewJzSn2	NewJzSn2	BS5Rm BDrum1	Voice Three	Voice Three	Voice Three
21	BS5Rm BDrum2	---	---	NewJzSn1	NewJzSn1	NewJzSn1	BS5Rm BDrum2	Jngl BD	Hiphop BD 2	909 BD
22	MC-500 Beep	MC-500 Beep	MC-500 Beep	NewRkBSn	NewRkBSn	NewRkBSn	MC-500 Beep	Jngl BD 2	Hiphop BD 2	Fal BD
23	MC-500 Beep	MC-500 Beep	MC-500 Beep	NewRockSn2mm	NewRockSn2mm	NewRockSn2mm	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
24	Concert Snr	Concert Snr	Concert Snr	NewRockSn1mm	NewRockSn1mm	NewRockSn1mm	Concert Snr	MC-500 Beep	MC-500 Beep	MC-500 Beep
25	Snare Roll	Snare Roll	Snare Roll	IPopSn38mm	IPopSn38mm	IPopSn38mm	Snare Roll	Concert Snr	Concert Snr	Concert Snr
26	FingerSnaps2	Finger Snap	FingerSnaps2	IPopGst39mm	IPopGst39mm	IPopGst39mm	FingerSnaps2	Snare Roll	Snare Roll	Snare Roll
27	High-Q	High-Q	High-Q	IPopSn38mm	IPopSn38mm	IPopSn38mm	High-Q	FingerSnaps2	FingerSnaps2	FingerSnaps2
28	Slap	Slap	Slap	FingerSnaps2	FingerSnaps2	FingerSnaps2	Slap	High-Q	High-Q	High-Q
29	ScratchPush	ScratchPush	ScratchPush	707 Claps	707 Claps	707 Claps	ScratchPush	Slap	Slap	Slap
30	ScratchPull	ScratchPull	ScratchPull	808Clap	808Clap	808Clap	ScratchPull	ScratchPush2	ScratchPush2	ScratchPush2
31	Sticks	Sticks	Sticks	Hand clp2	Hand clp2	Hand clp2	Sticks	Scratch Pull2	Scratch Pull2	Scratch Pull2
32	SquareClick	SquareClick	SquareClick	909 HandClap	909 HandClap	909 HandClap	SquareClick	Sticks	Sticks	Sticks
33	Mtrmn.Clck	Mtrmn.Clck	Mtrmn.Clck	IPopPhat32	IPopPhat32	Mex_Phat32	Mtrmn.Clck	SquareClick	SquareClick	SquareClick
34	Mtrmn.Bell	Mtrmn.Bell	Mtrmn.Bell	IPopMtrnClk	IPopMtrnClk	GospelHC1p1	Mtrmn.Bell	Mtrmn.Clck	Mtrmn.Clck	Mtrmn.Clck
35	BDrum1	Std.2 Kick2	BS5BDrum1B	IPopMtrnBell	IPopMtrnBell	Mex_SurRf34	BDrum1	Mtrmn.Bell	Mtrmn.Bell	Mtrmn.Bell
36	BS5BDrum2	Std.2 Kick1	BS5BDrum2B	IPopKik35	IPopKik35	Mex_Kik35	BS5BDrum2	BDrum1	Jngl BD	808 BD
37	Side Stick	Side Stick	Side Stick	IPopKik36	IPopKik36	Mex_Kik36	Side Stick	Hiphop BD 2	Jngl BD 2	909 BD 2
38	BS5 Snare2	Std.2 Snare1	BS5Snare2B	IPopCStk37st	IPopCStk37st	IPopCStk37mm	BS5 Snare2	Hiphop BD	Jngl SD 1	909 SD 1
39	BS5 Snare1	Std.2 Snare2	BS5Snare1B	IPopGst39st	IPopGst39st	Mex_Gst39	BS5 Snare1	LoFi SD 1	Hiphop SD 1	606 SD 2
40	Room Tom 6	Room Tom 6	Room Tom 6	808Clap	808Clap	808Clap	Room Tom 6	909 Claps	909 Claps	909 Claps
41	BS5 Tom16	Real Tom 6	BS5Tom16B	IPopTomF41	IPopTomF41	Mex_Snr40	BS5 Tom16	LoFi SD 2	Jngl SD	Techno SD
42	BS5 Tom8	Jazz Chd HHat2	BS5ChHt2B	IPopTomF41	IPopTomF41	Mex_Snr40	BS5 Tom8	909 Tom	606 Dnt.Tom	606 Dnt.Tom
43	BS5 Tom16	Real Tom 6	BS5Tom16B	IPopHt1.42	IPopHt1.42	Mex_Ht1.42	BS5 Tom16	Room Tom 5	Room Tom 5	Room Tom 5
44	Pedal HHat2	Pedal HHat2	Pedal HHat2	IPopTomL43	IPopTomL43	Mex_Ht1.42	Pedal HHat2	Room Chh	606 CH	TR-707 HHc
45	BS5 Tom12	Real Tom 4	BS5Tom12B	IPopTomL43	IPopTomL43	Mex_Ht1.42	BS5 Tom12	Room Tom 5	909 Tom	606 Dnt.Tom
46	BS5 Tom12	Real Tom 4	BS5Tom12B	IPopTomM45	IPopTomM45	Mex_Ht1.42	BS5 Tom12	Room Tom 2	909 Tom	606 Dnt.Tom
47	BS5 Tom12	Real Tom 4	BS5Tom12B	IPopTomM45	IPopTomM45	Mex_Ht1.42	BS5 Tom12	Room Tom 2	909 Tom	606 Dnt.Tom
48	BS5 Tom10	Real Tom 1	BS5Tom10B	IPopTomM47	IPopTomM47	Mex_Ht1.42	BS5 Tom10	Room Tom 2	909 Tom	606 Dnt.Tom
49	BS5 CrCym1	Crash Cym 1	BS5CrCym1B	IPopTomM47	IPopTomM47	Mex_Ht1.42	BS5 CrCym1	Room Tom 2	909 Tom	606 Dnt.Tom
50	BS5 Tom10	Real Tom 1	BS5Tom10B	IPopCym1.49	IPopCym1.49	Mex_Cym1.49	BS5 Tom10	Room Tom 2	909 Tom	606 Dnt.Tom
51	BS5 RdCym	Ride Cymbal	BS5RdCymB	IPopCym1.51	IPopCym1.51	Mex_Cym1.51	BS5 RdCym	Room Tom 2	909 Tom	606 Dnt.Tom
52	ChinaCymbal	ChinaCymbal	ChinaCymbal	IPopCym2.52	IPopCym2.52	Mex_Cym2.52	ChinaCymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal
53	BS5 RdlBell	Ride Bell	BS5RdlBellB	IPopRdl.51	IPopRdl.51	Mex_Rdl.51	BS5 RdlBell	ReverseCymbal	ReverseCymbal	ReverseCymbal
54	Tambourine	Tambourine	Tambourine	IPopRdl.55	IPopRdl.55	Mex_Rdl.55	Tambourine	Ride Bell	Ride Bell	Ride Bell
55	Splash Cym	Splash Cym	Splash Cym	IPopRdl.55	IPopRdl.55	Mex_Rdl.55	Splash Cym	Shake Tamb	Shake Tamb	Shake Tamb
56	Cowbell	Cowbell	Cowbell	IPopRdl.55	IPopRdl.55	Mex_Rdl.55	Cowbell	Tambourine	Tambourine	Tambourine
57	Crash Cym 2	Crash Cym 2	Crash Cym 2	IPopRdl.55	IPopRdl.55	Mex_Rdl.55	Crash Cym 2	Shake Tamb	Shake Tamb	Shake Tamb
58	Vibraslap	Vibraslap	Vibraslap	NewRkCrCym2	NewRkCrCym2	NewRkCrCym2	Vibraslap	808cowbe	808cowbe	808cowbe
59	Ride Cymbal	Ride Cymbal	Ride Cymbal	NewRkCrCym2	NewRkCrCym2	NewRkCrCym2	Ride Cymbal	909 Crash	909 Crash	909 Crash
60	Bongo High	Bongo High	Bongo High	NewRkRdCym1	NewRkRdCym1	NewRkRdCym1	Bongo High	Vibraslap	Vibraslap	Vibraslap
61	Bongo Lo	Bongo Lo	Bongo Lo	NewRkRdCym1	NewRkRdCym1	NewRkRdCym1	Bongo Lo	Ride Cymbal	Ride Cymbal	Ride Cymbal
62	Mute H.Conga	Mute H.Conga	Mute H.Conga	NewHdBongo	NewHdBongo	NewHdBongo	Mute H.Conga	Ride Cymbal	Ride Cymbal	Ride Cymbal
63	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	NewLoBongo	NewLoBongo	NewLoBongo	Conga Hi Opn	Bongo High	Bongo High	Bongo High
64	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	NewCongaSlp	NewCongaSlp	NewCongaSlp	Conga Lo Opn	Bongo Lo	Bongo Lo	Bongo Lo
65	High Timbale	High Timbale	High Timbale	NewCongaOp	NewCongaOp	NewCongaOp	High Timbale	Bongo Lo	Bongo Lo	Bongo Lo
66	Low Timbale	Low Timbale	Low Timbale	NewLoConga	NewLoConga	NewLoConga	Low Timbale	CR78 LoBongo	CR78 LoBongo	CR78 LoBongo
67	Agogo	Agogo	Agogo	NewTmbH	NewTmbH	NewTmbH	Agogo	808 Conga	808 Conga	808 Conga
68	Agogo	Agogo	Agogo	NewTmbLo	NewTmbLo	NewTmbLo	Agogo	808 Conga	808 Conga	808 Conga
69	Cabasa	Cabasa	Cabasa	NewTmbLo	NewTmbLo	NewTmbLo	Cabasa	808 Conga	808 Conga	808 Conga
70	Maracas	Maracas	Maracas	NewShaker2	NewShaker2	NewShaker2	Maracas	808 Conga	808 Conga	808 Conga
71	ShrtWhistle	ShrtWhistle	ShrtWhistle	NewShaker1	NewShaker1	NewShaker1	ShrtWhistle	808 Conga	808 Conga	808 Conga
72	LongWhistle	LongWhistle	LongWhistle	NewShaker1	NewShaker1	NewShaker1	LongWhistle	808 Conga	808 Conga	808 Conga
73	Short Guiro	Short Guiro	Short Guiro	NewShaker1	NewShaker1	NewShaker1	Short Guiro	808 Conga	808 Conga	808 Conga
74	Long Guiro	Long Guiro	Long Guiro	NewShaker1	NewShaker1	NewShaker1	Long Guiro	808 Conga	808 Conga	808 Conga
75	Claves	Claves	Claves	NewShaker1	NewShaker1	NewShaker1	Claves	808 Conga	808 Conga	808 Conga
76	Woodblock	Woodblock	Woodblock	NewShaker1	NewShaker1	NewShaker1	Woodblock	808 Conga	808 Conga	808 Conga
77	Woodblock	Woodblock	Woodblock	NewShaker1	NewShaker1	NewShaker1	Woodblock	808 Conga	808 Conga	808 Conga
78	Mute Cuca	Mute Cuca	Mute Cuca	NewShaker1	NewShaker1	NewShaker1	Mute Cuca	808 Conga	808 Conga	808 Conga
79	Open Cuca	Open Cuca	Open Cuca	NewShaker1	NewShaker1	NewShaker1	Open Cuca	808 Conga	808 Conga	808 Conga
80	Mute Triangl	Mute Triangl	Mute Triangl	NewShaker1	NewShaker1	NewShaker1	Mute Triangl	808 Conga	808 Conga	808 Conga
81	Open Triangl	Open Triangl	Open Triangl	NewShaker1	NewShaker1	NewShaker1	Open Triangl	808 Conga	808 Conga	808 Conga
82	Shaker	Shaker	Shaker	NewShaker1	NewShaker1	NewShaker1	Shaker	808 Conga	808 Conga	808 Conga
83	Jingle Bell	Jingle Bell	Jingle Bell	NewShaker1	NewShaker1	NewShaker1	Jingle Bell	808 Conga	808 Conga	808 Conga
84	Bell Tree	Bar Climes	Bell Tree	NewShaker1	NewShaker1	NewShaker1	Bell Tree	808 Conga	808 Conga	808 Conga
85	Castanets	Castanets	Castanets	NewShaker1	NewShaker1	NewShaker1	Castanets	808 Conga	808 Conga	808 Conga
86	Mute Surdo	Mute Surdo	Mute Surdo	NewShaker1	NewShaker1	NewShaker1	Mute Surdo	808 Conga	808 Conga	808 Conga
87	Open Surdo	Open Surdo	Open Surdo	NewShaker1	NewShaker1	NewShaker1	Open Surdo	808 Conga	808 Conga	808 Conga
88	Applause 2	Applause 2	Applause 2	NewShaker1	NewShaker1	NewShaker1	Applause 2	808 Conga	808 Conga	808 Conga
89	---	---	---	NewShaker1	NewShaker1	NewShaker1	---	808 Conga	808 Conga	808 Conga
90	---	---	---	NewShaker1	NewShaker1	NewShaker1	---	808 Conga	808 Conga	808 Conga
91	---	---	---	NewShaker1	NewShaker1	NewShaker1	---	808 Conga	808 Conga	808 Conga
92	---	---	---	NewShaker1	NewShaker1	NewShaker1	---	808 Conga	808 Conga	808 Conga
93	---	---	---	NewShaker1	NewShaker1	NewShaker1	---	808 Conga	808 Conga	808 Conga
94	---	---	---	NewShaker1	NewShaker1	NewShaker1	---	808 Conga	808 Conga	808 Conga
95	BS5Rm Snare2	BS5Rm Snare2	BS5Rm Snare2	NewShaker1	NewShaker1	NewShaker1	BS5Rm Snare2	808 Conga	808 Conga	808 Conga
96	BS5Rm Snare1	BS5Rm Snare1	BS5Rm Snare1	NewShaker1	NewShaker1	NewShaker1	BS5Rm Snare1	808 Conga	808 Conga	808 Conga

	PC: 1 [CC32: 4] STANDRD 1	PC: 7 [CC32: 4] STANDRD 2	PC: 3 [CC32: 4] STANDRD L/R	PC: 4 [CC32: 4] V-Pop1	PC: 5 [CC32: 4] V-Rock1	PC: 6 [CC32: 4] V-Fiesta	PC: 9 [CC32: 4] ROOM	PC: 10 [CC32: 4] HIP HOP	PC: 11 [CC32: 4] JUNGLE	PC: 12 [CC32: 4] TECHNO
96	(BSRm Snare1)	---	(BS51 BDrum2)	(CajonH)	(CajonH)	(CajonH)	(BS51 Snare1)	(Dance SD)	(HipHop SD 1)	(HipHop SD 2)
97	Std.1 Snare1	Std.1 Snare1	BS51 CrsCym1	CajonHFlm	CajonHFlm	CajonHFlm	Std.1 Snare1	Techno Hit	Techno Hit	Techno Hit
98	Std.1 Snare2	Std.1 Snare2	BS51 Snare2	CajonLo	CajonLo	CajonLo	Std.1 Snare2	Philly Hit	Philly Hit	Philly Hit
99	Std.2 Snare1	Std.2 Snare1	BS51 RdCym	CajonLoFlm	CajonLoFlm	CajonLoFlm	Std.2 Snare1	Shock Wave	Shock Wave	Shock Wave
100	Std.2 Snare2	Std.2 Snare2	BS51 Snare1	FimncHClp1	FimncHClp1	FimncHClp1	Std.2 Snare2	Lo Fi Rave	Lo Fi Rave	Lo Fi Rave
101	Tight Snare	Tight Snare	BS51 Tom16	FimncHClp1	FimncHClp1	FimncHClp1	Tight Snare	Bam Hit	Bam Hit	Bam Hit
102	Standard SH1	Standard SH1	BS51 ClpHat	BongoCowBell	BongoCowBell	BongoCowBell	Standard SH1	Bim Hit	Bim Hit	Bim Hit
103	LD Snare M	LD Snare M	BS51 Tom12	AlHey	AlHey	AlHey	LD Snare M	TapeRewind	TapeRewind	TapeRewind
104	LD Snare C	LD Snare C	BS51 RdBell	MamboCowBell	MamboCowBell	MamboCowBell	LD Snare C	Phono Noise	Phono Noise	Phono Noise
105	Jazz Snare 1	Jazz Snare 1	BS51 Tom10	MezFVoz2	MezFVoz2	MezFVoz2	Jazz Snare 1	Dance Snare1	Dance Snare1	Dance Snare1
106	Jazz Snare 2	Jazz Snare 2	BS51 OpenHat	AlFfoots	AlFfoots	AlFfoots	Jazz Snare 2	Power Snare2	Power Snare2	Power Snare2
107	Room Snare 1	Room Snare 1	BS51BDrum1P	MezFVox1	MezFVox1	MezFVox1	Room Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1
108	Room Snare 2	Room Snare 2	BS51BDrum2P	MezFVox1	MezFVox1	MezFVox1	Room Snare 2	Dance Snare2	Dance Snare2	Dance Snare2
109	Dance Snare1	Dance Snare1	BS51CrsCym1P	YodelFVox1	YodelFVox1	YodelFVox1	Dance Snare1	Elec Snare 2	Elec Snare 2	Elec Snare 2
110	Power Snare1	Power Snare1	BS51Snare2P	MezFVox2	MezFVox2	MezFVox2	Power Snare1	Elec. Snare	Elec. Snare	Elec. Snare
111	Rev.Snare	Rev.Snare	BS51 RdCym P	YodelMVox1	YodelMVox1	YodelMVox1	Rev.Snare	Elec Snare 3	Elec Snare 3	Elec Snare 3
112	Power Snare2	Power Snare2	BS51 Snare1P	MezFVox3	MezFVox3	MezFVox3	Power Snare2	666n260	666n260	666n260
113	Elec Snare 1	Elec Snare 1	BS51 Tom15 P	FimncFVox1	FimncFVox1	FimncFVox1	Elec Snare 1	TR-707 SD	TR-707 SD	TR-707 SD
114	Dance Snare2	Dance Snare2	BS51 ClpHatP	YodelFVox2	YodelFVox2	YodelFVox2	Dance Snare2	808 Snare 1	808 Snare 1	808 Snare 1
115	Elec Snare 2	Elec Snare 2	BS51 Tom12 P	FimncFVox2	FimncFVox2	FimncFVox2	Elec Snare 2	808 Snare 2	808 Snare 2	808 Snare 2
116	Elec. Snare	Elec. Snare	BS51 RdBellP	NewWhistle1	NewWhistle1	NewWhistle1	Elec. Snare	TR-808 SD2	TR-808 SD2	TR-808 SD2
117	Elec Snare 3	Elec Snare 3	BS51 Tom10 P	FimncFVox3	FimncFVox3	FimncFVox3	Elec Snare 3	909 Snare 1	909 Snare 1	909 Snare 1
118	TR-707 SD	TR-707 SD	BS51OpenHatP	NewWhistle2	NewWhistle2	NewWhistle2	TR-707 SD	909 Snare 2	909 Snare 2	909 Snare 2
119	808 Snare 1	808 Snare 1	---	FimncMVox1	FimncMVox1	FimncMVox1	808 Snare 1	909 SD 1	909 SD 1	909 SD 1
120	808 Snare 2	808 Snare 2	---	FimncMVox2	FimncMVox2	FimncMVox2	808 Snare 2	TR-909 SD2	TR-909 SD2	TR-909 SD2
121	909 Snare 1	909 Snare 1	---	BrazilVox1	BrazilVox1	BrazilVox1	909 Snare 1	Rap Snare	Rap Snare	Rap Snare
122	909 Snare 2	909 Snare 2	---	FimncMVox3	FimncMVox3	FimncMVox3	909 Snare 2	JungleSD1	JungleSD1	JungleSD1
123	Rap Snare	Rap Snare	---	BrazilVox2	BrazilVox2	BrazilVox2	Rap Snare	House SD	House SD	House SD
124	JungleSD1	JungleSD1	---	BrazilVox3	BrazilVox3	BrazilVox3	JungleSD1	House Snare	House Snare	House Snare
125	House SD	House SD	---	AlAahhh	AlAahhh	AlAahhh	House SD	House SD	House SD	House SD
126	House Snare	House Snare	---	p33137v	p33137v	p33137v	House Snare	Voce Tah	Voce Tah	Voce Tah
127	House SD	House SD	---	p33168v	p33168v	p33168v	House SD	Noise Slap	Noise Slap	Noise Slap

	PC: 13 [CC32: 4] ROOM L/R	PC: 14 [CC32: 4] HOUSE	PC: 17 [CC32: 4] POWER	PC: 18 [CC32: 4] V-Rock1	PC: 19 [CC32: 4] V-Rock2	PC: 25 [CC32: 4] ELECTRNIC	PC: 26 [CC32: 4] TR-808	PC: 27 [CC32: 4] DAHCE	PC: 29 [CC32: 4] CR-78	PC: 29 [CC32: 4] TR-806
96	(BSRm BDrum2)	(Ingr SD)	(-)	(CajonH)	(CajonH)	(-)	(-)	(HipHop SD 2)	(-)	(-)
97	BSRm CrsCym1	Techno Hit	Std.1 Snare1	CajonHFlm	CajonHFlm	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit
98	BSRm Snare2	Philly Hit	Std.1 Snare2	CajonLo	CajonLo	Philly Hit	Philly Hit	Philly Hit	Philly Hit	Philly Hit
99	BSRm RdCym	Shock Wave	Std.2 Snare1	CajonLoFlm	CajonLoFlm	Shock Wave	Shock Wave	Shock Wave	Shock Wave	Shock Wave
100	BSRm Snare1	Lo Fi Rave	Std.2 Snare2	FimncHClp1	FimncHClp1	Lo Fi Rave	Lo Fi Rave	Lo Fi Rave	Lo Fi Rave	Lo Fi Rave
101	Room Tom 5	Bam Hit	Tight Snare	FimncHClp1	FimncHClp1	Bam Hit	Bam Hit	Bam Hit	Bam Hit	Bam Hit
102	BSRm ClpHat	Bim Hit	Standard SH1	BongoCowBell	BongoCowBell	Bim Hit	Bim Hit	Bim Hit	Bim Hit	Bim Hit
103	Room Tom 2	TapeRewind	LD Snare M	AlHey	AlHey	TapeRewind	TapeRewind	TapeRewind	TapeRewind	TapeRewind
104	BSRm RdBell	Phono Noise	LD Snare C	MamboCowBell	MamboCowBell	Phono Noise	Phono Noise	Phono Noise	Phono Noise	Phono Noise
105	Room Tom 2	Dance Snare1	Jazz Snare 1	MezFVoz2	MezFVoz2	Dance Snare1	Dance Snare1	Dance Snare1	Dance Snare1	Dance Snare1
106	BSRm OpenHat	Power Snare2	Jazz Snare 2	AlFfoots	AlFfoots	Power Snare2	Power Snare2	Power Snare2	Power Snare2	Power Snare2
107	BSRmBDrum1P	Elec Snare 1	Room Snare 1	MezFVox1	MezFVox1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1
108	BSRmBDrum2P	Dance Snare2	Room Snare 2	MezFVox1	MezFVox1	Dance Snare2	Dance Snare2	Dance Snare2	Dance Snare2	Dance Snare2
109	BSRmCrsCym1P	Elec Snare 2	Dance Snare1	YodelFVox1	YodelFVox1	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2
110	BSRmSnare2 P	Power Snare1	Dance Snare1	MezFVox2	MezFVox2	Power Snare1	Power Snare1	Power Snare1	Power Snare1	Power Snare1
111	BSRm RdCymP	Elec Snare 3	Rev.Snare	YodelMVox1	YodelMVox1	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3
112	BSRmSnare1P	666n260	Power Snare2	MezFVox3	MezFVox3	666n260	666n260	666n260	666n260	666n260
113	Room Tom 5 P	TR-707 SD	Elec Snare 1	FimncFVox1	FimncFVox1	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 SD
114	BSRm ClpHatP	808 Snare 1	Dance Snare2	YodelFVox2	YodelFVox2	808 Snare 1	808 Snare 1	808 Snare 1	808 Snare 1	808 Snare 1
115	Room Tom 2 P	808 Snare 2	Elec Snare 2	FimncFVox2	FimncFVox2	808 Snare 2	808 Snare 2	808 Snare 2	808 Snare 2	808 Snare 2
116	BSRm RdCymP	TR-808 SD2	Elec. Snare	NewWhistle1	NewWhistle1	TR-808 SD2	TR-808 SD2	TR-808 SD2	TR-808 SD2	TR-808 SD2
117	Room Tom 2 P	909 Snare 1	Elec Snare 3	FimncFVox3	FimncFVox3	909 Snare 1	909 Snare 1	909 Snare 1	909 Snare 1	909 Snare 1
118	BSRmOpenHatP	909 Snare 2	TR-707 SD	NewWhistle2	NewWhistle2	909 Snare 2	909 Snare 2	909 Snare 2	909 Snare 2	909 Snare 2
119	---	909 SD 1	808 Snare 1	FimncMVox1	FimncMVox1	909 SD 1	909 SD 1	909 SD 1	909 SD 1	909 SD 1
120	---	TR-909 SD2	808 Snare 2	FimncMVox2	FimncMVox2	TR-909 SD2	TR-909 SD2	TR-909 SD2	TR-909 SD2	TR-909 SD2
121	---	Rap Snare	909 Snare 1	BrazilVox1	BrazilVox1	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Rap Snare
122	---	JungleSD1	909 Snare 2	FimncMVox3	FimncMVox3	JungleSD1	JungleSD1	JungleSD1	JungleSD1	JungleSD1
123	---	House SD	Rap Snare	BrazilVox2	BrazilVox2	House SD	House SD	House SD	House SD	House SD
124	---	House Snare	JungleSD1	BrazilVox3	BrazilVox3	House Snare	House Snare	House Snare	House Snare	House Snare
125	---	House SD	House SD	AlAahhh	AlAahhh	House SD	House SD	House SD	House SD	House SD
126	---	Voce Tah	House Snare	p33137v	p33137v	Voce Tah	Voce Tah	Voce Tah	Voce Tah	Voce Tah
127	---	Noise Slap	House SD	p33168v	p33168v	Noise Slap	Noise Slap	Noise Slap	Noise Slap	Noise Slap

REFERENCE

Drum Sets

	PC-13 [CC32: 4]	PC-14 [CC32: 4]	PC-17 [CC32: 4]	PC-18 [CC32: 4]	PC-19 [CC32: 4]	PC-25 [CC32: 4]	PC-26 [CC32: 4]	PC-27 [CC32: 4]	PC-28 [CC32: 4]	PC-29 [CC32: 4]
	ROOM L/R	HOUSE	POWER	V-Rock1	V-Rock2	ELECTRHC	TR-808	DANCE	CR-78	TR-808
C-1	0	---	Elec Kick 2	Std1 Kick1	HipHop BD1	HipHop BD1	Elec Kick 2	Elec Kick 2	Elec Kick 2	Elec Kick 2
	1	---	Elec Kick 1	Std1 Kick2	Jazz Kick 1	Jazz Kick 1	Elec Kick 1	Elec Kick 1	Elec Kick 1	Elec Kick 1
	2	---	CR78 BD 1	Std2 Kick1	Mex_Kik36	Mex_Kik36	CR78 BD 1	CR78 BD 1	CR78 BD 1	CR78 BD 1
	3	---	CR78 BD 2	Std2 Kick2	85RmBDrum1B	85RmBDrum1R	CR78 BD 2	CR78 BD 2	CR78 BD 2	CR78 BD 2
	4	---	TR-808 BD1	Kick 1	85RmBDrum2B	85RmBDrum2R	TR-808 BD1	TR-808 BD1	TR-808 BD1	TR-808 BD1
	5	---	TR-707 BD	Kick 2	909 BD 1	909 BD 1	TR-707 BD	TR-707 BD	TR-707 BD	TR-707 BD
	6	---	808 Kick	Jazz Kick 1	909 BD 2	909 BD 2	808 Kick	808 Kick	808 Kick	808 Kick
	7	---	TR-808 Kick	Jazz Kick 2	Jngl BD 2	Jngl BD 2	TR-808 Kick	TR-808 Kick	TR-808 Kick	TR-808 Kick
	8	---	808 BD	Room Kick 1	HipHop BD	HipHop BD	808 BD	808 BD	808 BD	808 BD
	9	---	TR-909 Kick	Room Kick 2	HipHop BD 2	HipHop BD 2	TR-909 Kick	TR-909 Kick	TR-909 Kick	TR-909 Kick
	10	---	Dance Kick 2	Power Kick1	85S1BDrum1B	85S1BDrum1R	Dance Kick 2	Dance Kick 2	Dance Kick 2	Dance Kick 2
	11	---	909 Comp BD	Power Kick2	NewJzKik	909 Comp BD	909 Comp BD	909 Comp BD	909 Comp BD	909 Comp BD
	12	---	TR-909 BD2	Elec Kick 2	NewRockKik	NewRockKik	TR-909 BD2	TR-909 BD2	TR-909 BD2	TR-909 BD2
	13	---	HipHop BD2	Elec Kick 1	CymbalRoll	CymbalRoll	HipHop BD2	HipHop BD2	HipHop BD2	HipHop BD2
	14	---	JungleBD Set	TR-808 Kick	NewWRCStMn	NewWRCStMn	JungleBD Set	JungleBD Set	JungleBD Set	JungleBD Set
	15	---	Techno BD1	TR-909 Kick	85RmSnare1B	85RmSnare1R	Techno BD1	Techno BD1	Techno BD1	Techno BD1
	16	---	Bounce	Dance Kick 2	85RmSnare2B	85RmSnare2R	Bounce	Bounce	Bounce	Bounce
	17	---	Voice One	Voice One	85S1Snare1B	85S1Snare1R	Voice One	Voice One	Voice One	Voice One
	18	---	Voice Two	Voice Two	85S1Snare2B	85S1Snare2R	Voice Two	Voice Two	Voice Two	Voice Two
	19	---	Voice Three	Voice Three	NewJzSn2	NewJzSn2	Voice Three	Voice Three	Voice Three	Voice Three
	20	---	Fat BD	---	NewJzSn1	NewJzSn1	---	909 BD	---	---
	21	---	Dance BD	---	NewR8B5n	NewR8B5n	---	909 BD 2	---	---
	22	---	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
	23	---	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
C1	24	---	Concert Svr	Concert Svr	Concert Svr	Concert Svr	Concert Svr	Concert Svr	Concert Svr	Concert Svr
	25	---	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
	26	---	Finger Snap	FingerSnaps2	FingerSnaps2	FingerSnaps2	Finger Snap	Finger Snap	FingerSnaps2	FingerSnaps2
	27	---	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q
	28	---	Slap	Slap	707 Claps	707 Claps	Slap	Slap	Slap	Slap
	29	---	ScratchPush	ScratchPush2	ScratchPush	ScratchPush2	Scratch Push2	Scratch Push2	Scratch Push2	Scratch Push2
	30	---	ScratchPull	ScratchPull2	ScratchPull	ScratchPull2	Scratch Pull2	Scratch Pull2	Scratch Pull2	Scratch Pull2
	31	---	Sticks	Sticks	909 HandClap	909 HandClap	Sticks	Sticks	Sticks	Sticks
	32	---	SquareClick	SquareClick	NewWRCStMn	NewWRCStMn	SquareClick	SquareClick	SquareClick	SquareClick
	33	---	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck
	34	---	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell
	35	---	85RmBDrum1B	909 BD	Power Kick2	NewRockKik	808 BD	Fat BD	CR78 BD 2	CR78 BD 2
	36	---	85RmBDrum2B	909 BD 2	Power Kick1	NewRockKik	TR-808 Kick	Dance BD	CR78 BD 1	TR-808 BD1
	37	---	Side Stick	House SD Rim	Side Stick	NewWRCStMn	808 Rimshot	Dance SD Rim	CR78 Rim	CR78 Rim
	38	---	85RmSnare2B	House SD	Dance Snare1	NewWRCStMn	808 Snare 1	Dance SD	CR78 SD 1	666160
	39	---	808lap	909 Claps	808lap	NewWRCStMn	808lap	Comp Claps 2	707 Claps	707 Claps
	40	---	85RmSnare1B	House SD	Power Snare1	NewWRCStMn	808lap	Rock SD Dry	CR78 SD 2	666260
	41	---	Room Tom 5	909 Tom	Rock Tom 4	NewWRCStMn	808 Tom 2	Synth Drum 2	78 TOM	606 TOM
	42	---	85RmCjHtB	TR-707 HtC	Close HtHat2	NewWRCStMn	CR-78 CHH	CR-78 chh	CR-78 chh	606 CH
	43	---	Room Tom 5	909 Tom	Rock Tom 4	NewWRCStMn	808 Tom 2	Synth Drum 2	78 TOM	606 TOM
	44	---	Pedal HtHat	CR-78 chh	Pedal HtHat2	NewWRCStMn	808 chh	CR-78 chh	606 CH	606 CH
	45	---	Room Tom 2	909 Tom	Rock Tom 4	NewWRCStMn	808 Tom 2	Synth Drum 2	78 TOM	606 TOM
	46	---	85RmOpenHtB	909 CH	Open HtHat2	NewWRCStMn	CR-78 oHh	CR-78 oHh	606 HtHat Op	606 HtHat Op
	47	---	Room Tom 2	909 Tom	Rock Tom 4	NewWRCStMn	808 Tom 2	Synth Drum 2	78 TOM	606 TOM
	48	---	Room Tom 2	909 Tom	Rock Tom 1	NewWRCStMn	808 Tom 2	Synth Drum 2	78 TOM	606 TOM
	49	---	85RmCrCym1B	909 Crash	Crash Cym.1	NewWRCStMn	808 Crash	808 Crash	808 Crash	808 Crash
	50	---	Room Tom 2	909 Tom	Rock Tom 1	NewWRCStMn	808 Tom 2	Synth Drum 2	78 TOM	606 TOM
	51	---	85RmRdCymB	909 Ride Cym	Ride Cymbal	NewWRCStMn	606 Ride Cym	606 Ride Cym	606 Ride Cym	606 Ride Cym
	52	---	ChinaCymbal	ReverseCymbal	ChinaCymbal	NewWRCStMn	ReverseCymbal	ChinaCymbal	ChinaCymbal	ChinaCymbal
	53	---	85RmRdCymB	Ride Bell	Ride Bell	NewWRCStMn	Ride Bell	Ride Bell	Ride Bell	Ride Bell
	54	---	Tambourine	Shake Tamb	Tambourine	CR78 Tmb	Shake Tamb	CR78 Tmb	CR78 Tmb	CR78 Tmb
	55	---	Splash Cym	Splash Cym	Splash Cym	NewWRCStMn	Splash Cym	Splash Cym	Splash Cym	Splash Cym
	56	---	Cowbell	808cowbe	Cowbell	ChaChaC8ell	Cowbell	CR78 Cow	CR78 Cow	CR78 Cow
	57	---	Crash Cym.2	909 Crash	Crash Cym.2	NewWRCStMn	909 Crash	Crash Cym.2	909 Crash	909 Crash
	58	---	Vibratlap	Vibratlap	Vibratlap	NewWRCStMn	Vibratlap	Vibratlap	Vibratlap	Vibratlap
	59	---	Ride Cymbal	Ride Cymbal	Ride Cymbal	IPopd1_51	Ride Cymbal	RideCym Edge	Ride Cymbal	RideCym Edge
C4	60	---	Bongo High	CR78 HiBongo	Bongo High	NewHiBongo	Bongo High	CR78 HiBongo	CR78 HiBongo	CR78 HiBongo
	61	---	Bongo Lo	CR78 LoBongo	Bongo Lo	NewLoBongo	Bongo Lo	CR78 LoBongo	CR78 LoBongo	CR78 LoBongo
	62	---	Mute H.Conga	808 Conga	Mute H.Conga	NewCongaSlp	Mute H.Conga	808 Conga	808 Conga	808 Conga
	63	---	Conga Hi Opn	808 Conga	Conga Hi Opn	NewCongaOp	Conga Hi Opn	808 Conga	808 Conga	808 Conga
	64	---	Conga Lo Opn	808 Conga	Conga Lo Opn	NewLoConga	Conga Lo Opn	808 Conga	808 Conga	808 Conga
	65	---	High Timbale	High Timbale	High Timbale	NewTimbHi	High Timbale	High Timbale	High Timbale	High Timbale
	66	---	Low Timbale	Low Timbale	Low Timbale	NewTimbLo	Low Timbale	Low Timbale	Low Timbale	Low Timbale
	67	---	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo
	68	---	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo
	69	---	Cabasa	Cabasa	Cabasa	NewShaker2	Cabasa	Cabasa	Cabasa	Cabasa
	70	---	Maracas	808marac	Maracas	NewShaker1	Maracas	CR78 Maracas	CR78 Maracas	CR78 Maracas
	71	---	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle
	72	---	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle
	73	---	Short Guiro	Short Guiro	NewQuide1	NewQuide1	Short Guiro	Short Guiro	Short Guiro	Short Guiro
	74	---	Long Guiro	CR78 Guiro	Long Guiro	NewQuide2	Long Guiro	CR78 Guiro	CR78 Guiro	CR78 Guiro
	75	---	Claves	808clav	Claves	NewClaves	Claves	CR78 Clv	CR78 Clv	CR78 Clv
	76	---	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
	77	---	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
	78	---	Mute Cuica	Hoo	Mute Cuica	Mute Cuica	Mute Cuica	Hoo	Hoo	Hoo
	79	---	Open Cuica	Hoo	Open Cuica	Open Cuica	Open Cuica	Hoo	Hoo	Hoo
	80	---	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	CR78 M.Beatz	CR78 M.Beatz	CR78 M.Beatz
	81	---	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	CR78 M.Beatz	CR78 M.Beatz	CR78 M.Beatz
	82	---	Shaker	626 Shaker	Shaker	Shaker	626 Shaker	626 Shaker	626 Shaker	626 Shaker
	83	---	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
	84	---	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
C5	85	---	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets
	86	---	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
	87	---	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo
	88	---	Applause 2	Applause 2	Crir	Crir	Small Club	Small Club	Small Club	Small Club
	89	---	606 SD 2	---	NewTmbHfM	NewTmbHfM	---	606 SD 2	---	---
	90	---	Dance SD	---	NewTmbLoFm	NewTmbLoFm	---	Techno SD	---	---
	91	---	Techno SD	---	NewTmbPHS	NewTmbPHS	---	House SD	---	---
	92	---	Rock SD Dry	---	NewShaker1	NewShaker1	---	Jngl SD	---	---
	93	---	HtHtOp SD 1	---	NewShaker2	NewShaker2	---	LoFi SD 1	---	---
	94	---	LoFi SD 1	---	HfHtOpMute	HfHtOpMute	---	LoFi SD 2	---	---
	95	---	85Rm BDrum1	LoFi SD 2	NewBngMute	NewBngMute	---	HipHop SD 1	---	---
C6	96	---	85Rm BDrum2	Jngl SD	CajonH	CajonH	---	HipHop SD 2	---	---

	PC: 30 (CC32: 4)	PC: 31 (CC32: 4)	PC: 33 (CC32: 4)	PC: 34 (CC32: 4)	PC: 41 (CC32: 4)	PC: 42 (CC32: 4)	PC: 43 (CC32: 4)	PC: 44 (CC32: 4)	PC: 49 (CC32: 4)	PC: 50 (CC32: 4)
	TR-707	TR-909	JAZZ	JAZZ L/R	BRUSH	BRUSH 2	BRUSH2L/R	V-JazzBs	DRUMSTR	ETHNIC
C-1	0	0	0	0	0	0	0	0	0	0
	0	0	0	0	0	0	0	0	0	0
	1	1	1	1	1	1	1	1	1	1
	2	2	2	2	2	2	2	2	2	2
	3	3	3	3	3	3	3	3	3	3
	4	4	4	4	4	4	4	4	4	4
	5	5	5	5	5	5	5	5	5	5
	6	6	6	6	6	6	6	6	6	6
	7	7	7	7	7	7	7	7	7	7
	8	8	8	8	8	8	8	8	8	8
	9	9	9	9	9	9	9	9	9	9
	10	10	10	10	10	10	10	10	10	10
	11	11	11	11	11	11	11	11	11	11
	12	12	12	12	12	12	12	12	12	12
	13	13	13	13	13	13	13	13	13	13
	14	14	14	14	14	14	14	14	14	14
	15	15	15	15	15	15	15	15	15	15
	16	16	16	16	16	16	16	16	16	16
	17	17	17	17	17	17	17	17	17	17
	18	18	18	18	18	18	18	18	18	18
	19	19	19	19	19	19	19	19	19	19
	20	20	20	20	20	20	20	20	20	20
	21	21	21	21	21	21	21	21	21	21
	22	22	22	22	22	22	22	22	22	22
	23	23	23	23	23	23	23	23	23	23
C1	24	24	24	24	24	24	24	24	24	24
	25	25	25	25	25	25	25	25	25	25
	26	26	26	26	26	26	26	26	26	26
	27	27	27	27	27	27	27	27	27	27
	28	28	28	28	28	28	28	28	28	28
	29	29	29	29	29	29	29	29	29	29
	30	30	30	30	30	30	30	30	30	30
	31	31	31	31	31	31	31	31	31	31
	32	32	32	32	32	32	32	32	32	32
	33	33	33	33	33	33	33	33	33	33
	34	34	34	34	34	34	34	34	34	34
	35	35	35	35	35	35	35	35	35	35
	36	36	36	36	36	36	36	36	36	36
C2	37	37	37	37	37	37	37	37	37	37
	38	38	38	38	38	38	38	38	38	38
	39	39	39	39	39	39	39	39	39	39
	40	40	40	40	40	40	40	40	40	40
	41	41	41	41	41	41	41	41	41	41
	42	42	42	42	42	42	42	42	42	42
	43	43	43	43	43	43	43	43	43	43
	44	44	44	44	44	44	44	44	44	44
	45	45	45	45	45	45	45	45	45	45
	46	46	46	46	46	46	46	46	46	46
	47	47	47	47	47	47	47	47	47	47
	48	48	48	48	48	48	48	48	48	48
C3	49	49	49	49	49	49	49	49	49	49
	50	50	50	50	50	50	50	50	50	50
	51	51	51	51	51	51	51	51	51	51
	52	52	52	52	52	52	52	52	52	52
	53	53	53	53	53	53	53	53	53	53
	54	54	54	54	54	54	54	54	54	54
	55	55	55	55	55	55	55	55	55	55
	56	56	56	56	56	56	56	56	56	56
	57	57	57	57	57	57	57	57	57	57
	58	58	58	58	58	58	58	58	58	58
	59	59	59	59	59	59	59	59	59	59
C4	60	60	60	60	60	60	60	60	60	60
	61	61	61	61	61	61	61	61	61	61
	62	62	62	62	62	62	62	62	62	62
	63	63	63	63	63	63	63	63	63	63
	64	64	64	64	64	64	64	64	64	64
	65	65	65	65	65	65	65	65	65	65
	66	66	66	66	66	66	66	66	66	66
	67	67	67	67	67	67	67	67	67	67
	68	68	68	68	68	68	68	68	68	68
	69	69	69	69	69	69	69	69	69	69
	70	70	70	70	70	70	70	70	70	70
	71	71	71	71	71	71	71	71	71	71
	72	72	72	72	72	72	72	72	72	72
	73	73	73	73	73	73	73	73	73	73
	74	74	74	74	74	74	74	74	74	74
	75	75	75	75	75	75	75	75	75	75
	76	76	76	76	76	76	76	76	76	76
	77	77	77	77	77	77	77	77	77	77
	78	78	78	78	78	78	78	78	78	78
	79	79	79	79	79	79	79	79	79	79
	80	80	80	80	80	80	80	80	80	80
	81	81	81	81	81	81	81	81	81	81
	82	82	82	82	82	82	82	82	82	82
	83	83	83	83	83	83	83	83	83	83
	84	84	84	84	84	84	84	84	84	84
C5	85	85	85	85	85	85	85	85	85	85
	86	86	86	86	86	86	86	86	86	86
	87	87	87	87	87	87	87	87	87	87
	88	88	88	88	88	88	88	88	88	88
	89	89	89	89	89	89	89	89	89	89
	90	90	90	90	90	90	90	90	90	90
	91	91	91	91	91	91	91	91	91	91
	92	92	92	92	92	92	92	92	92	92
	93	93	93	93	93	93	93	93	93	93
	94	94	94	94	94	94	94	94	94	94
	95	95	95	95	95	95	95	95	95	95
C7	96	96	96	96	96	96	96	96	96	96

REFERENCE

Drum Sets

	PC: 30 [CC32: 4] TR-707	PC: 31 [CC32: 4] TR-909	PC: 33 [CC32: 4] JAZZ	PC: 34 [CC32: 4] JAZZ L/R	PC: 41 [CC32: 4] BRUSH	PC: 42 [CC32: 4] BRUSH 2	PC: 43 [CC32: 4] BRUSHZLR	PC: 44 [CC32: 4] V-1zrBrs	PC: 49 [CC32: 4] ORCHESTRA	PC: 50 [CC32: 4] ETHNIC
(C)	96	(-)	(-)	(85z Bsdrum2)	(-)	(-)	(85Br Bsdrum2)	(CajonHi)	(-)	(Cabasa Down)
	97	Techno Hit	Techno Hit	85z CrsCym1	--	--	85Br CrsCym1	CajonHiFlm	Applause 2	Claves
	98	Philly Hit	Philly Hit	85z Snare1	--	--	85Br Snare1	CajonLto	Small Club	Woodblock
	99	Shock Wave	Shock Wave	85Br Snare2	85z RdCym	--	85Br Snare2	85Br RdCym	CajonLoFlm	Woodblock
	100	Lo Fi Rave	Lo Fi Rave	Brush Swirl	85z Snare2	Brush Swirl	85Br Snare2	85Br Snare2	FimcoHCP1	Timpani
	101	Bam Hit	Bam Hit	Brush Tap	85z Tom1b	Brush Tap	85Br Tom3	FimcoHCP1	Timpani	--
	102	Bim Hit	Bim Hit	Brush Slap1	85z ClsHat	Brush Slap1	85Br ClsHat	BongoCowBell	Timpani	--
	103	TapeRewind	TapeRewind	Brush Slap2	85z Tom13	Brush Slap2	85Br Tom2	AlHey	Timpani	--
	104	Phono Noise	Phono Noise	Brush Slap	85z RdBell	Brush Slap	85Br RdBell	MamboCowBell	Timpani	--
	105	Dance Snare1	Dance Snare1	Brush Swirl	85z Tom12	Brush Swirl	85Br Tom1	MesaFVox2	Timpani	--
	106	Power Snare2	Power Snare2	Brush Swirl	85z OpenHat	Brush Swirl	85Br OpenHat	AlFoots	Timpani	--
	107	Elec Snare 1	Elec Snare 1	Long Swirl	85zBsdrum1P	Long Swirl	85BrBsdrum1P	MesaFVox1	Timpani	--
	108	Dance Snare2	Dance Snare2	Jazz Snare 1	85zBsdrum2P	Jazz Snare 1	85BrBsdrum2P	MesaFVox1	Timpani	--
	109	Elec Snare 2	Elec Snare 2	Jazz Snare 2	85zCrsCym1P	Jazz Snare 2	85BrCrsCym1P	YodelFVox1	Timpani	--
	110	Elec Snare 3	Elec Snare 3	Std.1 Snare1	85z Snare1P	Std.1 Snare1	85Br Snare1P	MesaFVox2	Timpani	--
	111	66m260	66m260	Std.2 Snare1	85z RdCym P	Std.2 Snare1	85Br RdCym P	YodelFVox1	Timpani	--
	112	TR-707 SD	TR-707 SD	Std.2 Snare2	85z Snare2P	Std.2 Snare2	85Br Snare2P	MesaFVox3	Timpani	--
	113	808 Snare 1	808 Snare 1	Std.2 Snare2	85z Tom16 P	Std.2 Snare2	85Br Tom3 P	FimcoFVox1	Timpani	--
	114	808 Snare 2	808 Snare 2	Tight Snare	85z ClsHat P	Tight Snare	85Br ClsHat P	YodelFVox2	--	--
	115	TR-808 SD2	TR-808 SD2	Standard SH1	85z Tom13 P	Standard SH1	85Br Tom2 P	FimcoFVox2	--	--
	116	909 Snare 1	909 Snare 1	LD Snare M	LD Snare M	LD Snare M	85Br RdBellP	NewWhistle1	--	--
	117	909 Snare 2	909 Snare 2	LD Snare C	85z Tom12 P	LD Snare C	85Br Tom1 P	FimcoFVox3	--	--
	118	909 SD 1	909 SD 1	Room Snare 1	85zOpenHatP	Room Snare 1	85BrOpenHatP	NewWhistle2	--	--
	119	909 SD 2	909 SD 2	Room Snare 2	Room Snare 2	Room Snare 2	--	FimcoMVoxx1	--	--
	120	TR-909 SD2	TR-909 SD2	Dance Snare1	Dance Snare1	Dance Snare1	--	FimcoMVoxx2	--	--
	121	Rap Snare	Rap Snare	Power Snare1	Power Snare1	Power Snare1	--	BratzFVox1	--	--
	122	JungleSD1	JungleSD1	Rev Snare	Rev Snare	Rev Snare	--	FimcoMVoxx3	--	--
	123	House SD	House SD	Power Snare2	Power Snare2	Power Snare2	--	BratzFVox2	--	--
	124	House Share	House Share	Elec Snare 1	Elec Snare 1	Elec Snare 1	--	BratzFVox3	--	--
	125	House SD	House SD	Dance Snare2	Dance Snare2	Dance Snare2	--	AFabhh	--	--
	126	Voice Tah	Voice Tah	Elec Snare 2	Elec Snare 2	Elec Snare 2	--	p33137v	--	--
	127	Noise Slap	Noise Slap	Elec Snare 3	Elec Snare 3	Elec Snare 3	--	p33168v	--	--

	PC: 51 [CC32: 4] KICK&SHR	PC: 52 [CC32: 4] KICK&SNZ	PC: 53 [CC32: 4] ASIA	PC: 54 [CC32: 4] CYMB&CLAP	PC: 55 [CC32: 4] GAMELAN 1	PC: 56 [CC32: 4] GAMELAN 2	PC: 57 [CC32: 4] SRX	PC: 58 [CC32: 4] RHYTHMFX	PC: 59 [CC32: 4] RHYTHMFX2	PC: 60 [CC32: 4] RHYTHMFX3
(C)	96	(HipHop SD2)	(HipHop SD2)	(-)	(-)	(-)	(Perc. Bang)	(-)	(-)	(R Boocoon)
	97	JungleSD1	JungleSD1	--	--	--	--	--	--	R Bounce
	98	Jungle SD2	Jungle SD2	--	--	--	--	--	--	R CD Tray
	99	Slap	Slap	--	--	--	--	--	--	R Drill
	100	MG_Blip	MG_Blip	--	--	--	--	--	--	R Glass Stir
	101	House SD	House SD	--	--	--	--	--	--	R Ice Ring
	102	CR78 SD 1	CR78 SD 1	--	--	--	--	--	--	R Kinapasm
	103	CR78 SD 2	CR78 SD 2	--	--	--	--	--	--	R Scratch 4
	104	66m160	66m160	--	--	--	--	--	--	R Scratch 5
	105	66m260	66m260	--	--	--	--	--	--	R Scratch 6
	106	TR-707 SD	TR-707 SD	--	--	--	--	--	--	R Scratch 7
	107	TR-707 SD 2	TR-707 SD 2	--	--	--	--	--	--	R Seal
	108	TR-707 SD 3	TR-707 SD 3	--	--	--	--	--	--	R Stabl 1
	109	TR-808 SD2	TR-808 SD2	--	--	--	--	--	--	R Stabl 2
	110	909 SD 1	909 SD 1	--	--	--	--	--	--	R Swrd Boom!
	111	TR-909 SD2	TR-909 SD2	--	--	--	--	--	--	R Swrd Cross
	112	--	--	--	--	--	--	--	--	R Thrill Hit
	113	--	--	--	--	--	--	--	--	R Audio Sw
	114	--	--	--	--	--	--	--	--	R Typing 1
	115	--	--	--	--	--	--	--	--	R Typing 2
	116	--	--	--	--	--	--	--	--	R Typing 3
	117	--	--	--	--	--	--	--	--	R Typing 4
	118	--	--	--	--	--	--	--	--	R Typing 5
	119	--	--	--	--	--	--	--	--	R Typing 6
	120	--	--	--	--	--	--	--	--	--
	121	--	--	--	--	--	--	--	--	--
	122	--	--	--	--	--	--	--	--	--
	123	--	--	--	--	--	--	--	--	--
	124	--	--	--	--	--	--	--	--	--
	125	--	--	--	--	--	--	--	--	--
	126	--	--	--	--	--	--	--	--	--
	127	--	--	--	--	--	--	--	--	--

	PC-51 (CC32: 4)	PC-52 (CC32: 4)	PC-53 (CC32: 4)	PC-54 (CC32: 4)	PC-55 (CC32: 4)	PC-56 (CC32: 4)	PC-57 (CC32: 4)	PC-58 (CC32: 4)	PC-59 (CC32: 4)	PC-60 (CC32: 4)	
	KICK&SHR	KICK&SN2	ASIA	CYMB&CLAP	GAMELAN 1	GAMELAN 2	SFX	RHYTHMFX	RHYTHMFX2	RHYTHMFX3	
C-1	0	...	...	...	...	...	...	...	...	...	
	2	...	...	...	...	...	...	...	...	...	
	4	...	...	...	...	...	...	...	...	...	
	7	...	...	...	...	...	...	...	...	...	
	9	...	...	...	...	...	...	...	...	...	
	11	...	...	...	...	...	...	...	...	...	
C2	12	...	...	...	...	...	...	...	...	...	
	14	...	...	...	...	...	...	...	...	...	
	16	...	...	...	...	...	...	...	...	...	
	17	...	...	...	...	...	...	...	...	R Bs Mute HZ	
	19	...	...	...	...	...	...	...	...	R Bs StQuar	
	21	...	...	...	...	...	...	...	...	R Bs Atk HZ	
	23	...	...	...	...	...	...	...	...	R CnGtCutUp	
	24	...	...	...	...	...	...	...	...	R CnGtCutDn	
	26	CR78 BD 1	CR78 BD 1	Gamelan Gong	...	...	...	...	MC 500 Beep	R CnGtMIDn	
	28	TR-606 BD1	TR-606 BD1	Gamelan Gong	...	...	...	...	MC 500 Beep	R CnGtMIDn	
	29	TR-707 BD	TR-707 BD	Gamelan Gong	...	...	...	...	...	R DaGtCutUp	
	31	808 BD	808 BD	Gamelan Gong	...	...	...	...	...	R DaGtCutDn	
	33	909 Comp BD	909 Comp BD	Gamelan Gong	...	...	...	...	...	R DaGtStrk	
	35	TR-909 BD2	TR-909 BD2	Gamelan Gong	...	...	...	...	...	R DaGtMute	
	37	HipHop BD2	HipHop BD2	Gamelan Gong	rev.hvhh	...	...	...	...	R SGrSdM1	
	39	HipHop BD1	HipHop BD1	Gamelan Gong	Rev. LVCHH 1	...	...	...	...	R SGrSdM2	
	41	Jungle BD2	Jungle BD2	Gamelan Gong	Rev. LVCHH 2	...	...	...	...	R SGrSdM3	
	43	JungleBD Set	JungleBD Set	Gender	Jungle HH	...	...	...	...	R SGrSdM4	
C3	45	Techno BD2	Techno BD2	Gender	Close HHat	Kendang/Wadon	Kendang/Wadon	Dist. CutNoise	Rev Kick 1	rev.707bd	R SGrSdM2
	47	Techno BD1	Techno BD1	Gender	Jazz Clsd HH	Kendang/Wadon	Kendang/Wadon	Bar. Slide	Rev ConB0	rev.909bd2	R Tbone HZ
	49	Mix Kick	Mix Kick	Gender	Rozm CH	Babarangan	Babarangan	PcL Strape	Rev PowerK1	rev.hphp_bd1	R TpeL HZ
	51	Standard KK1	Standard KK1	Gender	Close HHat1	Pelenggan	Pelenggan	High-O	Rev Elec.K1	rev.glt_bd2	R St BdDrum1
	53	Std.1 Kick1	855r BdDrum1	Bonang	Close HHat2	Kelontuk	Kelontuk	Slap	Rev Snare 1	rev.tch_bd2	R St BdDrum2
	55	Std.1 Kick2	855r BdDrum2	Bonang	TR-707 HH-c	Kelontuk Mt.	Kelontuk Mt.	ScratchPush	Rev Snare 2	rev.566m2	R Bm BdDrum1
	57	Std.2 Kick1	858r BdDrum1	Bonang	808 CH	Kelontuk Sid	Kelontuk Sid	ScratchPull	Rev Std1SD1	rev.c77bd1	R Bm BdDrum2
	59	Std.2 Kick2	858r BdDrum2	Bonang	808_chh	Gong Wadon	Gong Wadon	Sicks	Rev TghtSD	rev.c77bd2	R Iz BdDrum1
	61	Kick 1	85zr BdDrum1	Bonang	TR-808 CHH	Gong Lanang	Gong Lanang	SquareClick	Rev DanceSD	rev.glt_bd2	R Iz BdDrum2
	63	Kick 2	85zr BdDrum2	RAMA Cymbal	CR-78 chh	Ceng Ceng	Ceng Ceng	Mtrm.Click	Rev 808SD	rev.tch_bd2	R Bz BdDrum1
	65	SOX Kick	HipHop BD 2	RAMA Cymbal	G5 Pedal HH	Kopyak Op	Kopyak Op	Mtrm. Bell	Rev Tom 1	rev.707bd	R Bz BdDrum2
	67	Jazz Kick 1	HipHop BD	Sagar R	Pedal HHat2	Kajar	Kajar	Gt. FretNoise	Rev Tom 2	rev.606m1	R HipHop BD2
C4	69	Jazz Kick 2	Concert BD M1	Sagar L-c	Pedal HHat2	Kajar	Kajar	Gt. CutNoise	Rev Strcks	rev.909bd1	R HipHop BD
	71	Concert BD	Concert BD	Jaw Harp Wow	Half OpenHH2	Kempur	Kempur	Gt. CutNoise	Rev Slap	rev.hphp_bd2	R Ingtl BD
	73	Room Kick 1	858m BdDrum1	Wadaiko	Half OpenHH2	Jegogan	Jegogan	String Slap	ReverseCymb1	rev.glt_bd2	R Ingtl BD 2
	75	Room Kick 2	858m BdDrum2	Wadaiko Rim	Open Hi Hat	Jegogan33dw	Jegogan40up	Pl.KeyClick	Rev Cymbal2	Rev House SD	R 808 BD
	77	Power Kick 1	Jngl BD	Taiko	Jazz Open HH	Jegogan33dw	Jegogan20dw	Laughing	Rev Open HH	Rev LVCHH 1	R 909 BD 2
	79	Power Kick 2	Jngl BD 2	Shimedaiko	RH OH2	Jegogan33dw	Jegogan20up	Screaming	Rev RideCym	rev.606hcl	R 909 BD 2
	81	Elec Kick 1	Jngl BD Roll	Atarigane	Open HHat2	Jegogan	Jegogan40up	Punch	Rev CR-78OHH	rev.c77chh	R Fat BD
	83	Elec Kick 2	Fat BD	Hyoshigi	909 OH	Jublag	Jublag	Heart Beat	Rev Clsd HH	rev.808hh	R Dance BD
	85	Elec. Kick	Dance BD	Ohkawa	TR-707 OHH	Jublag33up	Jublag40up	Footsteps	Rev BendGong	rev.707hh	R St Snare2
	87	TR-808 Kick	808 BD	H Kotsumami	606 HHat Op	Jublag33dw	Jublag20dw	Footsteps	Rev Belltree	rev.344mb2	R St Snare1
	89	TR-909 Kick	909 BD	L Kotsumami	808_chh	Jublag33dw	Jublag20up	Applause	Rev Guaro	rev.344mb3	R Bm Snare2
	91	Dance Kick 2	909 BD 2	Yuko Dude	TR-808 OHH	Jublag	Jublag40up	Creaking	Rev Bendr	rev.808bth	R Bm Snare1
C5	93	Std.1 Snare1	855r Snare2	Buk. f	CR-78 ohh	Penyarah33dw	Penyarah20dw	Door	Rev GunShot	rev.707ohh	R Iz Snare2
	95	Std.1 Snare2	855r Snare1	Buk. r	Crash Cym.1	Penyarah	Penyarah40up	Scratch	Rev Scratch	rev.vvohh	R Iz Snare1
	97	Std.2 Snare1	855r Snare1	Geengari_p	Crash Cym.2	Penyarah	Penyarah	Wind Chimes	Rev Lasergun	rev.666cym	R Bz Snare2
	99	Std.2 Snare2	855r Snare2	Geengari_m	G5 Crash	Penyarah33up	Penyarah40up	Car Engine	Click	Rev. HynLuo	R Bz Snare1
	101	Tight Snare	Tight Snare	Geengari_f	Brush Crash	Penyarah20dw	Penyarah20dw	Car Stop	Tekno Thip	rev.707fs	R Lofi SD 1
	103	Concert Snr	Concert Snr	Geengari_m	Hard Crash	Penyarah33dw	Penyarah20up	Car-Pass	Pop Drop	Voice One	R Lofi SD 2
	105	Jazz Snare 1	85zr Snare1	Geengari 5	909 Crash	Penyarah	Penyarah40up	Car-Crash	Wood Slap	rev.one	R HipHop SD1
	107	Jazz Snare 2	85zr Snare2	Jang-Gu_c	808 Crash	Pemaded33up	Pemaded40up	Siren	Dist. Kick	voice Two	R HipHop SD2
	109	Room Snare 1	858m Snare1	Jang-Gu_k	Crash Mute 1	Pemaded33dw	Pemaded20dw	Train	Syn.Drops	rev.two	R House SD
	111	Room Snare 2	858m Snare2	Jang-Gu_r	Crash Mute 2	Pemaded33dw	Pemaded20up	Jetplane	Rev.H-Q	voice Three	R Ingtl SD
	113	Dance Snare1	Lofi SD 1	Jng. p	ReverseCymb1	Pemaded20up	Pemaded20up	Helicopter	ShrtWhistle	rev.three	R 606 SD 2
	115	Power Snare1	Lofi SD 2	Jng. f	Rev.Cymbal2	Pemaded	Pemaded	Starship	Ice Block	voice Tah	R Techno SD
	117	Rev Snare	Rev Snare	Jng. m	Reverse Cym.	Pemaded33up	Pemaded40up	Gun Shot	Digit Tambrn.	rev.tah	R Dance SD
C6	119	Power Snare2	Lofi SD Rim	Asian Gong 1	rev.tta_crm	Pemaded33dw	Pemaded20dw	Machine Gun	Alias	voice 1	R RockSD Dry
	121	Elec Snare 1	Big Gong	Crash Cym.1	Pemaded33dw	Pemaded20up	Pemaded20up	Lasergun	Mod.Bell	voice Au	R Lofi SD Rim
	123	Dance Snare2	HipHop SD 1	Small Gong	Splash Cym	Pemaded	Pemaded20up	Explosion	Tambourine	voice Whey	R 909 SD Rim
	125	Elek Snare 2	HipHop SD 2	Fai Ban	Ride Bell	Pemaded33up	Pemaded33up	Dog	Metalic Perc	Frog Vpore	R Ingtl SD Rim
	127	House Snare	Dance SD	Ban. Gu	Brush RideBell	Reyong33dw	Reyong20dw	HorseGallop	Velo FX Noiz	rev.pyooh	R DanceSDRim
	129	Elek. Snare	606 SD 2	langudai	Ride Cymbal	Reyong33dw	Reyong20up	Bird	St.HoiseClap	Douby	R HouseSDRim
	131	Elek Snare 3	Techno SD	lamm60	Ride Cymbal	Reyong	Reyong20up	Rain	Swish	rev.douby	R Bsh Tom1
	133	808 Snare 1	House SD	Bend Gong L	Brush Ride	Reyong	Reyong	Thunder	Noise Slap	Baert	R Bsh Tom2
	135	808 Snare 2	Rock SD Dry	Bend Gong	Ride Cym RH	Reyong33up	Reyong40up	Wind	voice 1	Baert	R Bsh Tom3
	137	909 Snare 1	Jngl SD	Huyin Luo L	Ride Cym RL	Reyong33dw	Reyong20dw	Seashore	voice Au	Bounce	R 606 Tom
	139	909 Snare 2	Jngl SD Roll	hyn60	Ride Cym RL	Reyong33dw	Reyong20up	Stream	Hoo	rev.bounce	R Ingtl Crsh
C7	141	Brush Swirl	Brush Swirl	Huyin Luo Mt	RideCym Edge	Reyong	Reyong40up	Bubble	Tape Stop 1	Dist Knock	R St Clshat
	143	Brush Tap	Brush Tap	Hu yin Luo H	RideCym Edge	Reyong	Reyong40up	Kitty	Tape Stop 2	ytwm3.ttp	R Rev Clshat
	145	Brush Slap1	858r Snare1	Hymlo mute	RideCym Edge	Reyong33up	Reyong40up	Bird 2	xxx	xxx	R Iz Clshat
	147	Brush Slap2	858r Snare2	naoob0	606 Ride Cym	Reyong33dw	Reyong20dw	Growl	Space Birds	Noise Attack	R Bz Clshat
	149	Brush Slap	Brush Slap	saob06	TR808 Ride	Reyong33dw	Reyong20up	Applause 2	FlyingMonstr	SpaceWorms	R 707 Claps
	151	Brush Swirl1	Brush Swirl	Dholak 1	ChinaCymbal	---	---	Telephone 1	---	---	R 909 Claps
	153	Brush Swirl2	Brush Swirl	Dholak 2	ChinaCymbal	---	---	Telephone 2	---	Calculang	R R8R Claps1
	155	Long Swirl	Long Swirl	---	Hand Clap	---	---	Small Club	---	Small FOSaw	R HipHopClap
	157	Standard SH1	Standard SH1	---	Hand clap?	---	---	Small Club 2	---	---	R CompClaps2
	159	LD Snare M	LD Snare M	---	808clap	---	---	ApplauseWave	---	---	R Shaker 2
	161	LD Snare C	LD Snare C	---	909 HandClap	---	---	Eruption	---	---	R IngtlShaker
	163	Rap Snare	Rap Snare	---	HC2 Claps 2	---	---	Big Shot	---	---	R Clap Hit
	165	HipHop SD2	HipHop SD2	---	707 Claps	---	---	Perc. Bang	---	---	R Booteen

REFERENCE

Drum Sets

	PC: 64 [CC32: 4] SFX 2	PC: 63 [CC32: 4] CYMBLAZ	PC: 64 [CC32: 4] V-VonDrm	PC: 128 [CC32: 4] GM-64/32L	PC: 9 [CC32: 122] GM2STDR	PC: 9 [CC32: 122] GM2 ROOM	PC: 17 [CC32: 122] GM2POWER	PC: 25 [CC32: 122] GM2ELECT	PC: 24 [CC32: 122] GM2ANALG	PC: 33 [CC32: 122] GM2 JAZZ
C-1	0			HipHop BD1						
	1			Jazz Kick 1						
	2			p1502v						
	3			85RmBdDrum1B						
	4			85RmBdDrum2B						
	5			909 BD						
	6			909 BD 2						
	7			Ingl BD 2						
	8			HipHop BD						
	9			HipHop BD 2						
	10			85SbDrum1B						
C0	12			NewJkKik						
	13			NewRockKik						
	14			CymbalRoll						
	15			NewRLCS11Mn						
	16			85RmSnare1B						
	17			85RmSnare2B						
	18			85SfSnare1B						
	19			85SfSnare2B						
	20			NewJ25m7						
	21			NewJ25m1						
	22			NewR85Sn						
	23			NewRock15/1mm						
C1	24			IPop5138mm						
	25			IPop5139mm						
	26			IPop5138mm						
	27			FingerSnaps2	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q
	28			707 Claps	Slap	Slap	Slap	Slap	Slap	Slap
	29			BIRclap	ScratchPush	ScratchPush	ScratchPush	ScratchPush2	ScratchPush2	ScratchPush
	30			Hand clap	ScratchPull	ScratchPull	ScratchPull	Scratch Pull2	Scratch Pull2	ScratchPull
	31			909 HandClap	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks
	32			A.Bs.TouchHz	Rev. LVCHH 2	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick
	33			A.Bs.AttackHz	Rev. LVCHH 2	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click
	34			DstCT MuteHz	Rev. LVCHH 2	Mtrnm. Bell	Mtrnm. Bell	Mtrnm. Bell	Mtrnm. Bell	Mtrnm. Bell
	35			51GL.SiHtz1	Rev. LVCHH 2	p5006v	Kick 1	85S1 BdDrum1	85Rm BdDrum1	Power Kick2
	36			51GL.SiHtz2	Close HiHat2	p32079v	Kick 1	85S1 BdDrum2	85Rm BdDrum2	Power Kick1
	37			51GL.SiHtz3	Jazz Cld.HH	p33146v	Side Stick	Side Stick	Side Stick	Side Stick
	38			51GL.SiHtz4	Close HiHat2	p32011v	Fat Snare	85S1 Snare2	B2Rm Snare2	Dance Snare1
	39			Gt.StrokeHz1	Romn Chh	p47001v	Hand Clap	909 HandClap	B0Bclap	B0Bclap
	40			Gt.StrokeHz2	TR-707 HH c	p33137v	Elec Snare	85S1 Snare1	Power Snare1	Elec Snare2
	41			Gt.StrokeHz3	606 CH	p33168v	Tom	Real Tom 6	Room Tom 5	Rock Tom 4
	42			Gt.StrokeHz4	TR-808 CHH	p33102v	Close HiHat	Close HiHat2	Romn Chh	Close HiHat2
	43			Gt.StrokeHz5	CR-78 cth	p24001v	Tom	Real Tom 6	Room Tom 5	Rock Tom 4
	44			Open CD Tray	GS Pedal HH	p23014c	Open HiHat2	Pedal HiHat2	Pedal HiHat2	Synth Drum 2
	45			Audio Switch	Pedal HiHat	p33157v	Tom	Real Tom 4	Room Tom 2	Rock Tom 4
	46			Key Typing 1	Open HiHat2	p33019v	Open Hi Hat	Open HiHat2	R8 Ohh2	Open HiHat2
	47			Key Typing 2	Half OpenHH1	p33164v	Tom	Real Tom 4	Room Tom 2	Rock Tom 4
	48			Key Typing 3	Half OpenHH2	p33159v	Tom	Real Tom 1	Room Tom 2	Rock Tom 1
	49			Key Typing 4	Open HiHat2	p33029v	GS Crash	Crash Cym.1	Crash Cym.1	Crash Cym.1
	50			Key Typing 5	Open HiHat2	p33158v	Tom	Real Tom 1	Room Tom 2	Rock Tom 1
	51			Key Typing 6	Open HiHat2	p43002z	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal
	52			BabyLaughing	Jazz Open HH	cym013v	ChinaCymbal	ChinaCymbal	ChinaCymbal	ReverseCymbal
	53			Clap Hit	909 OH	p45002v	Ride Bell	Ride Bell	Ride Bell	Ride Bell
	54			Stabl 1	TR-707 OHH	p36017v	Tambourine	Tambourine	Tambourine	CR78 Tmb
	55			Stabl 2	606 HHat Op	p34109v	Splash Cym	Splash Cym	Splash Cym	Splash Cym
	56			Bounce Hit	TR-808 OHH	p36019v	Cowbell	Cowbell	Cowbell	808cwb
	57			Bowteen	CR-78 cth	p44001v	Crash Cym.2	Crash Cym.2	Crash Cym.2	Crash Cym.2
	58			Glas & Glam	Crash Cym.1	p36009v	Vibraslap	Vibraslap	Vibraslap	Vibraslap
	59			Ice Ring	GS Crash	AfAahh	Ride Cymbal	Ride Cymbal	Ride Cymbal	RideCym Edge
C4	60			Crack Bottle	Hard Crash	NewHiBongo	High Bongo	Bongo High	Bongo High	Bongo High
	61			Pour Bottle	Brush Crash	NewLoBongo	Low Bongo	Bongo Lo	Bongo Lo	CR78 LoBongo
	62			Soda	Hard Crash	NewCongaSlp	Mute Conga	Mute H.Conga	Mute H.Conga	Mute H.Conga
	63			Car Engine 2	909 Crash	NewCongaOp	Conga	Conga Hi Opn	Conga Hi Opn	Conga Lo Opn
	64			Car Horn	Ingl Crash	NewLoConga	Conga	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn
	65			R.Crosing	808 Crash	NewTmbLo	Timbales	High Timbale	High Timbale	High Timbale
	66			SL 1	Crash Mute 2	NewTmbLo	Timbales	Low Timbale	Low Timbale	Low Timbale
	67			SL 2	Crash Mute 1	Agogo	Agogo	Agogo	Agogo	Agogo
	68			Over Blow	Crash Mute 2	Agogo	Agogo	Agogo	Agogo	Agogo
	69			Sword Boom1	Crash Mute 2	NewShaker2	Cabasa	Cabasa	Cabasa	Cabasa
	70			Sword Cross	Crash Mute 1	NewShaker1	Maracas	Maracas	Maracas	808marac
	71			Industry Hit	Crash Mute 2	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle
C5	72			Drill Hit	rev_tra_rsm	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle
	73			Compressor	rev_tra_rsm	NewQuide1	Short Guiro	Short Guiro	Short Guiro	Short Guiro
	74			Thrill Hit	Reverse Cym	NewQuide2	Long Guiro	Long Guiro	Long Guiro	Long Guiro
	75			Explosion 7	rev_tra_rsm	NewClaves	Claves	Claves	Claves	808clav
	76			Seal	Splash Cym	Woodblock	Laughing	Woodblock	Woodblock	Woodblock
	77			Fancy Animal	Ride Bell	Woodblock	Screaming	Woodblock	Woodblock	Woodblock
	78			Cricket	Ride Bell	Mute Cuica	Punch	Mute Cuica	Mute Cuica	Mute Cuica
	79			Baert	Ride Bell	Open Cuica	Heart Beat	Open Cuica	Open Cuica	Open Cuica
	80			Frog Vpoc	Brush RideB	MuteTriangl	Footsteps	MuteTriangl	MuteTriangl	MuteTriangl
	81			Wind 2	Ride Cymbal	OpenTriangl	Footsteps	OpenTriangl	OpenTriangl	OpenTriangl
	82			Scratch 3	Ride Cymbal	Shaker	Applause	Shaker	Shaker	626 Shaker
	83			Scratch 4	Ride Cymbal	Jingle Bell	Creaking	Jingle Bell	Jingle Bell	Jingle Bell
C6	84			Scratch 5	Brush Ride	Bell Tree	Door	Bell Tree	Bell Tree	Bell Tree
	85			Scratch 6	606 Ride Cym	Castanets	Scratch	Castanets	Castanets	Castanets
	86			Scratch 7	TR808 Ride	Mute Surdo	Wind Chimes	Mute Surdo	Mute Surdo	Mute Surdo
	87			Noise Attack	ChinaCymbal	Open Surdo	Car-Engine	Open Surdo	Open Surdo	Open Surdo
	88			Bounce	China Cym2	CRir	Car-Stop	Open Surdo	Open Surdo	Open Surdo
	89			Dist Knock	Hand clap2	NewTmbLofm	Car-Pass	Open Surdo	Open Surdo	Open Surdo
	90			tax	HC2 Claps 2	NewTmbLofm	Car-Crash	Open Surdo	Open Surdo	Open Surdo
	91			808clap	HC2 Claps 2	NewTmbLofm	Car-Crash	Open Surdo	Open Surdo	Open Surdo
	92			808clap	HC2 Claps 2	NewTmbLofm	Car-Crash	Open Surdo	Open Surdo	Open Surdo
	93			808clap	HC2 Claps 2	NewTmbLofm	Car-Crash	Open Surdo	Open Surdo	Open Surdo
	94			808clap	HC2 Claps 2	NewTmbLofm	Car-Crash	Open Surdo	Open Surdo	Open Surdo
	95			808clap	HC2 Claps 2	NewTmbLofm	Car-Crash	Open Surdo	Open Surdo	Open Surdo
C7	96			707 Claps	CapnHi	Gun Shot				

(CC32=122 only via MIDI)



	PC 61 [CC32: 4] SFX 2	PC 67 [CC32: 4] CYM8CLA2	PC 64 [CC32: 4] V-VoxDrum	PC 128 [CC32: 4] CM-44/32L	PC 129 [CC32: 122] GM2STDR	PC 130 [CC32: 122] GM2 ROOM	PC 131 [CC32: 122] GM2POWER	PC 25 [CC32: 122] GM2ELECT	PC 26 [CC32: 122] GM2ANALG	PC 23 [CC32: 122] GM2 JAZZ
(C7) 96	(--)	(--)	(CajonH)	(Gun Shot)	(--)	(--)	(--)	(--)	(--)	(--)
97	...	...	CajonHFlm	Machine Gun	...	...	...	...	...	...
98	...	...	CajonLo	LaserGun	...	...	...	...	...	...
99	...	...	CajonLoFlm	Explosion	...	...	...	...	...	...
100	...	...	FimcooClip1	Dog	...	...	...	...	...	...
101	...	...	FimcooClip1	HorseGallop	...	...	...	...	...	...
102	...	...	EongoCowBell	Bird	...	...	...	...	...	...
103	...	...	AlHey	Rain	...	...	...	...	...	...
104	...	...	MamboCowBell	Thunder	...	...	...	...	...	...
105	...	...	MexFVox2	Wind	...	...	...	...	...	...
106	...	...	AlFrost	Seahore	...	...	...	...	...	...
107	...	...	MexFVox1	Stream	...	...	...	...	...	...
108	...	...	MexFVox1	Bubble	...	...	...	...	...	...
109	...	...	YodelVox1	...	...	...	...	...	...	...
110	...	...	MexMVoX2	...	...	...	...	...	...	...
111	...	...	YodelMVoX1	...	...	...	...	...	...	...
112	...	...	MexMVoX3	...	...	...	...	...	...	...
113	...	...	FimcooVox1	...	...	...	...	...	...	...
114	...	...	YodelVox2	...	...	...	...	...	...	...
115	...	...	FimcooVox2	...	...	...	...	...	...	...
116	...	...	NewWhistle1	...	...	...	...	...	...	...
117	...	...	FimcooVox3	...	...	...	...	...	...	...
118	...	...	NewWhistle2	...	...	...	...	...	...	...
119	...	...	FimcooMVoX1	...	...	...	...	...	...	...
120	...	...	FimcooMVoX2	...	...	...	...	...	...	...
121	...	...	BrazilVox1	...	...	...	...	...	...	...
122	...	...	FimcooMVoX3	...	...	...	...	...	...	...
123	...	...	BrazilVox2	...	...	...	...	...	...	...
124	...	...	BrazilVox3	...	...	...	...	...	...	...
125	...	...	AlAahhh	...	...	...	...	...	...	...
126	...	...	p33137r	...	...	...	...	...	...	...
127	...	...	p33168r	...	...	...	...	...	...	...

(CC32=122 only via MIDI)  
(CC32= 119 only via MIDI)

REFERENCE

Drum Sets

	PG 21 (CC32=122)	PG 24 (CC32=124)	PG 27 (CC32=127)	PG 31 (CC32=131)	PG 33 (CC32=133)	PG 9 (CC32=119)	PG 17 (CC32=119)	PG 23 (CC32=119)	PG 26 (CC32=119)	PG 33 (CC32=119)
	GM2 BRUSH	GM2ORCHS	GM2 SFX	stndrkt	stndrkt2	room kit	rock kit	electrok	analogkt	jazz kit
C-1	0	...	...	...	...	...	...	...	...	...
	2	...	...	...	...	...	...	...	...	...
	4	...	...	...	...	...	...	...	...	...
	5	...	...	...	...	...	...	...	...	...
	7	...	...	...	...	...	...	...	...	...
	9	...	...	...	...	...	...	...	...	...
	11	...	...	...	...	...	...	...	...	...
C0	12	...	...	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
	14	...	...	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo
	16	...	...	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q
	17	...	...	Slap	Slap	Slap	Slap	Slap	Slap	Slap
	18	...	...	ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush
	19	...	...	ScratchPull	ScratchPull	ScratchPull	ScratchPull	ScratchPull	ScratchPull	ScratchPull
	20	...	...	FingerSnaps2	FingerSnaps2	FingerSnaps2	FingerSnaps2	FingerSnaps2	FingerSnaps2	FingerSnaps2
	21	...	...	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick
	22	...	...	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck	Mtrm.Clck
	23	...	...	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell	Mtrm. Bell
C1	24	...	...	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
	25	...	...	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl
	26	...	...	Brush Slap1	Brush Slap1	Brush Slap1	Brush Slap1	Brush Slap1	Brush Slap1	Brush Slap1
	28	...	...	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl	ReverseCymb	ReverseCymb	Brush Swirl
	29	...	...	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
	30	...	...	Castanets	Castanets	Castanets	Castanets	High-Q	High-Q	Castanets
	31	...	...	Concert Svr	Concert Svr	Concert Svr	Room Snare 1	Standard SN1	Power Snare1	Concert Svr
	32	...	...	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks
	33	...	...	Jazz Kick 1	Jazz Kick 1	Jazz Kick 1	Room Kick 2	Std2 Kick2	Mix Kick	Jazz Kick 1
	34	...	...	Jazz Snare 2	Jazz Snare 2	Jazz Snare 2	Jazz Snare 2	Jazz Snare 2	Jazz Snare 2	Jazz Snare 2
	35	...	...	Mix Kick	Std2 Kick2	Mix Kick	Std2 Kick2	Elec Kick 2	808 BD	Mix Kick
C2	36	...	...	Standard KK1	Std2 Kick1	Room Kick 1	Std2 Kick1	Power Kick1	TR-808 Kick	Jazz Kick 2
	37	...	...	Side Stick	Side Stick	Side Stick	Side Stick	Side Stick	808 Tumsht	Side Stick
	38	...	...	Standard SN1	Std2 Snare1	Standard SN1	LD Snare M	Dance Snare1	808 Snare 1	Standard SN1
	39	...	...	Brush Slap1	Castanets	High-Q	909 HandClap	909 HandClap	909 HandClap	909 HandClap
	40	...	...	Concert Svr	LD Snare M	LD Snare M	Jazz Snare 2	Power Snare 1	TR-808 SD2	LD Snare M
	41	...	...	Timpani	ScratchPush	Real Tom 6	Real Tom 6	Synth Drum 2	808 Tom 2	Real Tom 6
	42	...	...	Bs Chh	Timpani	ScratchPull	Close HHat2	Close HHat2	TR-808 CHH	Open HHat2
	43	...	...	Lite Tom 4	Timpani	Sticks	Real Tom 6	Real Tom 6	808 Tom 2	Real Tom 4
	44	...	...	Pedal HHat	Timpani	SquareClick	Pedal HHat2	Pedal HHat2	808_jhh	Pedal HHat2
	45	...	...	Lite Tom 4	Timpani	Mtrm.Clck	Real Tom 4	Real Tom 4	808 Tom 2	Real Tom 4
	46	...	...	Brush Ohh	Timpani	Mtrm. Bell	Open HHat2	Open HHat2	TR-808 OHH	Open HHat2
	47	...	...	Lite Tom 4	Timpani	Gt.CutNoise	Real Tom 4	Real Tom 4	808 Tom 2	Real Tom 1
C3	48	...	...	Brush Crash	Timpani	Gt.CutNoise	Crash Cym.1	Crash Cym.1	808 Crash	Crash Cym.1
	49	...	...	Lite Tom 4	Timpani	String Slap	Real Tom 1	Real Tom 1	808 Tom 2	Real Tom 1
	50	...	...	Ride Cym IN	Timpani	Fl KeyClick	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal
	51	...	...	ChinaCymbal	Timpani	Laughing	ChinaCymbal	ChinaCymbal	ChinaCymbal	ChinaCymbal
	52	...	...	Brush RideBL	Timpani	Screamng	Ride Bell	Ride Bell	Ride Bell	Ride Bell
	53	...	...	Tambourine	Tambourine	Punch	Tambourine	Tambourine	Tambourine	Tambourine
	54	...	...	Splash Cym.	Splash Cym.	Heart Beat	Splash Cym.	Splash Cym.	Splash Cym.	Splash Cym.
	55	...	...	Cowbell	Cowbell	Footsteps	Cowbell	Cowbell	808Cowbe	Cowbell
	56	...	...	Crash Cym.2	Con.Cymbal2	Footsteps	Crash Cym.2	Crash Cym.2	Crash Cym.2	Crash Cym.2
	57	...	...	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap
	58	...	...	RideCym Edge	Concert Cym	Creaking	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal
C4	59	...	...	Bongo High	Bongo High	Door	Bongo High	Bongo High	Bongo High	Bongo High
	60	...	...	Bongo Lo	Bongo Lo	Scratch	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo
	61	...	...	Mute H.Conga	Mute H.Conga	Wind Chimes	Mute H.Conga	Mute H.Conga	808 Conga	Mute H.Conga
	62	...	...	Conga Hi Opn	Conga Hi Opn	Car-Engine	Conga Hi Opn	Conga Hi Opn	808 Conga	Conga Hi Opn
	63	...	...	Conga Lo Opn	Conga Lo Opn	Car-Stop	Conga Lo Opn	Conga Lo Opn	808 Conga	Conga Lo Opn
	64	...	...	High Timbale	High Timbale	Car Pass	High Timbale	High Timbale	High Timbale	High Timbale
	65	...	...	Low Timbale	Low Timbale	Car-Crash	Low Timbale	Low Timbale	High Timbale	Low Timbale
	66	...	...	Agogo	Agogo	Sire	Agogo	Agogo	Agogo	Agogo
	67	...	...	Agogo	Agogo	Train	Agogo	Agogo	Agogo	Agogo
	68	...	...	Cabasa	Cabasa	Jetplane	Cabasa	Cabasa	Cabasa	Cabasa
	69	...	...	Maracas	Maracas	Helicopter	Maracas	Maracas	808marac	Maracas
	70	...	...	ShrtWhistle	ShrtWhistle	Starship	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle
	71	...	...	LongWhistle	LongWhistle	Gun Shot	LongWhistle	LongWhistle	LongWhistle	LongWhistle
C5	72	...	...	Shrt Guero	Shrt Guero	Machine Gun	Shrt Guero	Shrt Guero	Shrt Guero	Shrt Guero
	73	...	...	Long Guero	Long Guero	Lasegun	Long Guero	Long Guero	Long Guero	Long Guero
	74	...	...	Claves	Claves	Explosion	Claves	Claves	808Clave	Claves
	75	...	...	Woodblock	Woodblock	Dog	Woodblock	Woodblock	Woodblock	Woodblock
	76	...	...	Woodblock	Woodblock	HorseGallop	Woodblock	Woodblock	Woodblock	Woodblock
	77	...	...	Mute Cuica	Mute Cuica	Bird	Mute Cuica	Mute Cuica	ScratchPush	Mute Cuica
	78	...	...	Open Cuica	Open Cuica	Rain	Open Cuica	Open Cuica	ScratchPull	Open Cuica
	79	...	...	MuteTriangl	MuteTriangl	Thunder	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl
	80	...	...	OpenTriangl	OpenTriangl	Wind	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl
	81	...	...	Shaker	Shaker	Seashore	Shaker	Shaker	Shaker	Shaker
	82	...	...	Jingle Bell	Jingle Bell	Stream	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
C6	83	...	...	Bell Tree	Bell Tree	Bubble	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	84	...	...	Castanets	Castanets	...	...	...	...	...
	85	...	...	Mute Surdo	Mute Surdo	...	...	...	...	...
	86	...	...	Open Surdo	Open Surdo	...	...	...	...	...
	87	...	...	...	...	...	...	...	...	...
	88	...	...	Applause	Applause	...	...	...	...	...
	89	...	...	...	...	...	...	...	...	...
	90	...	...	...	...	...	...	...	...	...
	91	...	...	...	...	...	...	...	...	...
	92	...	...	...	...	...	...	...	...	...
	93	...	...	...	...	...	...	...	...	...
	94	...	...	...	...	...	...	...	...	...
	95	...	...	...	...	...	...	...	...	...
	96	...	...	...	...	...	...	...	...	...

(CC32= 119 only via MIDI)

(CC32=122 only via MIDI)

	PC-41 (CC32: 119)	PC-49 (CC32: 119)	PC-121 (CC32: 122)	PC-122 (CC32: 122)	PC-1 (CC32: 3)	PC-2 (CC32: 3)	PC-3 (CC32: 3)	PC-9 (CC32: 3)	PC-10 (CC32: 3)	PC-11 (CC32: 3)
	brush kit	classick	SFX 1 kit	SFX 2 kit	STANDRD1	STANDRD2	STANDRD3	ROOM	Hip-Hop	Angle
C-1	1	---	---	---	Std 1 Kick 1	Std 1 Kick 1	Std 1 Kick 1	Std 1 Kick 1	Elec Kick 2	Elec Kick 2
2	2	---	---	---	Std 1 Kick 2	Std 1 Kick 2	Std 1 Kick 2	Std 1 Kick 2	Elec Kick 1	Elec Kick 1
3	3	---	---	---	Std 2 Kick 1	Std 2 Kick 1	Std 2 Kick 1	Std 2 Kick 1	CR-78 Kick 1	CR-78 BD 1
4	4	---	---	---	Std 2 Kick 2	Std 2 Kick 2	Std 2 Kick 2	Std 2 Kick 2	CR-78 Kick 2	CR-78 BD 2
5	5	---	---	---	Kick 1	Kick 1	Kick 1	Kick 1	TR-606 Kick 1	TR-606 BD1
6	6	---	---	---	Kick 2	Kick 2	Kick 2	Kick 2	TR-707 Kick 1	TR-707 BD
7	7	---	---	---	Jazz Kick 1	Jazz Kick 1	Jazz Kick 1	Jazz Kick 1	TR-808 Kick	808 Kick
8	8	---	---	---	Jazz Kick 2	Jazz Kick 2	Jazz Kick 2	Jazz Kick 2	TR-808 Kick	TR-808 Kick
9	9	---	---	---	Room Kick 1	Room Kick 1	Room Kick 1	Room Kick 1	TR-808 Kick 2	808 BD
10	10	---	---	---	Room Kick 2	Room Kick 2	Room Kick 2	Room Kick 2	TR-909 Kick	TR-909 Kick
11	11	---	---	---	Power Kick 1	Power Kick 1	Power Kick 1	Power Kick 1	Dance Kick	Dance Kick 2
12	12	---	---	---	Power Kick 2	Power Kick 2	Power Kick 2	Power Kick 2	Hip-Hop Kick 2	909 Comp BD
13	13	---	---	---	Ele Kick 2	Ele Kick 2	Ele Kick 2	Ele Kick 2	TR-909 Kick 1	TR-909 BD2
14	14	Mute Surdo	Mute Surdo	---	Ele Kick 1	Ele Kick 1	Ele Kick 1	Ele Kick 1	Hip-Hop Kick 3	HipHop BD2
15	15	Open Surdo	Open Surdo	---	TR-808 Kick	TR-808 Kick	TR-808 Kick	TR-808 Kick	Jungle BD Srt	JungleBD Srt
16	16	High Q	---	---	TR-909 Kick	TR-909 Kick	TR-909 Kick	TR-909 Kick	Techno BD 1	Techno BD1
17	17	Slap	Slap	---	Dance Kick	Dance Kick	Dance Kick	Dance Kick	Bounce	Bounce
18	18	ScratchPush	ScratchPush	---	Voice One	Voice One	Voice One	Voice One	Voice One	Voice One
19	19	ScratchPull	ScratchPull	---	Voice Two	Voice Two	Voice Two	Voice Two	Voice Two	Voice Two
20	20	FingerSnaps2	FingerSnaps2	---	Voice Three	Voice Three	Voice Three	Voice Three	Voice Three	Voice Three
21	21	SquareClick	SquareClick	---	---	---	---	---	---	---
22	22	Mtrm Click	Mtrm Click	---	---	---	---	---	---	---
23	23	Mtrm Bell	Mtrm Bell	---	MC-500 Beep 1	MC-500 Beep 1	MC-500 Beep 1	MC-500 Beep 1	MC-500 Beep 1	MC-500 Beep
24	24	MC-500 Beep	MC-500 Beep	---	MC-500 Beep 2	MC-500 Beep 2	MC-500 Beep 2	MC-500 Beep 2	MC-500 Beep 2	MC-500 Beep
25	25	Concert SD	---	---	Concert SD	Concert SD	Concert SD	Concert SD	Concert SD	Concert Snr
26	26	Brush Swirl	Brush Swirl	---	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
27	27	Brush Swirl	Brush Swirl	---	Finger Snap	Finger Snap	Finger Snap 2	Finger Snap 2	Finger Snap 2	FingerSnaps2
28	28	Brush Slap1	Brush Slap1	---	High Q	High Q	High Q	High Q	High Q	High-Q
29	29	Brush Swirl	Brush Swirl	---	Slap	Slap	Slap	Slap	Slap	Slap
30	30	Snare Roll	Snare Roll	---	Scratch Push (EXCT)	Scratch Push	Scratch Push	Scratch Push	Scratch Push 2 (EXCT)	Scratch Push2
31	31	Castanets	Castanets	---	Scratch Pull (EXCT)	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Pull 2 (EXCT)	Scratch Pull2
32	32	Brush Slap1	Concert Snr	---	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks
33	33	Sticks	Sticks	---	Square Click	Square Click	Square Click	Square Click	Square Click	SquareClick
34	34	Jazz Kick 1	Jazz Kick 1	---	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Mtrm Click
35	35	Jazz Snare 2	Jazz Snare 2	---	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Mtrm Bell
36	36	Mx Kick	Concert BD	---	Standard 1 Kick 2	Standard 2 Kick 2	Standard 3 Kick 2	Room Kick 2	Hip-Hop Kick 2	HipHop BD1
37	37	Jazz Kick 1	Concert BD m	Gt CutNoise	Telephone 2	Standard 1 Kick 1	Standard 2 Kick 1	[RND] Kick	Room Kick 1	Std2 Kick2
38	38	Side Stick	Side Stick	Gt CutNoise	Creaking	Side Stick	Side Stick	Side Stick	TR-808 Rim Shot	Side Stick
39	39	Brush Slap1	Standard SN1	Dnst CutNoiz	Door	Standard 1 Snare 1	Standard 2 Snare 1	[RND] Snare	Room Snare 1	Dance Snare1
40	40	909 HandClap	909 HandClap	String Slap	ScratchPush	Hand Clap	TR-808 Hand Clap	[RND] Hand Clap	TR-808 Hand Clap	Hand Clap
41	41	LR Snare M	LR Snare M	Basz Slide	XG Scratch2	Standard 2 Snare 2	Standard 3 Snare 2	Room Snare 2	Hip-Hop Snare 2	House SD
42	42	Lite Tom 4	Real Tom 6	Pick Scrape	Wind Chimes	Low Tom2	Low Tom2	Room Low Tom2	TR-909 Low Tom 2	909 Tom
43	43	Close HiHat2	Pedal HiHat2	---	Telephone 2	Closed Hi-Hat	[RND] Closed Hi-Hat	Closed Hi-Hat	Closed Hi-Hat 3	606 CH
44	44	Lite Tom 4	Real Tom 4	---	---	Low Tom1	Low Tom1	Room Low Tom 1	TR-909 Low Tom 1	909 Tom
45	45	Pedal HiHat2	Pedal HiHat2	---	---	Pedal Hi-Hat	[RND] Pedal Hi-Hat	RoomPedal Hi-Hat	RoomPedal Hi-Hat	Jungle HH
46	46	Lite Tom 4	Real Tom 4	---	---	Mid Tom2	Mid Tom2	Room Mid Tom 2	TR-909 Mid Tom 2	909 Tom
47	47	Open HiHat2	Open HiHat2	---	---	Open Hi-Hat	[RND] Open Hi-Hat	Open Hi-Hat 3	606 HiHat Op	---
48	48	Lite Tom 4	Real Tom 1	---	---	Mid Tom 1	Mid Tom 1	Room Mid Tom 1	TR-909 Mid Tom 1	909 Tom
49	49	Lite Tom 4	Real Tom 1	---	---	High Tom 2	High Tom 2	Room High Tom 2	TR-909 High Tom 2	909 Tom
50	50	Crash Cym 1	Concert Cym	---	---	Crash Cymbal	[RND] Crash Cymbal	Crash Cymbal 1	TR-909 Crash Cymbal	Ingl Crash
51	51	Lite Tom 4	Real Tom 1	---	---	High Tom 1	High Tom 1	Room High Tom 1	TR-909 High Tom 1	909 Tom Snare
52	52	Ride Cymbal	ConcertCymCl	---	---	Ride Cymbal 1	[RND] Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal
53	53	ChinaCymbal	ChinaCymbal	Fl KeyClick	Cai Engine	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	ReverseCymbal
54	54	Ride Bell	Ride Bell	---	Cai Stop	Ride Bell	[RND] Ride Bell	Ride Bell	Ride Bell	Ride Bell
55	55	Tambourine	Tambourine	---	Cai-Pans	Tambourine	Tambourine	Tambourine	Shake Tambourine	Shake Tamb
56	56	Splash Cym	Splash Cym	---	Cai-Crash	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cym
57	57	Cowbell	Cowbell	---	Siren	Cowbell	Cowbell	Cowbell	TR-808 Cowbell	808COW
58	58	Crash Cym 2	Concert Cym	---	Train	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	Crash Cymbal 2	Crash Cym2
59	59	VibraSnap	VibraSnap	---	Jetslap	Vibra-slap	Vibra-slap	Vibra-slap	Vibra-slap	VibraSnap
60	60	Ride Cymbal	ConcertCymCl	---	Starslap	Ride Cymbal 2	[RND] Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal 2	Ride Cymbal
61	61	Bongo High	Bongo High	---	Burst Noise	High Bongo	High Bongo	High Bongo	High Bongo	Bongo High
62	62	Bongo Lo	Bongo Lo	---	Coaster	Low Bongo	Low Bongo	Low Bongo	Low Bongo	Bongo Lo
63	63	Mute H.Conga	Mute H.Conga	---	Submarine	Mute High Conga	Mute High Conga	Mute High Conga	Mute High Conga	Mute H.Conga
64	64	Conga Hi Opn	Conga Hi Opn	---	---	Open High Conga	Open High Conga	Open High Conga	Open High Conga	Conga Hi Opn
65	65	Conga Lo Opn	Conga Lo Opn	---	---	Open Low Conga	Open Low Conga	Open Low Conga	Open Low Conga	Conga Lo Opn
66	66	High Timbale	High Timbale	---	---	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
67	67	Low Timbale	Low Timbale	---	---	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
68	68	Agogo	Agogo	---	---	High Agogo	High Agogo	Low Agogo	Low Agogo	Agogo
69	69	Agogo	Agogo	Rain	Laughing	Low Agogo	Low Agogo	Low Agogo	Low Agogo	Agogo
70	70	Cabasa	Cabasa	Thunder	Screaming	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
71	71	Maracas	Maracas	Wind	Punch	Maracas	Maracas	Maracas	TR-808 Maracas	808marac
72	72	ShrtWhistle	ShrtWhistle	Stream	Heart Beat	Short High Whistle	Short High Whistle	Short High Whistle	Short High Whistle	ShrtWhistle
73	73	LongWhistle	LongWhistle	Bubble	Footsteps	Long Low Whistle	Long Low Whistle	Long Low Whistle	Long Low Whistle	LongWhistle
74	74	Short Guiro	Short Guiro	Feed	ApplauseWave	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro
75	75	Long Guiro	Long Guiro	---	---	Long Guiro	Long Guiro	Long Guiro	CR-78 Guiro	CR78 Guiro
76	76	Claves	Claves	---	---	Claves	Claves	Claves	TR-808 Claves	808Clave
77	77	Woodblock	Woodblock	---	---	High Wood Block	High Wood Block	High Wood Block	High Wood Block	Woodblock
78	78	Woodblock	Woodblock	---	---	Low Wood Block	Low Wood Block	Low Wood Block	Low Wood Block	Woodblock
79	79	Mute Cuica	Mute Cuica	---	---	Mute Cuica	Mute Cuica	Mute Cuica	High Hoo	Hoo
80	80	Open Cuica	Open Cuica	---	---	Open Cuica	Open Cuica	Open Cuica	Low Hoo	Hoo
81	81	Mute Triangl	Mute Triangl	---	---	Mute Triangle	Mute Triangle	Mute Triangle	Electric Mute Triangle	MuteTriangl
82	82	Open Triangl	Open Triangl	---	---	Open Triangle	Open Triangle	Open Triangle	Electric Open Triangle	OpenTriangl
83	83	Shaker	Shaker	---	---	Shaker	Shaker	Shaker	TR-626 Shaker	626 Shaker
84	84	Jingle Bell	Jingle Bell	---	---	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
85	85	Bell Tree	Bell Tree	Dog	Machine Gun	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
86	86	---	---	HorseGallop	Lasergun	Castanets	Castanets	Castanets	Castanets	Castanets
87	87	---	---	Bird 2	Explosion	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
88	88	---	---	Kitty	Firework	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo
89	89	---	---	Growl	---	Applause 2	Applause 2	Applause 2	Applause 2	Small Club 1
90	90	---	---	Huanted	---	---	---	---	---	Small Club
91	91	---	---	Ghost	---	---	---	---	---	---
92	92	---	---	Maou	---	---	---	---	---	---
93	93	---	---	---	---	---	---	---	---	---
94	94	---	---	---	---	---	---	---	---	---
95	95	---	---	---	---	---	---	---	---	---
96	96	---	---	---	---	---	---	---	---	---

REFERENCE

Drum Sets

	PC: 1 (CC32: 1) brush kit	PC: 2 (CC32: 1) classic	PC: 3 (CC32: 1) SFX 1 kit	PC: 4 (CC32: 1) SFX 2 kit	PC: 1 (CC32: 3) STANDRD1	PC: 2 (CC32: 3) STANDRD2	PC: 3 (CC32: 3) STANDRD3	PC: 4 (CC32: 3) ROOM	PC: 10 (CC32: 3) HipHop	PC: 11 (CC32: 3) Jungle
(C7) 96	(--)	(--)	(--)	(--)	(--)	(--)	(--)	(--)	(--)	(--)
96	---	---	---	---	Standard 1 Snare 1	Standard 1 Snare 1	Standard 1 Snare 1	Standard 1 Snare 1	Techno Hit	Techno Hit
98	---	---	---	---	Standard 1 Snare 2	Standard 1 Snare 2	Standard 1 Snare 2	Standard 1 Snare 2	Philly Hit	Philly Hit
100	---	---	---	---	Standard 2 Snare 1	Standard 2 Snare 1	Standard 2 Snare 1	Standard 2 Snare 1	Shock Wave	Shock Wave
101	---	---	---	---	Standard 2 Snare 2	Standard 2 Snare 2	Standard 2 Snare 2	Standard 2 Snare 2	Lo-Fi Rave Bam Hit	Lo-Fi Rave
101	---	---	---	---	Snare Drum 2	Snare Drum 2	Snare Drum 2	Snare Drum 2	Bim-Hit	Bam Hit
103	---	---	---	---	Standard 1 Snare 1	Standard 1 Snare 1	Standard 1 Snare 1	Standard 1 Snare 1	Tape Rewind	Tape Rewind
103	---	---	---	---	Standard 1 Snare 2	Standard 1 Snare 2	Standard 1 Snare 2	Standard 1 Snare 2	Phonograph Noise	TapeRewind
105	---	---	---	---	Standard Snare 3	Standard Snare 3	Standard Snare 3	Standard Snare 3	Phono Noise	Phono Noise
105	---	---	---	---	Jazz Snare 1	Jazz Snare 1	Jazz Snare 1	Jazz Snare 1	Dance Snare 1	Dance Snare 1
107	---	---	---	---	Jazz Snare 2	Jazz Snare 2	Jazz Snare 2	Jazz Snare 2	Dance Snare 2	Power Snare 2
108	---	---	---	---	Room Snare 1	421 Room Snare 1	Room Snare 1	Room Snare 1	Disco Snare	Elec Snare 1
108	---	---	---	---	Room Snare 2	Room Snare 2	Room Snare 2	Room Snare 2	Electric Snare 2	Dance Snare 2
110	---	---	---	---	Power Snare 1	Power Snare 1	Power Snare 1	Power Snare 1	Electric Snare	Elec Snare 2
110	---	---	---	---	Power Snare 2	Power Snare 2	Power Snare 2	Power Snare 2	Electric Snare 3	Elec Snare
112	---	---	---	---	Gated Snare	Gated Snare	Gated Snare	Gated Snare	TR-606 Snare	Elec Snare 3
112	---	---	---	---	Dance Snare 1	Dance Snare 1	Dance Snare 1	Dance Snare 1	TR-707 Snare	66in260
113	---	---	---	---	Dance Snare 2	Dance Snare 2	Dance Snare 2	Dance Snare 2	TR-808 Snare 1	TR-707 SD
115	---	---	---	---	Disco Snare	Disco Snare	Disco Snare	Disco Snare	TR-808 Snare 2	808 Snare 1
115	---	---	---	---	Electric Snare 2	Electric Snare 2	Electric Snare 2	Electric Snare 2	TR-808 Snare 2	808 Snare 2
117	---	---	---	---	Electric Snare	Electric Snare	Electric Snare	Electric Snare	TR-909 Snare 1	TR-808 SD2
117	---	---	---	---	Electric Snare 3	Electric Snare 3	Electric Snare 3	Electric Snare 3	TR-909 Snare 2	909 Snare 1
119	---	---	---	---	TR-707 Snare	TR-707 Snare	TR-707 Snare	TR-707 Snare	TR-909 Snare 1	909 Snare 2
119	---	---	---	---	TR-808 Snare 1	TR-808 Snare 1	TR-808 Snare 1	TR-808 Snare 1	TR-909 Snare 2	909 SD 1
120	---	---	---	---	TR-808 Snare 2	TR-808 Snare 2	TR-808 Snare 2	TR-808 Snare 2	Rap Snare	TR-909 SD2
122	---	---	---	---	TR-909 Snare 1	TR-909 Snare 1	TR-909 Snare 1	TR-909 Snare 1	Jungle Snare 1	Rap Snare
122	---	---	---	---	TR-909 Snare 2	TR-909 Snare 2	TR-909 Snare 2	TR-909 Snare 2	House Snare 1	JungleSD1
124	---	---	---	---	Rap Snare	Rap Snare	Rap Snare	Rap Snare	House Snare	House SD
124	---	---	---	---	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	House Snare 2	House Snare
125	---	---	---	---	House Snare 1	House Snare 1	House Snare 1	House Snare 1	Voice Tah	House SD
125	---	---	---	---	House Snare	House Snare	House Snare	House Snare	Slappy	Voice Tah
G9 127	---	---	---	---	House Snare 2	House Snare 2	House Snare 2	House Snare 2	House Snare 2	Noise Slap

	PC: 26 (CC32: 3) TECHNO	PC: 17 (CC32: 3) POWER	PC: 25 (CC32: 3) ELECTNIC	PC: 26 (CC32: 3) TR-808	PC: 27 (CC32: 3) DANCE	PC: 28 (CC32: 3) CR-78	PC: 29 (CC32: 3) TR-406	PC: 30 (CC32: 3) TR-707	PC: 31 (CC32: 3) TR-909	PC: 33 (CC32: 3) JAZZ
(C7) 96	(--)	(--)	(--)	(--)	(--)	(--)	(--)	(--)	(--)	(--)
96	Techno Hit	Std. 1 Snare 1	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit	---
98	Philly Hit	Std. 1 Snare 2	Philly Hit	Philly Hit	Philly Hit	Philly Hit	Philly Hit	Philly Hit	Philly Hit	---
100	Shock Wave	Std. 2 Snare 1	Shock Wave	Shock Wave	Shock Wave	Shock Wave	Shock Wave	Shock Wave	Shock Wave	---
100	Lo-Fi Rave *	Std. 2 Snare 2	Lo-Fi Rave *	Lo-Fi Rave *	Lo-Fi Rave *	Lo-Fi Rave *	Lo-Fi Rave *	Lo-Fi Rave *	Lo-Fi Rave *	---
101	Bam Hit	Tight Snare	Bam Hit	Bam Hit	Bam Hit	Bam Hit	Bam Hit	Bam Hit	Bam Hit	Brush Tap
101	Bim-Hit	Standard SH1	Bim Hit	Bim Hit	Bim Hit	Bim Hit	Bim Hit	Bim Hit	Bim Hit	Brush Slap1
103	Tape Rewind	LD Snare M	TapeRewind	Tape Rewind	TapeRewind	TapeRewind	TapeRewind	TapeRewind	TapeRewind	Brush Slap2
103	Phono Noise	LD Snare C	Phono Noise	Phono Noise	Phono Noise	Phono Noise	Phono Noise	Phono Noise	Phono Noise	Brush Slap
105	Dance Snare 1	Jazz Snare 1	Dance Snare 1	Dance Snare 1	Dance Snare 1	Dance Snare 1	Dance Snare 1	Dance Snare 1	Dance Snare 1	Brush Swirl
105	Power Snare 2	Jazz Snare 2	Power Snare 2	Power Snare 2	Power Snare 2	Power Snare 2	Power Snare 2	Power Snare 2	Power Snare 2	Brush Swirl
107	Elec Snare 1	Room Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Long Swirl
108	Dance Snare 2	Room Snare 2	Dance Snare 2	Dance Snare 2	Dance Snare 2	Dance Snare 2	Dance Snare 2	Dance Snare 2	Dance Snare 2	Jazz Snare 1
110	Elec Snare 2	Power Snare 1	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2	Jazz Snare 2
110	Elec Snare 3	Dance Snare 1	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3	Std. 1 Snare 1
112	66in260	Power Snare 2	66in260	66in260	66in260	66in260	66in260	66in260	66in260	Std. 2 Snare 1
112	TR-707 SD	Elec Snare 1	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 SD	Std. 2 Snare 2
115	808 Snare 1	Dance Snare 2	808 Snare 1	808 Snare 1	808 Snare 1	808 Snare 1	808 Snare 1	808 Snare 1	808 Snare 1	Tight Snare
115	808 Snare 2	Elec Snare 2	808 Snare 2	808 Snare 2	808 Snare 2	808 Snare 2	808 Snare 2	808 Snare 2	808 Snare 2	Standard SH1
117	TR-808 SD2	Elec Snare	TR-808 SD2	TR-808 SD2	TR-808 SD2	TR-808 SD2	TR-808 SD2	TR-808 SD2	TR-808 SD2	LD Snare M
117	909 Snare 1	Elec Snare 3	909 Snare 1	909 Snare 1	909 Snare 1	909 Snare 1	909 Snare 1	909 Snare 1	909 Snare 1	LD Snare C
119	909 Snare 2	TR-707 SD	909 Snare 2	909 Snare 2	909 Snare 2	909 Snare 2	909 Snare 2	909 Snare 2	909 Snare 2	Room Snare 1
119	909 SD 1	808 Snare 1	909 SD 1	909 SD 1	909 SD 1	909 SD 1	909 SD 1	909 SD 1	909 SD 1	Room Snare 2
120	TR-909 SD2	808 Snare 2	TR-909 SD2	TR-909 SD2	TR-909 SD2	TR-909 SD2	TR-909 SD2	TR-909 SD2	TR-909 SD2	Dance Snare 1
122	Rap Snare	909 Snare 1	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Power Snare 1
122	JungleSD1	909 Snare 2	JungleSD1	JungleSD1	JungleSD1	JungleSD1	JungleSD1	JungleSD1	JungleSD1	Rev Snare
124	House SD	Rap Snare	House SD	House SD	House SD	House SD	House SD	House SD	House SD	Power Snare 2
124	House Snare	JungleSD1	House Snare	House Snare	House Snare	House Snare	House Snare	House Snare	House Snare	Elec Snare 1
125	House SD	House SD	House SD	House SD	House SD	House SD	House SD	House SD	House SD	Dance Snare 2
125	Voice Tah	House Snare	Voice Tah	Voice Tah	Voice Tah	Voice Tah	Voice Tah	Voice Tah	Voice Tah	Elec Snare 2
G9 127	Noise Slap	House SD	Noise Slap	Noise Slap	Noise Slap	Noise Slap	Noise Slap	Noise Slap	Noise Slap	Elec Snare 3

	PC-17 [CC32: 3] TECHNO	PC-18 [CC32: 3] POWER	PC-25 [CC32: 3] ELECTRIC	PC-26 [CC32: 3] TR-808	PC-27 [CC32: 3] DANCE	PC-28 [CC32: 3] CR-78	PC-29 [CC32: 3] TR-808	PC-30 [CC32: 3] TR-707	PC-31 [CC32: 3] TR-909	PC-33 [CC32: 3] JAZZ
C-1	0	1	2	3	4	5	6	7	8	9
	10	11	12	13	14	15	16	17	18	19
	20	21	22	23	24	25	26	27	28	29
	30	31	32	33	34	35	36	37	38	39
	40	41	42	43	44	45	46	47	48	49
	50	51	52	53	54	55	56	57	58	59
	60	61	62	63	64	65	66	67	68	69
	70	71	72	73	74	75	76	77	78	79
	80	81	82	83	84	85	86	87	88	89
	90	91	92	93	94	95	96	97	98	99
C7	100	101	102	103	104	105	106	107	108	109

REFERENCE

Drum Sets

	PC: 41 [CC32: 3]	PC: 49 [CC32: 3]	PC: 50 [CC32: 3]	PC: 51 [CC32: 3]	PC: 53 [CC32: 3]	PC: 54 [CC32: 3]	PC: 57 [CC32: 3]	PC: 58 [CC32: 3]	PC: 59 [CC32: 3]	PC: 128 [CC32: 3]	
	BRUSH	ORCHESTRA	ETHNIC	KICK&SNR	ASIA	CYMB&CLAP	SFX	Rhythm FX	RHYTHMFX2	CM-64/32L	
C-1	0	Std 1 Kick1	Std 1 Kick1	...	...	...	...	...	...	...	
	1	Std 1 Kick2	Std 1 Kick2	...	...	...	...	...	...	...	
	2	Std 2 Kick1	Std 2 Kick1	...	...	...	...	...	...	...	
	3	Std 2 Kick2	Std 2 Kick2	...	...	...	...	...	...	...	
	4	Kick 1	Kick 1	...	...	...	...	...	...	...	
	5	Kick 2	Kick 2	...	...	...	...	...	...	...	
	6	Jazz Kick 1	Jazz Kick 1	...	...	...	...	...	...	...	
	7	Jazz Kick 2	Jazz Kick 2	...	...	...	...	...	...	...	
	8	Room Kick 1	Room Kick 1	...	...	...	...	...	...	...	
	9	Room Kick 2	Room Kick 2	...	...	...	...	...	...	...	
	10	Power Kick1	Power Kick1	...	...	...	...	...	...	...	
	11	Power Kick2	Power Kick2	...	...	...	...	...	...	...	
C0	12	Elec Kick 2	Elec Kick 2	...	...	...	...	...	...	...	
	13	Elec Kick 1	Elec Kick 1	...	...	...	...	...	...	...	
	14	TR-808 Kick	TR-808 Kick	...	...	...	...	...	...	...	
	15	TR-909 Kick	TR-909 Kick	...	...	...	...	...	...	...	
	16	Dance Kick 2	Dance Kick 2	...	...	...	...	...	...	...	
	17	Voice One	Voice One	...	...	...	...	...	...	...	
	18	Voice Two	Voice Two	...	...	...	...	...	...	...	
	19	Voice Three	Voice Three	...	...	...	...	...	...	...	
	20	...	...	...	...	...	...	...	...	...	
	21	...	...	...	...	...	...	...	...	...	
	22	MC-500 Beep	MC-500 Beep	...	...	...	MC-500 Beep	...	...	...	
	23	MC-500 Beep	MC-500 Beep	...	...	...	ywm3.atp	...	...	...	
C1	24	Concert Snr	Concert Snr	...	...	...	ywm2.atp	...	...	...	
	25	Snare Roll	Snare Roll	Finger Snap	CR78 BD 1	Gamelan Gong C#	Guitar Slap	...	...	...	
	26	Finger Snap	Finger Snap	Tambourine	CR78 BD 2	Gamelan Gong D#	Chord Stroke	...	...	...	
	27	High Q	Jazz Clsd HH	Castanets	TR-606 BD1	Gamelan Gong G	Chord Stroke	...	...	...	
	28	Slap	Pedal HiHat	Crash Cymbal 1	TR-707 BD	Gamelan Gong A#	Bwa 3	...	...	...	
	29	ScratchPhon	Jazz Open HH	Snare Roll	808 BD	Gamelan Gong C	Phono Noise	...	...	...	
	30	ScratchPull	Ride Cymbal	Concert SD	909 Comp BD	Gamelan Gong C#	TapReWind	...	...	...	
	31	Sticks	Sticks	Concert Cymbal	TR-909 BD2	Gamelan Gong D#	Scratch Push2	...	...	...	
	32	SquareClick	SquareClick	Concert BD 1	HiHat BD2	Gamelan Gong G	Scratch Pull2	...	...	...	
	33	Mtrm Click	Mtrm Click	Jingle Bell	HiHat BD1	Gamelan Gong A#	Rev. LVGH1	GLCutHouse2	...	...	
	34	Mtrm Bell	Bell Tree	Jungle BD2	Gamelan Gong C	Rev. LVGH2	GLCutHouse2	...	...	...	
	35	Jazz Kick 2	Jazz Kick 1	Bar Chimes	JungleBD Set	Gender CH	Jungle HH	Dist.CutNoiz	...	Kick 1	
C2	36	Jazz Kick 1	Concert BD	Wadaiko *	Techno BD2	Gender DF	Close HiHat	Dist.CutNoiz Bang	Reverse Kick 1	rev.707bd	Kick 1
	37	Side Stick	Side Stick	Wadaiko * Rim *	Techno BD1	Gender G	Jazz Clsd HH	Bass Slide	Reverse Concert Bass	rev.909bd2	Side Stick
	38	Brush Swirl	Concert Snr	Shime Taiko	Mix Kick	Gender A#	Room Chk	Pick Scrape	Reverse Power Kick 1	rev.hphp_bd1	Fat Snare
	39	Brush Slap1	Castanets	Atriganes	Standard KK 1	Gender c	Close HiHat1	High-Q	Reverse Elect c Kick 1	rev.jgl_bd2	Hand Clap
	40	Brush Swirl	Concert Snr	Hyoushigi	Std 1 Kick1	Bonang C#	Close HiHat2	Slap	Reverse Snare 1	rev.tech_bd2	Elec Snare
	41	Lite Tom 4	Timpani	Ohkawa	Std 1 Kick2	Bonang D#	TR-707 HH-c	ScratchPull	Reverse Snare 2	rev.606sn2	Tom
	42	Bis Chh	Timpani	High Kotsuzumi	Std 2 Kick1	Bonang G	808 CH	ScratchPush	Reverse Standard 1	rev.c78bd1	Close HiHat
	43	Lite Tom 4	Timpani	Low Kotsuzumi	Std 2 Kick2	Bonang A#	808_rhh	Sticks	Reverse Snare Drum 2	rev.c78bd2	Tom
	44	Pedal HiHat	Timpani	Bar Gu	Kick 1	Bonang c	TR-808 GHH	SquareClick	Reverse Tight Snare	rev.jgl_sd2	Open HiHat2
	45	Lite Tom 4	Timpani	Big Gong	Kick 2	Thai Gong	CR-78 chh	Mtrm Click	Reverse 808 Snare	rev.tech_sd2	Tom
	46	Brush Ohh	Timpani	Small Gong	Soft Kick	Rama Cymbal	GS Pedal HH	Mtrm Bell	Reverse Tom 1	rev.707bd	Open Hi Hat
C3	47	Lite Tom 4	Timpani	Bend Gong	Jazz Kick 1	Saget Opens	Pedal HiHat	GLFretNoiz	Reverse Tom 2	rev.606s1	Tom
	48	Lite Tom 4	Timpani	Thai Gong	Jazz Kick 2	Saget Closed	Pedal HiHat2	GLCutHouse	Reverse Strks	rev.909s1	Tom
	49	Brush Crash	Timpani	Rama Cymbal	Concert BD	Jawa Harp	Hall OpenHit	GLCutHouse	Reverse Slap	rev.hghp_sd2	GS Crash
	50	Lite Tom 4	Timpani	Gamelan Gong	Room Kick 1	Wadako *	Hall OpenHit2	String Slap	Reverse Cymbal 1	rev.jgl_sd1	Tom
	51	Ride Cym H#	Timpani	Udo Short [EXC1]	Room Kick 2	Wadaiko Rim *	Open Hi-Hat	FLKeyClick	Reverse Cymbal 2	Rev. House SD	Ride Cymbal
	52	Crash Cymbal	Timpani	Udo Long [EXC1]	Power Kick 1	Taiko	Jazz Open HH	Laughing	Reverse Open Hi-Hat	Rev. LVGH1 1	...
	53	Brush RideBll	Timpani	Udo Slap	Power Kick2	Shimeiko	BB Ohh2	Screaming	Reverse Ride Cymbal	rev.606hcl	...
	54	Tambourine	Tambourine	Bendir	Elec Kick 2	Atriganes	Open HiHat2	Punch	Reverse CR-78 Open	rev.707rhh	Tambourine
	55	Splash Cym	Splash Cym	Req Dum	Elec Kick 1	Hyoushigi	909 OH	Heart Beat	Reverse Closed Hi-Hat	rev.808rhh	...
	56	Cowbell	Cowbell	Req Tik	Elec Kick	Ohkawa	TR-707 OH#	Footsteps	Reverse Gong	rev.jgl_hh	Cowbell
	57	Crash Cym 2	Crash Cymbal2	Tabla Te	TR-808 Kick	Hish Kotsuzumi	909 HiHat Op	Footsteps	Reverse Bell Tree	rev.344mb2	...
	58	Vibratop	Vibratop	Tabla Ha	TR-909 Kick	Low Kotsuzumi	808_rhh	Applause	Reverse Guaro	rev.344mb1	...
	59	RideCym Edge	Concert Cym	Tabla Tun	Dance Kick 2	Yoyo Dude	TR-808 OH#	...	Reverse Bendir	rev.808bhh	...
C4	60	Bongo High	Bongo High	Tabla Ge	Std 1 Snare1	Buk	CR-78 ohh	Door	Reverse Gun Shot	rev.707ohh	High Bongo
	61	Power Snare 1	Bongo Lu	Tabla Ge H#	Std 1 Snare2	Buk Rim	Crash Cym. 1	Scratch	Reverse Scratch	rev.wohth	Low Bongo
	62	Rev Snare	Mute H Conga	Talking Drum *	Std 2 Snare1	Gengari p	Crash Cym.2	Wind Chimes	Reverse Laser Gun	rev.606cym	Mute Conga
	63	Conga Lo Opn	Conga Hi Opn	Bend Talking Drum *	Std 2 Snare2	Gengari Mute Low	GS Crash	Car Engine	Key Click	Rev. HynLuo	Conga
	64	Conga Lo Opn	Conga Lo Opn	Caaju	Tight Snare	Gengari f	Brush Crash	Car Stop	Tekno Thp	rev.707fs	Conga
	65	High Timbale	High Timbale	Djembe	Concert Snr	Gengari Mute High	Hard Crash	Car-Past	Pop Drop	Voice One	Timbales
	66	Low Timbale	Low Timbale	Djembe Rim	Jazz Snare 1	Gengari Samll	509 Crash	Car-Crash	Woody Slap	rev.one	Timbales
	67	Agogo	Agogo	Timbales Low	Jazz Snare 2	Jang Gu Che	808 Crash	Siren	Distortion Kick *	Voice Two	Agogo
	68	Agogo	Agogo	Timbales Palla	Room Snare 1	Jang Gu Kun	Crash Mute 1	Train	Syn. Drops	rev.two	Agogo
	69	Cabasa	Cabasa	Timbales High	Room Snare 2	Jang Gu Rem	Crash Mute 2	Jetalane	Reverse Hi Q	Voice Three	Cabasa
	70	Maracas	Maracas	Cowbell	Dance Snare 1	jng p *	ReverseCymbal	Helicopter	Pipe	rev.three	Maracas
	71	ShrtWhistle	ShrtWhistle	High Bongo	Power Snare1	jng f *	Rev.Cymbal2	Starship	Ice Block	Voice Tah	ShrtWhistle
C5	72	LongWhistle	LongWhistle	Low Bongo	Rev. Snare	Jng Mute	Reverse Cym	Gun Shot	Digital Tambourine *	rev.tah	LongWhistle
	73	Shrt Guaro	Shrt Guaro	Mute High Conga	Power Snare2	Asian Gong 1	rev.trn_crm	Machine Gun	Alkas	Voice 1	Vibratop
	74	Long Guaro	Long Guaro	Open High Conga	Elec Snare 1	Big Gong	Crash Cym.1	Lasergun	Modulated Bell	Voice Au	...
	75	Claves	Claves	Mute Low Conga	Dance Snare2	Small Gong	Splash Cym	Explosion	Spark	Voice Whcy	Claves
	76	Woodblock	Woodblock	Conga Slap	Elec Snare 2	Pai Ban	Ride Bell	Dog	Metallic Percussion	Frog Vpoxe	Laughing
	77	Woodblock	Woodblock	Open Low Conga	House Snare	Bar Gu	Brush RideBll	HorseGallop	Velocity Noise FX	rev.yppoh	Screaming
	78	Mute Caica	Mute Caica	Conga Slide *	Elec. Snare	Tang Gu	Ride Cymbal	Bird	Stereo Noise Cap *	Doubly	Punch
	79	Open Caica	Open Caica	Mute Pandiero	Elec Snare 3	Tang Gu Mute	Ride Cymbal	Rain	Swish	rev.doubly	Heart Beat
	80	Mute Triangl	Mute Triangl	Open Pandiero	808 Snare 1	Shou Luo *	Brush Ride	Thunder	Slappy *	Bartl	Footsteps
	81	Open Triangl	Open Triangl	Open Surdo [EXC2]	808 Snare 2	Bend Gong	Ride Cym W#	Wind	Voice Du	Bartl	Footsteps
	82	Shaker	Shaker	Mute Surdo [EXC2]	909 Snare 1	HuYin Luo Low *	Ride Cym R#	Scratchre	Voice Au	Bounce	Applause
	83	Jingle Bell	Jingle Bell	Tamborin	909 Snare 2	HuYin Luo Mid	Ride Cym B#	Stream	Hoo	rev.bounce	Creating
C6	84	Bell Tree	Bell Tree	High Agogo	Brush Swirl	HuYin LuoMid Mute!	RideCym Edge	Bubble	Tape Stop 1 *	Dist Knock	Door
	85	Castanets	Castanets	Low Agogo	Brush Tap	HuYin LuoHigh	RideCym Edge	Kitty	Tape Stop 2 *	ywm3.atp	Scratch
	86	Mute Surdo	Mute Surdo	Shaker	Brush Slap1	HuYin LuoHighMute	RideCym Edge	Bird 2	Musle *	xxx	Wind Chimes
	87	Open Surdo	Open Surdo	High Whistle [EXC3]	Brush Slap2	Hao Bo	606 Ride Cym	Grown	Space Birds	Noise Attack	Car-Engine
	88	Applause	Applause	Long Whistle [EXC3]	Brush Slap	Xiao Bo	TR808 Ride	Applause 2	Flying Monster	Space Worms	Car-Stop
	89	...	...	Mute Caica [EXC4]	Brush Swirl	...	ChinaCymbal	Telephone 1	Emergency!	Car-Pass	...
	90	...	...	Open Caica [EXC4]	Brush Swirl	...	China Cym2	Telephone 2	Calculating	Car-Crash	...
	91	...	...	Mute Triangle [EXC5]	Long Swirl	...	Hand Clap	Small Cub	...	SawFDSaw	Stem
	92	...	...	Open Triangle [EXC5]	Standard SH1	...	Hand clap2	Small Cub 2	...	...	Train
	93	...	...	Shrt Guaro [EXC6]	LD Snare M	...	808clap	ApplauseWave	...	...	Jetalane
	94	...	...	Long Guaro [EXC6]	LD Snare C	...	909 HandClap	Eruption	...	...	Helicopter
	95	...	...	Cabasa Up	Rap Snare	...	HC2 Claps 2	Big Shot	...	...	Starship
C7	96	...	...	Cabasa Down	HiHatop SD2	...	707 Claps	Perc. Bang	...	...	Gun Shot

	PC: 41 [CC32: 3] BRUSH	PC: 49 [CC32: 3] ORCHSTRA	PC: 50 [CC32: 3] ETHNIC	PC: 51 [CC32: 3] KICK&SHR	PC: 53 [CC32: 3] ASIA	PC: 54 [CC32: 3] CYMBCLAP	PC: 57 [CC32: 3] SFX	PC: 58 [CC32: 3] RHYTHM FX	PC: 59 [CC32: 3] RHYTHMFX2	PC: 128 [CC32: 3] CM-54/32L
(C7) 196	(--)	(--)	(Cajon Down)	(HipHop SD2)	(--)	(707 Claps)	(Perc. Bang)	(--)	(--)	(Gun Shot)
97	--	Applause 2	Claves	JungleSD1	--	--	--	--	--	LaserGun
98	--	Small Clab	High Wood Block	Jungle SD2	--	--	--	--	--	Explosion
99	--	Timpani	Low Wood Block	Slap	--	--	--	--	--	Ding
100	Brush Swirl	Timpani	--	MG_Blip	--	--	--	--	--	HorseGallop
101	Brush Tap	Timpani	--	House SD	--	--	--	--	--	Bird
102	Brush Slap 1	Timpani	--	CR78 SD 1	--	--	--	--	--	Rain
103	Brush Slap 2	Timpani	--	CR78 SD 2	--	--	--	--	--	Thunder
104	Brush Slap	Timpani	--	66sn160	--	--	--	--	--	Wind
105	Brush Swirl	Timpani	--	66sn260	--	--	--	--	--	Seashore
106	Brush Swirl	Timpani	--	TR-707 SD	--	--	--	--	--	Stream
107	Long Swirl	Timpani	--	TR-707 SD 2	--	--	--	--	--	Bubble
108	Jazz Snare 1	Timpani	--	TR-707 SD 3	--	--	--	--	--	--
109	Jazz Snare 2	Timpani	--	TR-808 SD2	--	--	--	--	--	--
110	Std. 1 Snare1	Timpani	--	909 SD 1	--	--	--	--	--	--
111	Std. 1 Snare2	Timpani	--	TR-909 SD2	--	--	--	--	--	--
112	Std. 2 Snare1	Timpani	--	--	--	--	--	--	--	--
113	Std. 2 Snare2	Timpani	--	--	--	--	--	--	--	--
114	Tight Snare	--	--	--	--	--	--	--	--	--
115	Standard SH1	--	--	--	--	--	--	--	--	--
116	LD Snare M	--	--	--	--	--	--	--	--	--
117	LD Snare C	--	--	--	--	--	--	--	--	--
118	Room Snare 1	--	--	--	--	--	--	--	--	--
119	Room Snare 2	--	--	--	--	--	--	--	--	--
120	Dance Snare1	--	--	--	--	--	--	--	--	--
121	Power Snare1	--	--	--	--	--	--	--	--	--
122	Rev Snare	--	--	--	--	--	--	--	--	--
123	Power Snare2	--	--	--	--	--	--	--	--	--
124	Elec Snare 1	--	--	--	--	--	--	--	--	--
125	Dance Snare2	--	--	--	--	--	--	--	--	--
126	Elec Snare 2	--	--	--	--	--	--	--	--	--
G9 127	Elec Snare 3	--	--	--	--	--	--	--	--	--

REFERENCE

Drum Sets

	PC: 1 [CC32: 2] STANDRD1	PC: 2 [CC32: 2] STANDRD2	PC: 3 [CC32: 2] Room	PC: 17 [CC32: 2] Power	PC: 25 [CC32: 2] ELECTRNC	PC: 24 [CC32: 2] TR808009	PC: 27 [CC32: 2] Dance	PC: 33 [CC32: 2] Jazz	PC: 41 [CC32: 2] Brush	PC: 49 [CC32: 2] ORCHSTRA	
C-1	0										
	1										
	2										
	3										
	4										
	5										
	6										
	7										
	8										
	9										
	10										
	11										
C0	12										
	13										
	14										
	15										
	16										
	17										
	18										
	19										
	20										
	21										
	22										
	23										
C1	24										
	25	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	
	26	Finger Snaps2	Finger Snap	Finger Snap	Finger Snaps2	Finger Snap	Finger Snaps2	Finger Snap	Finger Snap	Finger Snap	
	27	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q	High-Q	Jazz Clid HH	
	28	Slap	Slap	Slap	Slap	Slap	Slap	Slap	Slap	Pedal HHat	
	29	ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush2	ScratchPush2	ScratchPush	ScratchPush	Jazz Open HH	
	30	ScratchPull	ScratchPull	ScratchPull	ScratchPull	ScratchPull2	ScratchPull2	ScratchPull	ScratchPull	Ride Cymbal	
	31	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks	
	32	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	
	33	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click	Mtrnm Click	
	34	Mtrnm Bell	Mtrnm Bell	Mtrnm Bell	Mtrnm Bell	Mtrnm Bell	Mtrnm Bell	Mtrnm Bell	Mtrnm Bell	Mtrnm Bell	
C2	35	855t BdDrum1	Std2 Kick2	85Rm BdDrum1	Power Kick1	Elec Kick 2	808 BD	TR-909 BD2	BZ1z BdDrum1	Jazz Kick 2	Jazz Kics 1
	36	855t BdDrum2	Std 2 Kick1	85Rm BdDrum2	Power Kick1	Elec Kick 1	TR-808 Kick	Techno BD2	BZ1z BdDrum2	Jazz Kick 1	Concert BD
	37	Side Stick	Side Stick	Side Stick	Side Stick	Side Stick	808 Rimpot	Side Stick	Side Stick	Side Stick	Side Stick
	38	855t Snare2	Std.2 Snare1	BZ1m Snare2	Dance Snare1	Elec Snare	808 Snare 1	Dance Snare1	BZ1z Snare1	Brush Swirl	Concert Sni
	39	909 HandClap	808clap	808clap	808clap	808clap	909 HandClap	Hand clap2	Brush Swirl	Catarnets	Catarnets
	40	855t Snare1	Std.2 Snare2	BZ1m Snare1	Power Snare1	Elec Snare 2	TR-808 SD2	Power Snare1	BZ1z Snare1	Brush Swirl	Concert Sni
	41	Real Tom 6	Real Tom 6	Room Tom 5	Rock Tom 4	Synth Drum 2	808 Tom 2	Synth Drum 2	Real Tom 6	Lite Tom 4	Tempari
	42	Close HHat2	Close HHat2	Room Chh	Close HHat2	Jazz Clid HH	TR-808 CHH	CR-78 chh	Jazz Clid HH	Brs Chh	Tempari
	43	Real Tom 6	Real Tom 6	Room Tom 5	Rock Tom 4	Synth Drum 2	808 Tom 2	Synth Drum 2	Real Tom 6	Lite Tom 4	Tempari
	44	Pedal HHat2	Pedal HHat2	Pedal HHat	Pedal HHat2	Fedat HHat	808_chh	808_chh	Pedal HHat	Pedal HHat	Tempari
	45	Real Tom 4	Real Tom 4	Room Tom 2	Rock Tom 4	Synth Drum 2	808 Tom 2	Synth Drum 2	Real Tom 4	Lite Tom 4	Tempari
	46	Open HHat2	Jazz Open HH	RB Ohh2	Open HHat2	Jazz Open HH	TR-808 OHH	CR-78 ohh	Jazz Open HH	Brush Ohh	Tempari
	47	Real Tom 4	Real Tom 4	Room Tom 2	Rock Tom 4	Synth Drum 2	808 Tom 2	Synth Drum 2	Real Tom 4	Lite Tom 4	Tempari
	48	Real Tom 1	Real Tom 1	Room Tom 2	Rock Tom 1	Synth Drum 2	808 Tom 2	Synth Drum 2	Real Tom 1	Lite Tom 4	Tempari
	49	Crash Cym 1	Crash Cym 1	Crash Cym 1	Crash Cym 1	Crash Cym 1	808 Crash	808 Crash	Crash Cym 1	Brush Crash	Tempari
	50	Real Tom 1	Real Tom 1	Room Tom 2	Rock Tom 1	Synth Drum 2	808 Tom 2	Synth Drum 2	Real Tom 1	Lite Tom 4	Tempari
	51	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal	808 Ride Cym	808 Ride Cym	Ride Cym RH	Ride Cym RH	Tempari
	52	ChinaCymbal	ChinaCymbal	ChinaCymbal	ChinaCymbal	ReverseCymbal	ChinaCymbal	ReverseCymbal	ChinaCymbal	ChinaCymbal	Tempari
	53	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell	Brush RideBL	Tempari
	54	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	CR78 Tmb	Shake Tamb	Tambourine	Tambourine	Tambourine
	55	Splash Cym	Splash Cym	Splash Cym	Splash Cym	Splash Cym	Splash Cym	Splash Cym	Splash Cym	Splash Cym	Splash Cym
	56	Cowbell	Cowbell	Cowbell	Cowbell	Cowbell	808Cowse	Cowbell	Cowbell	Cowbell	Cowbell
	57	Crash Cym 2	Crash Cym 2	Crash Cym 2	Crash Cym 2	Crash Cym 2	808Crash	Crash Cym 2	Crash Cym 2	Crash Cym 2	Con Cymbal2
	58	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Vibraslap
	59	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal	RideCym Edge	Ride Cymbal	RideCym Edge	RideCym Edge	Concert Cym
C4	60	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High
	61	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo	Bongo Lo
	62	Mute H Conga	Mute H Conga	Mute H Conga	Mute H Conga	Mute H Conga	808 Conga	Mute H Conga	Mute H Conga	Mute H Conga	Mute H Conga
	63	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	808 Conga	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn
	64	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	808 Conga	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn
	65	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	66	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
	67	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo
	68	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo
	69	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
	70	Maracas	Maracas	Maracas	Maracas	Maracas	808marac	Maracas	Maracas	Maracas	Maracas
	71	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle
C5	72	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle	LongWhistle
	73	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro	CR78 Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro
	74	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro	CR78 Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro
	75	Claves	Claves	Claves	Claves	Claves	808Clave	Claves	Claves	Claves	Claves
	76	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
	77	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
	78	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Hoo	Hoo	Mute Cuica	Mute Cuica	Mute Cuica
	79	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Hoo	Hoo	Open Cuica	Open Cuica	Open Cuica
	80	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl
	81	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl
	82	Shaker	Shaker	Shaker	Shaker	Shaker	826 Shaker	826 Shaker	Shaker	Shaker	Shaker
	83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
C6	84	Bell Tree	Bar Chimes	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
	85	Catarnets	Catarnets	Catarnets	Catarnets	Catarnets	Catarnets	Catarnets	Catarnets	Catarnets	Catarnets
	86	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
	87	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo
	88										Alptiane
	89										
	90										
	91										
	92										
	93										
	94										
C7	95										



	PC: 50 [CC32: 2] Ethnic	PC: 51 [CC32: 2] KICK&SNR	PC: 52 [CC32: 2] Oriental	PC: 57 [CC32: 2] SFX	PC: 58 [CC32: 2] Rhythm FX	PC: 128 [CC32: 2] CM64/321	PC: 1 [CC32: 1] Standard	PC: 9 [CC32: 1] Room	PC: 17 [CC32: 1] Power	PC: 25 [CC32: 1] ELECTRIC
C-1	0									
	1									
	2									
	3									
	4									
	5									
	6									
	7									
	8									
	9									
	10									
	11									
C0	12									
	13									
	14									
	15									
	16									
	17									
	18									
	19									
	20									
	21									
	22									
	23									
C1	24									
	25	Finger Snap								
	26	Tambourine								
	27	Castanets					High-Q	High-Q	High-Q	High-Q
	28	Crash Cym 1					Slap	Slap	Slap	Slap
	29	Snare Roll					ScratchPush	ScratchPush	ScratchPush	ScratchPush2
	30	Concert Snr					ScratchPull	ScratchPull	ScratchPull	ScratchPull2
	31	Concert Cym		Scratch Push2			Sticks	Sticks	Sticks	Sticks
	32	Concert BD		Scratch Pull2			SquareClick	SquareClick	SquareClick	SquareClick
	33	Jingle Bell		GL CutNoise2			Mtrm Click	Mtrm Click	Mtrm Click	Mtrm Click
	34	Bell Tree		GL CutNoise2			Mtrm Bell	Mtrm Bell	Mtrm Bell	Mtrm Bell
	35	Bar Chimes	TR-707 BD	Dist.CutNoise		Kick 1	B55m BdDrum1	B55m BdDrum1	Power Kick2	Elec Kick 2
C2	36	Wadako	TR-707 BD	Dist.CutNoise	Rev Kick 1	Kick 1	B55m BdDrum2	B55m BdDrum2	Power Kick1	Elec Kick 1
	37	Wadako Rim	TR-707 Rim	Bass Slide	Rev ConBD	Side Stick	B55m BdDrum2	B55m BdDrum2	Side Stick	Side Stick
	38	Shmedako	TR-707 SD	Pick Strape	Rev PowerK1	Far Snare	B55m Snare2	B55m Snare2	Elec Snare1	Elec Snare
	39	Atarigane	Hand Clap 22	High-Q	Rev Elec K1	Hand Clap	909 HandClap	909 HandClap	B8Bclap	B8Bclap
	40	Hyoushup	Std 1 Kick1	Slap	Rev Snare 1	Elec. Snare	B55m Snare1	B55m Snare1	Power Snare1	Elec Snare 2
	41	Dhawa	Std 1 Kick2	Tom	ScratchPush	Rev Snare 2	Tom	Room Tom 5	Room Tom 5	Jazz Drum 2
	42	H Kotsuzum	Std 2 Kick1	TR-707 HH-c	ScratchPull	Rev Std1SD1	Close HHat	Room Cth	Close HHat2	Jazz Clst HH
	43	I Kotsuzum	Std 2 Kick2	Tom	Sticks	Rev TightSD1	Tom	Room Tom 6	Room Tom 6	Synth Drum 2
	44	Ban Gu	Kick 1	TR-707 HH-c	SquareClick	Rev DarceSD	Open HHat2	Pedal HHat	Pedal HHat2	Pedal HHat
	45	Big Gong	Kick 2	Tom	Mtrm Bell	Rev B8BSD	Tom	Room Tom 4	Room Tom 4	Synth Drum 2
	46	Small Gong	Soft Kick	TR-707 HH-o	Mtrm Bell	Rev Tom 1	Open H. Hat	Open HHat2	Open HHat2	Jazz Open HH
	47	Bend Gong	Jazz Kick 1	Tom	GL FretNoise	Rev Tom 2	Tom	Room Tom 4	Room Tom 4	Synth Drum 2
C3	48	RAMA Cymbal	Jazz Kick 2	Tom	GL CutNoise	Rev Sticks	Tom	Room Tom 1	Room Tom 1	Synth Drum 2
	49	RAMA Cymbal	Concert BD	TR-707 Crash	GL CutNoise	Rev Slap	GS Crash	Crash Cym 1	Crash Cym 1	Crash Cym 1
	50	Gamelan Gong	Room Kick 1	Tom	String Slap	ReverseCymbal	Tom	Room Tom 2	Room Tom 2	Synth Drum 2
	51	Lido Short	Room Kick 2	Ride Cymbal	Fl.KeyClick	Rev Cymbal2	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal
	52	Lido Long	Power Kick1	Dholaz Dom2	Laughing	Rev Open HH	ChnaCymbal	ChnaCymbal	ChnaCymbal	ReverseCymbal
	53	Lido Slap	Power Kick2	Dholaz 2 Sak	Screaming	Rev RideCym	---	Ride Bell	Ride Bell	Ride Bell
	54	Bendir	Elec Kick 2	Tambourine	Punch	Rev CR-78DH	Tambourine	Tambourine	Tambourine	Tambourine
	55	Req Dqm	Elec Kick 1	Dholaz Rim1	Heart Beat	Rev Chd HH	---	Splash Cym	Splash Cym	Splash Cym
	56	Req tk	Elec. Kick	Cowbell	Footsteps	Rev BendGong	Cowbell	Cowbell	Cowbell	Cowbell
	57	Tabla Te	TR-808 Kick	Dholaz RimC	Footsteps	Rev BellTree	---	Crash Cym 2	Crash Cym 2	Crash Cym 2
	58	Tabla Na	TR-909 Kick	Cabasa	Applause	Rev Guero	---	Vibraslap	Vibraslap	Vibraslap
	59	Tabla Lun	Dance Kick 2	Doff 2 Dom 2	Creaking	Rev Bendrf	---	Ride Cymbal	Ride Cymbal	Ride Cymbal
C4	60	Tabla Ge	Std 1 Snare1	Doff2 Sak 1B	Door	Rev Gurfhr	High Bongo	Bongo High	Bongo High	Bongo High
	61	Tabla Ge Hi	Std 1 Snare2	Low Bongo	Scratch	Rev Scratch	Low Bongo	Bongo Lo	Bongo Lo	Bongo Lo
	62	Talking Drum	Std 2 Snare1	Doff 2 Sak 2	Wind Chimes	Rev Lasegun	Low Bongo	Mute H Conga	Mute H Conga	Mute H Conga
	63	Req tk dr	Std 2 Snare2	High Bongo	Car. Engine	Click	Conga	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn
	64	Casin	Tight Snare	Doff 2 Rim 3	Car. Stop	Tekno Thip	Conga	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn
	65	Dimbaz	Concert Snr	Tabla1 Dom 2	Car. Pass	Pop Drop	Tembales	High Timbale	High Timbale	High Timbale
	66	Dymbaz Jm	Jazz Snare 1	Tabla1 Rim1	Car. Crash	Wood Slap	Tembales	Low Timbale	Low Timbale	Low Timbale
	67	Low Timbale	Jazz Snare 2	Tabla 2 Sak	Siren	Dist Kick	Agogo	Agogo	Agogo	Agogo
	68	Tabla Pala	Room Snare 1	Tabla Fx	Train	Syn Drops	Agogo	Agogo	Agogo	Agogo
	69	High Timbale	Room Snare 2	Tabla2 Tak1D	Jetplane	Rev Hi-Q	Cabasa	Cabasa	Cabasa	Cabasa
	70	Cowbell	Dance Snare1	Tabla 2 Tak	Helicopter	ShriWhistle	Maracas	Maracas	Maracas	Maracas
	71	Bongo High	Power Snare1	Tabla2 Rim 2	Starship	Ice Block	ShriWhistle	ShriWhistle	ShriWhistle	ShriWhistle
C5	72	Bongo Lo	Rev Snare	Rek 2 Dom 1B	Gun Shot	Dip-Tambn	LongWhistle	LongWhistle	LongWhistle	LongWhistle
	73	Mute H Conga	Power Snare2	Rek 2 Rim 2	Machine Gun	Alias	Vibraslap	Short Guiro	Short Guiro	Short Guiro
	74	Conga Hi Opn	Elec Snare 1	Rek 2 Dom 1	Lasegun	Wood Bell	Long Guiro	Long Guiro	Long Guiro	Long Guiro
	75	Conga MLOw	Dance Snare2	Rek 2 Tak 1	Explosion	Tambourine	Claves	Claves	Claves	Claves
	76	Conga Slap	Elec Snare 2	Rek 2 Sak 2C	Dog	Mesic Perc	Woodblock	Woodblock	Woodblock	Woodblock
	77	Conga Lo Opn	House Snare	Rek 2 Sak 1	HorseGallop	Valo FX Hoaz	Screaming	Woodblock	Woodblock	Woodblock
	78	Conga Slide	Elec. Snare	Hager 2	Bird	St.HoneClap	Punch	Mute Cuica	Mute Cuica	Mute Cuica
	79	Mut Panderio	Elec Snare 3	Rek2Xhan Cl2	Rain	Swish	Heart Beat	Open Cuica	Open Cuica	Open Cuica
	80	Open Panderio	B08 Snare 1	Zir 2	Thunder	Nose Slap	Footstep	MuteTriangl	MuteTriangl	MuteTriangl
	81	Mute Surdo	B08 Snare 2	Rek2Xhan Clp2	Wind	Voice 1	Footsteps	OpenTriangl	OpenTriangl	OpenTriangl
	82	Mute Surdo	909 Snare 1	Rek 2 Sak 1	Seashore	Voice Au	Applause	Shaker	Shaker	Shaker
	83	Tamborim	909 Snare 2	Rek 2 Sak 1	Stream	Hoo	Creaking	Jingle Bell	Jingle Bell	Jingle Bell
C6	84	Agogo	Brush Swrl	Sagar Md	Bubble	Tap Stop 1	Door	Bell Tree	Bell Tree	Bell Tree
	85	Agogo	Brush Tap	Sagar Hi	Kitty	Tap Stop 2	Scratch	Castanets	Castanets	Castanets
	86	Low Whistle	Brush Slap2	Sagar Sak	Bird 2	Mesic	Wind Chimes	Mute Surdo	Mute Surdo	Mute Surdo
	87	Shri Whistle	Brush Slap2	Jingle Bell	Growl	Spare Birds	Car.Engine	Open Surdo	Open Surdo	Open Surdo
	88	Mute Cuica	Brush Swrl	ZaghrouaEd3	Telephone 1	---	---	---	---	---
	89	Open Cuica	Brush Swrl	Tabla1RimDom3	Telephone 2	---	---	---	---	---
	90	MuteTriangl	Long Swrl	Nakrazhan 1	---	---	---	---	---	---
	91	OpenTriangl	---	Tabla1Rim2	---	---	---	---	---	---
	92	Short Guiro	---	Nakrazhan 2	---	---	---	---	---	---
	93	Long Guiro	---	Tabla1RimTak3	---	---	---	---	---	---
	94	Cabasa Up	---	TR-707 BD	---	---	---	---	---	---
C7	95	Cabasa Dnm	---	Hand Clap 1	---	---	---	---	---	---

REFERENCE

Drum Sets



































































	PC: 50 [CC32: 2] Ethnic	PC: 51 [CC32: 2] MICK&SHR	PC: 52 [CC32: 2] Oriental	PC: 57 [CC32: 2] SFX	PC: 58 [CC32: 2] Rhythre FX	PC: 128 [CC32: 2] CM64/32L	PC: 1 [CC32: 1] Standard	PC: 9 [CC32: 1] Room	PC: 17 [CC32: 1] Power	PC: 25 [CC32: 1] ELECTRNC
(CT) 96	(Cabasa Down)	(--)	(--)	(--)	(--)	(Gun Shot)	(--)	(--)	(--)	(--)
96	Claves	---	---	---	---	Machine Gun	---	---	---	---
98	Woodblock	---	---	---	---	Lasergun	---	---	---	---
99	Woodblock	---	---	---	---	Explosion	---	---	---	---
100	---	---	---	---	---	Dog	---	---	---	---
101	---	---	---	---	---	HorseGallop	---	---	---	---
102	---	---	---	---	---	Bird	---	---	---	---
103	---	---	---	---	---	Rain	---	---	---	---
104	---	---	---	---	---	Thunder	---	---	---	---
105	---	---	---	---	---	Wind	---	---	---	---
106	---	---	---	---	---	Seashore	---	---	---	---
107	---	---	---	---	---	Stream	---	---	---	---
108	---	---	---	---	---	Bubble	---	---	---	---
109	---	---	---	---	---	---	---	---	---	---
110	---	---	---	---	---	---	---	---	---	---
111	---	---	---	---	---	---	---	---	---	---
112	---	---	---	---	---	---	---	---	---	---
113	---	---	---	---	---	---	---	---	---	---
114	---	---	---	---	---	---	---	---	---	---
115	---	---	---	---	---	---	---	---	---	---
116	---	---	---	---	---	---	---	---	---	---
117	---	---	---	---	---	---	---	---	---	---
118	---	---	---	---	---	---	---	---	---	---
119	---	---	---	---	---	---	---	---	---	---
120	---	---	---	---	---	---	---	---	---	---
121	---	---	---	---	---	---	---	---	---	---
122	---	---	---	---	---	---	---	---	---	---
123	---	---	---	---	---	---	---	---	---	---
124	---	---	---	---	---	---	---	---	---	---
125	---	---	---	---	---	---	---	---	---	---
126	---	---	---	---	---	---	---	---	---	---
127	---	---	---	---	---	---	---	---	---	---

	PC: 26 [CC32: 1] TR-808	PC: 33 [CC32: 1] Jazz	PC: 41 [CC32: 1] Brass	PC: 49 [CC32: 1] ORCHSTRA	PC: 57 [CC32: 1] SFX	PC: 128 [CC32: 1] CM64/32L
(CT) 96	(--)	(--)	(--)	(--)	(--)	(Gun Shot)
96	---	---	---	---	---	Machine Gun
98	---	---	---	---	---	Lasergun
99	---	---	---	---	---	Explosion
100	---	---	---	---	---	Dog
101	---	---	---	---	---	HorseGallop
102	---	---	---	---	---	Bird
103	---	---	---	---	---	Rain
104	---	---	---	---	---	Thunder
105	---	---	---	---	---	Wind
106	---	---	---	---	---	Seashore
107	---	---	---	---	---	Stream
108	---	---	---	---	---	Bubble
109	---	---	---	---	---	---
110	---	---	---	---	---	---
111	---	---	---	---	---	---
112	---	---	---	---	---	---
113	---	---	---	---	---	---
114	---	---	---	---	---	---
115	---	---	---	---	---	---
116	---	---	---	---	---	---
117	---	---	---	---	---	---
118	---	---	---	---	---	---
119	---	---	---	---	---	---
120	---	---	---	---	---	---
121	---	---	---	---	---	---
122	---	---	---	---	---	---
123	---	---	---	---	---	---
124	---	---	---	---	---	---
125	---	---	---	---	---	---
126	---	---	---	---	---	---
127	---	---	---	---	---	---

	PC: 26 [CC32: 1] TR-808	PC: 33 [CC32: 1] Jazz	PC: 41 [CC32: 1] Brush	PC: 49 [CC32: 1] ORCHSTRA	PC: 57 [CC32: 1] SFX	PC: 128 [CC32: 1] CM64/32L
C-1	10	---	---	---	---	---
	11	---	---	---	---	---
	12	---	---	---	---	---
	13	---	---	---	---	---
	14	---	---	---	---	---
	15	---	---	---	---	---
	16	---	---	---	---	---
	17	---	---	---	---	---
	18	---	---	---	---	---
	19	---	---	---	---	---
	20	---	---	---	---	---
	21	---	---	---	---	---
	22	---	---	---	---	---
	23	---	---	---	---	---
C1	24	---	---	---	---	---
	25	---	---	---	---	---
	26	---	---	---	---	---
	27	High-Q	High-Q	High-Q	Jazz Clsd.HH	---
	28	Slap	Slap	Slap	Pedal HHat	---
	29	Scrth Push2	ScratchPush	ScratchPush	Jazz Open HH	---
	30	Scrth Pull2	ScratchPull	ScratchPull	Ride Cymbal	---
	31	Sticks	Sticks	Sticks	Sticks	---
	32	SquareClick	SquareClick	SquareClick	SquareClick	---
	33	Mtrm Click	Mtrm Click	Mtrm Click	Mtrm Click	---
	34	Mtrm Bell	Mtrm Bell	Mtrm Bell	Mtrm Bell	---
	35	808 BD	82jr BDrum1	Jazz Kick 2	Jazz Kick 1	Kick 1
	36	TR-808 Kick	82jr BDrum2	Jazz Kick 1	Concert BD	Kick 1
	37	808 Rimshot	Side Stick	Side Stick	Side Stick	Side Stick
	38	808 Snare 1	82jr Snare1	Brush Swirl	Concert Snr	Snare
	39	808 Clap	Hand Clap2	Brush Slap1	Castanets	High Q
	40	TR-808 SD2	82jr Snare2	Brush Swirl	Concert Snr	Slap
	41	808 Tom 2	Real Tom 6	Lite Tom 4	Timpani	ScratchPush
	42	TR-808 CHH	Jazz Clsd HH	Brs Chh	Timpani	ScratchPull
	43	808 Tom 2	Real Tom 6	Lite Tom 4	Timpani	Sticks
	44	808 Chh	Pedal HHat	Pedal HHat	Timpani	SquareClick
	45	808 Tom 2	Real Tom 4	Lite Tom 4	Timpani	Mtrm Click
	46	TR-808 OHH	Jazz Open HH	Brush Chh	Timpani	Mtrm Bell
	47	808 Tom 2	Real Tom 4	Lite Tom 4	Timpani	Gl FretNoise
	48	808 Tom 2	Real Tom 1	Lite Tom 4	Timpani	Gl CutNoise
	49	808 Crash	Crash Cym 1	Brush Crash	Timpani	Gl CutNoise
	50	808 Tom 2	Real Tom 7	Lite Tom 8	Timpani	String Slap
	51	808 Ride Cym	Ride Cym III	Ride Cym III	Timpani	FlKeyClick
	52	ChinaCymbal	ChinaCymbal	ChinaCymbal	Timpani	Laughing
	53	Ride Bell	Ride Bell	Brush RideBt	Timpani	Screaming
	54	Tambourine	Tambourine	Tambourine	Tambourine	Punch
	55	Splash Cym	Splash Cym	Splash Cym	Splash Cym	Heart Beat
	56	808 Cowbell	Cowbell	Cowbell	Cowbell	Cowbell
	57	809 Crash	Crash Cym 2	Crash Cym 2	Con Cymbal2	Footsteps
	58	Vibraslap	Vibraslap	Vibraslap	Vibraslap	Applause
	59	RideCym Edge	RideCym Edge	RideCym Edge	Concert Cym	Creeping
C8	60	High Bongo	Bongo High	Bongo High	Bongo High	Door
	61	Low Bongo	Bongo Lo	Bongo Lo	Bongo Lo	Scratch
	62	808 Conga	Mute H Conga	Mute H Conga	Mute H Conga	Wind Chimes
	63	808 Conga	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	Car-Engine
	64	808 Conga	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	Car-Stop
	65	High Timbale	High Timbale	High Timbale	High Timbale	Car-Pass
	66	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Car-Crash
	67	Agogo	Agogo	Agogo	Agogo	Siren
	68	Agogo	Agogo	Agogo	Agogo	Train
	69	Cabasa	Cabasa	Cabasa	Cabasa	Jetplane
	70	808 Maracas	Maracas	Maracas	Maracas	Helicopter
	71	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	Starship
C5	72	LongWhistle	LongWhistle	LongWhistle	LongWhistle	Gun Shot
	73	Shrt Guiro	Shrt Guiro	Shrt Guiro	Shrt Guiro	Machine Gun
	74	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Lazergun
	75	808 Claves	Claves	Claves	Claves	Explosion
	76	Woodblock	Woodblock	Woodblock	Woodblock	Dog
	77	Woodblock	Woodblock	Woodblock	Woodblock	Horse Gallop
	78	Mute Cuca	Mute Cuca	Mute Cuca	Mute Cuca	Bird
	79	Open Cuca	Open Cuca	Open Cuca	Open Cuca	Rain
	80	Mute Triangl	Mute Triangl	Mute Triangl	Mute Triangl	Thunder
	81	Open Triangl	Open Triangl	Open Triangl	Open Triangl	Wind
	82	6/8 Shaker	Shaker	Shaker	Shaker	Footsteps
	83	Jingle Bell	Jingle Bell	Jingle Bell	Jingle Bell	Seashore
	84	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Stream
C6	85	Castanets	Castanets	Castanets	Castanets	Bubble
	86	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Door
	87	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Scratch
	88	---	---	---	---	---
	89	---	---	---	---	---
	90	---	---	---	---	---
	91	---	---	---	---	---
	92	---	---	---	---	---
	93	---	---	---	---	---
	94	---	---	---	---	---
	95	---	---	---	---	---
C7	96	---	---	---	---	---

REFERENCE

# 24. Chord Intelligence

C	C#	D	E $\flat$	E	F
					
CM7	C#M7	DM7	E $\flat$ M7	EM7	FM7
					
C7	C#7	D7	E $\flat$ 7	E7	F7
					
Cm	C#m	Dm	E $\flat$ m	Em	Fm
					
Cm7	C#m7	Dm7	E $\flat$ m7	Em7	Fm7
					
CmM7	C#mM7	DmM7	E $\flat$ mM7	EmM7	FmM7
					
Cdim	C#dim	Ddim	E $\flat$ dim	Edim	Fdim
					
Cm7 (b5)	C#m7 (b5)	Dm7 (b5)	E $\flat$ m7 (b5)	Em7 (b5)	Fm7 (b5)
					
Caug	C#aug	Daug	E $\flat$ aug	Eaug	Faug
					
Csus4	C#sus4	Dsus4	E $\flat$ sus4	Esus4	Fsus4
					
C7sus4	C#7sus4	D7sus4	E $\flat$ 7sus4	E7sus4	F7sus4
					

F#	G	A $\flat$	A	B $\flat$	B
F#M7	GM7	A $\flat$ M7	AM7	B $\flat$ M7	BM7
F#7	G7	A $\flat$ 7	A7	B $\flat$ 7	B7
F#m	Gm	A $\flat$ m	Am	B $\flat$ m	Bm
F#m7	Gm7	A $\flat$ m7	Am7	B $\flat$ m7	Bm7
F#mM7	GmM7	A $\flat$ mM7	AmM7	B $\flat$ mM7	BmM7
F#dim	Gdim	A $\flat$ dim	Adim	B $\flat$ dim	Bdim
F#m7 (b5)	Gm7 (b5)	A $\flat$ m7 (b5)	Am7 (b5)	B $\flat$ m7 (b5)	Bm7 (b5)
F#aug	Gaug	A $\flat$ aug	Aaug	B $\flat$ aug	Baug
F#sus4	Gsus4	A $\flat$ sus4	Asus4	B $\flat$ sus4	Bsus4
F#7sus4	G7sus4	A $\flat$ 7sus4	A7sus4	B $\flat$ 7sus4	B7sus4

REFERENCE

# MIDI Implementation Chart

[Interactive Keyboard]  
Model: EM-55

Date: October 2001  
Version: 1.00

Function...		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	1~16 1~16, Off	1~16 1~16, Off	32 Parts 2 Logical Parts
Mode	Default Message Altered	Mode 3 Mode 3, 4 (M=1) *****	Mode 3 Mode 3, 4 (M=1)	*2
Note Number	True Voice	0~127 *****	0~127 0~127	
Velocity	Note ON Note OFF	O X	O X	
After Touch	Key's Ch's	X X	O O	
Pitch Bend		O *1	O *1	
Control Change	0,32	O *1	O	Bank Select
	1	O *1	O	Modulation
	5	O	O	Portamento Time
	6, 38	O	O	Data Entry
	7	O	O	Volume
	10	O	O	Panpot
	11	O	O	Expression
	64	O	O	Hold 1
	65	X	O	Portamento
	66	X	O	Sostenuto
	67	X	O	Soft
	84	O	O	Portamento Control
	91	O	O (Reverb)	Effect 1 Depth
93	O	O (Chorus)	Effect 3 Depth	
98, 99	O	O	NRPN LSB, MSB	
100, 101	O	O	RPN LSB, MSB	
Program Change	True #	O *****	O 0~127	Program Number 1~128
System Exclusive		)	O	
System Common	Song Position Pointer Song Sel Tune	X *1 X X	X X X	
System Real Time	Clock Commands	O *1 O *1	O O	
Aux Messages	All Sounds Off Reset All Controllers Local On/Off All Notes Off Active Sense Reset	X X *1 O X O X	O (120, 126, 127) O (121) O O (123-125) O X	
Notes		*1 O X is selectable *2 Recognized as M=1 even if M≠1		

Mode 1: OMNI ON, POLY  
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO  
Mode 4: OMNI OFF, MONO

O: Yes  
X: No



 Roland®

**K6018455**

UPC

K6018455



10981

VI-333

**Roland**

602.15.3478

RAM RES 318-02 - Printed in Italy by Alda Tecnografica srl -02-02 EM-55 E/Sp/F