


ANATEK

MIDIMATCH

OPERATING
INSTRUCTIONS



MIDI Match™

FEATURES

- Sends MIDI data up to 4000 feet
- Uses standard audio cable
- ◆ Immune to noise/interference
- ◆ XLR audio inputs/outputs
- ◆ Dual independent circuitry

APPLICATIONS

- ◆ Remote control MIDI lighting equipment
- ◆ Send MIDI through audio snake
- ◆ Use existing studio wiring for MIDI
- ◆ Church and auditorium MIDI transmission


HOW MIDIMATCH WORKS

The MIDIMatch system consists of two identical, bi-directional MIDIMatch units, one for each end of the line. MIDI signals are converted to a balanced signal that can be transmitted over long distances while remaining immune to noise and interference. Each unit contains a separate receiver and transmitter, making simultaneous receiving and transmitting of different MIDI data possible. Two LEDs on each unit monitor incoming MIDI data from either the XLR inputs or the MIDI inputs in addition to indicating 9v power.


BASIC HOOKUP

- 1) Connect a 9v power supply to each MIDIMatch.
- 2) Connect a cable from the output of your MIDI device to the MIDI input on the transmitting MIDIMatch.
- 3) Connect an standard XLR-equipped 2 conductor + shield audio cable from the transmitting MIDIMatch to the receiving MIDIMatch.
- 4) Send MIDI data. The receiving MIDIMatch's LED will blink off then back on confirming the presence of data.

One-Way Communication



Bi-Directional Communication



LIMITED WARRANTY

Creation Technologies Inc. warrants this product to be free from manufacturer's defects for a period of ONE YEAR from the date of purchase. This warranty is void if the unit is opened or tampered with, if the unit is immersed in any liquid, or if the unit is connected to any device that does not meet standard MIDI specifications. Should the product prove to be defective within the warranty period, Creation shall repair or replace the unit at our election and sole expense (with the exception of shipping, which Creation will pay one way). Creation makes no other warranties, express or implied, including, but not limited to, any implied warranties of merchantability or fitness for a particular purpose. In no event shall Creation be liable for loss of profits or benefits, indirect, special, consequential or other similar damages arising out of any breach of this warranty or otherwise.

ANALIK

Distributed by Creation Technologies
400 Brooksbank Ave.

N. Vancouver, B.C. Canada V7J-1G9
Ph: 604-980-6850 Fax: 604-980-6711

Printed in Canada