Pocket Filter™ Helpful Hints

Congratulations on your purchase of Pocket Filter™. Anatek's Pocket Products™ are the ultimate in MIDI accessory convenience: compact, simple to use, and require no batteries or external power supply.

FEATURES

- Requires no batteries or AC adaptors
- Filters several data types:
 - Polyphonic and Channel Aftertouch (Pressure)
 - All Controllers (Modulation, Breath Controller, MIDI Volume, Sustain Pedal, etc.)
 - Pitch Bender
 - Program Changes
 - Note ON and Note OFF events
 - System Exclusive
 - MIDI Clock (Start/Stop/Continue and Song Position Pointer)
 - Active Sensing
- Filters on one, several or all 16 MIDI channels
- One or more data types can be selected simultaneously
- Fully microprocessor controlled
- Uses ultra-fast data handling technology
- Works with all other Pocket Products™
- Can be used with Velcro or double-sided tape to attach Pocket Filter™ to a keyboard or other Pocket Products™

APPLICATIONS

- Filter Aftertouch to save sequencer memory
- Allow a sound module to respond to patch changes only on selected MIDI channels
- Remove pitch bender information
- Remove patch change information
- Remove System Exclusive information
- Remove MIDI Clock and Active Sensing
- Update keyboard or sound module that doesn't allow selective filtering of different MIDI data types
- Channelize older synths (Memorymoog, etc.) that only respond to OMNI mode. Use "ALL" and select filtering on every MIDI channel except for the channel you wish to receive on

OTHER PRODUCTS

Anatek's Pocket Product[™] line includes: Pocket Filter[™], Pocket Merge[™], Pocket Pedal[™], and Pocket Sequencer[™] — with more Pocket Products[™] to be released soon. For further information on these products, please write to:

Anatek Microcircuits Inc.

Music Products Division 400 Brooksbank Avenue, North Vancouver, B.C. Canada V7J 1G9 PHONE: (604) 980-6850 FAX: (604) 980-2722

LIMITED WARRANTY

Anatek Microcircuits Inc. warrants this product to be free from manufacturer's defects for a period of ONE YEAR from the date of purchase. This warranty is void if the unit is opened or tampered with, if the unit is immersed in any liquid, or if the unit is connected to any device that does not meet standard MIDI specifications. Should the product prove to be defective within the warranty period, Anatek shall repair or replace the unit at our election and sole expense (with the exception of shipping, which Anatek will pay one way). Anatek makes no other warranties, express or implied, including, but not limited to, any implied warranties of merchantability or fitness for a particular purpose. In no event shall Anatek be liable for loss of profits or benefits, indirect, special consequential or other similar damages arising out of any breach of this warranty or otherwise.

