

Pocket Panic™

Helpful Hints

Congratulations on your purchase of Pocket Panic™. Anatek's Pocket Products™ are the ultimate in MIDI accessory convenience: compact, simple to use, and require no batteries or external power supply.

FEATURES

- Requires no batteries or AC adaptors
- In-line MIDI Panic button
- Sends ALL NOTES OFF command on all channels
- Compatible with older MIDI synths that do not respond to the ALL NOTES OFF command
- Resets controllers
- Sends OMNI OFF command
- Filters the ALL NOTES OFF command
- Hands-free footswitch control (automatically adjusts to normally-open or normally-closed footswitches)
- "Transparent" operation (i.e. when Panic isn't being sent, all data is passed)
- Works with all Pocket Products™
- Compact and lightweight
- Can be used with Velcro or double-sided tape to attach Pocket Panic™ to a keyboard or to other Pocket Products™

APPLICATIONS

- Use in live MIDI applications whenever a "stuck" note occurs
- Use to reset controllers to their default settings
- Send an OMNI OFF command to a synth or sound module
- Filter-out the ALL NOTES OFF commands when they are sent too often (as with some keyboard controllers)
- Use Pocket Panic™ to enter an initialization sequence into a MIDI sequencer so that controllers are reset at the beginning of the song

OTHER PRODUCTS

Anatek's Pocket Product™ line includes: Pocket Merge™, Pocket Filter™, Pocket Pedal™, Pocket THRU™, Pocket Transpose™, Pocket Record™, Pocket Panic™, Pocket Split™, and Pocket Channel™—with more Pocket Products™ to be released soon. For further information on these products, please contact customer support at:

Anatek Microcircuits Inc.

Music Products Division

400 Brooksbank Avenue, North Vancouver, B.C. Canada V7J 1G9

PHONE: (604) 980-6850 FAX: (604) 980-2722

POCKET PANIC™
is a trademark of
Anatek Microcircuits Inc.
Music Products Division

ANATEK
©1989
MICROCIRCUITS INC.
MUSIC PRODUCTS DIVISION
MADE IN CANADA

LIMITED WARRANTY

Anatek Microcircuits Inc. warrants this product to be free from manufacturer's defects for a period of ONE YEAR from the date of purchase. This warranty is void if the unit is opened or tampered with, if the unit is immersed in any liquid, or if the unit is connected to any device that does not meet standard MIDI specifications. Should the product prove to be defective within the warranty period, Anatek shall repair or replace the unit at our election and sole expense (with the exception of shipping, which Anatek will pay one way). Anatek makes no other warranties, express or implied, including, but not limited to, any implied warranties of merchantability or fitness for a particular purpose. In no event shall Anatek be liable for loss of profits or benefits, indirect, special consequential or other similar damages arising out of any breach of this warranty or otherwise.