



## Instructions for BEHRINGER BCF2000 & 'Only Controllers' preset

### BEHRINGER BCF2000 Only Controllers

This document will give you a quick overview about the BEHRINGER BCF2000 'ONLY CONTROLLERS' PRESET and how to install it.

#### Installation:

##### 1. Open and extract the ZIP file.

The following files are included:

- This INSTRUCTION text document (.pdf)
- SINGLE PRESET file (.syx)

##### 2. How to get the B-CONTROL PRESET from your computer into your hardware:

- **Connect the B-Control to your computer** via USB or MIDI port (Computer MIDI OUT to B-Control MIDI IN)
- **Select the correct USB or stand alone operating mode** on the hardware (please refer to the manual for details)
- **Open the B-Control preset file with a MIDI dump program** like "MIDI-OX" or "Send SX" on your computer or use the B-CONTROL EDIT software editor, which is available free of charge at our homepage [www.behringer.com](http://www.behringer.com)
- Don't forget to **select the correct MIDI ports** into the dump software!

- **Dumping a single preset (SINGLE DUMP)**
  1. **Select the preset** ('bcf\_Only\_Controllers.syx') on your MIDI dump program
  2. **Send the preset** to the B-CONTROL and wait until completion
  3. **Push the STORE** button on the hardware
  4. **Select the desired destination** preset number
  5. **Push the STORE** button again
  6. **The preset is now saved** on your hardware
  7. Now you can dump the next preset (proceed with steps 1 thru 5 again)

**Hint:** If you do not want to overwrite one of your presets in the B-CONTROL hardware, select a vacant destination number during step 4 (e.g. preset 'P-32').

#	Name	Type	Description/Application
01	'bcf_Only_Controllers'	Single Preset	Contains all CC-commands from CC1 to CC 94 on MIDI channel 1 -> Perfect for the LEARN function in your music software studio/instrument/plug-in

**Preset Name:** BCF - Only Controllers

The image shows the Behringer BCF2000 MIDI controller interface. The main display area is a grid of MIDI CC assignments for a preset named 'BCF - Only Controllers'. The grid is organized into sections:

- Top Section:** A grid of 8 columns and 4 rows of CC assignments (Ch. 1). The first row contains CC 1 to CC 8. The second row contains CC 9 to CC 16. The third row contains CC 17 to CC 24. The fourth row contains CC 25 to CC 32.
- Middle Section:** A grid of 8 columns and 2 rows of CC assignments (Ch. 1). The first row contains CC 33 to CC 40. The second row contains CC 41 to CC 48.
- Bottom Section:** A grid of 8 columns and 1 row of CC assignments (Ch. 1), containing CC 81 to CC 88.

Additional interface elements include:

- Left Side:** A vertical column of buttons labeled E1, E2, E3, and E4.
- Right Side:** A 'FOOT-SW/CTRL' section with buttons for FS (Footswitch) and FC (Foot Controller), and a 'P- 1' display.
- Bottom Right:** A control panel with buttons for 'B-CONTROL FADER', 'B-CF2000', 'DUAL', 'LEARN', 'MIDI', and 'MIDI'. Below this are four buttons for CC 89, CC 90, CC 91, and CC 92 (all Ch. 1).

*Please consider this preset as a basic starting point for building up your individual edits/alignments.*

© 2004 BEHRINGER Spezielle Studiotechnik GmbH