


# CHORUS SPACE-D CD400

Digital 3-Dimensional Sound Effects Pedal

Thank you for showing your confidence in us by purchasing the BEHRINGER CHORUS SPACE-D CD400. This ultimate effects pedal is designed to suit almost any application you can think of. Add a breathtaking third dimension to your sound or instrument and experience the secret weapon of professional recording studios.

The chorus effect adds a shifting detuned signal to the original, similar to playing in unison in a group of instruments, and it is often used for dispersing sounds.

## 1. Controls



- 1 The **LEVEL** control adjusts the effect sound level.
- 2 The **EQ** control allows you to shape your overall effect sound. Turning it to the right will emphasize high frequencies while turning to the left will cut them.
- 3 The **RATE** control determines the chorus effect speed.
- 4 Turn up the **DEPTH** control to achieve a fuller and deeper effect sound.
- 5 The **ON/BATT** LED illuminates when the effect is activated. It also serves as a battery level indicator.
- 6 Use the footswitch to activate/deactivate the effect.
- 7 Use this ¼" TS **IN** connector to plug in the instrument cable.
- 8 The two ¼" TS **OUT A** and **OUT B** connectors send the signal to your amp. Use both connectors if you want to achieve full stereo chorus effect. For mono use plug in OUT A only.

Use the **DC IN** connection to plug in a 9 V power supply (not included).

The **BATTERY COMPARTMENT** is located underneath the pedal cover. To install or replace the 9 V battery (not included), press the hinges with a ballpoint pen and remove the pedal cover. Be careful not to scratch the unit.

- ◆ **The CD400 has no on/off switch. As soon as you insert the plug into the in connector, the CD400 begins running. When not using the DC400, remove the plug from the in connector. This extends the life of the battery.**

The **SERIAL NUMBER** is located at the underside.

- ◆ **In rare cases interferences of the normal function may appear by external influence (e.g. electrostatic discharge), as for example sound disturbances or malfunctions. If this occurs, please turn down the volume on subsequent amplifiers and disconnect the input connector briefly to restart the application.**

## 2. Safety Instructions

Do not use near water, or install near heat sources. Use only authorized attachments/accessories. Do not service product yourself. Contact our qualified servicing personnel for servicing or repairs, especially when power supply cord or plug is damaged.

## 3. Warranty

Please register your new BEHRINGER equipment right after your purchase by visiting <http://behringer.com> and read the terms and conditions of our warranty carefully.

## 4. Specifications

In	
Connector	¼" TS
Impedance	500 kΩ

Out A	
Connector	¼" TS
Impedance	1 kΩ

Out B	
Connector	¼" TS
Impedance	1 kΩ

Power Supply	
	9 V $\overline{\text{---}}$ , 100 mA regulated

### BEHRINGER PSU-SB

USA/Canada	120 V $\sim$ , 60 Hz
Europe/U.K./Australia	230 V $\sim$ , 50 Hz
China	220 V $\sim$ , 50 Hz
Korea	220 V $\sim$ , 60 Hz
Japan	100 V $\sim$ , 50/60 Hz

Power connector	2 mm DC jack, negative center
Battery	9 V type 6LR61
Power consumption	30 mA

Physical/Weight	
Dimensions (H x W x D)	approx. 2 ⅛ x 2 ¾ x 4 ⅞" approx. 54 x 70 x 123 mm
Weight	approx. 0.73 lbs / 0.33 kg

BEHRINGER is constantly striving to maintain the highest professional standards. As a result of these efforts, modifications may be made from time to time to existing products without prior notice. Specifications and appearance may therefore differ from those listed or shown.

TECHNICAL SPECIFICATIONS AND APPEARANCES ARE SUBJECT TO CHANGE WITHOUT NOTICE AND ACCURACY IS NOT GUARANTEED. BEHRINGER IS PART OF THE MUSIC GROUP (MUSIC-GROUP.COM). ALL TRADEMARKS ARE THE PROPERTY OF THEIR RESPECTIVE OWNERS. MUSIC GROUP ACCEPTS NO LIABILITY FOR ANY LOSS WHICH MAY BE SUFFERED BY ANY PERSON WHO RELIES EITHER WHOLLY OR IN PART UPON ANY DESCRIPTION, PHOTOGRAPH OR STATEMENT CONTAINED HEREIN. COLORS AND SPECIFICATIONS MAY VARY FROM ACTUAL PRODUCT. MUSIC GROUP PRODUCTS ARE SOLD THROUGH AUTHORIZED FULLFILLERS AND RESELLERS ONLY. FULLFILLERS AND RESELLERS ARE NOT AGENTS OF MUSIC GROUP AND HAVE ABSOLUTELY NO AUTHORITY TO BIND MUSIC GROUP BY ANY EXPRESS OR IMPLIED UNDERTAKING OR REPRESENTATION. THIS MANUAL IS COPYRIGHTED. NO PART OF THIS MANUAL MAY BE REPRODUCED OR TRANSMITTED IN ANY FORM OR BY ANY MEANS, ELECTRONIC OR MECHANICAL, INCLUDING PHOTOCOPYING AND RECORDING OF ANY KIND, FOR ANY PURPOSE, WITHOUT THE EXPRESS WRITTEN PERMISSION OF MUSIC GROUP IP LTD. ALL RIGHTS RESERVED. © 2012 MUSIC Group IP Ltd. Trident Chambers, Wickhams Cay, P.O. Box 146, Road Town, Tortola, British Virgin Islands