

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position




Heel or  
Not Connected


Name/Description: **Tube Drive**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup> <sub>FBDK</sub>



MID <sup>SUB/</sup> <sub>COMP</sub>



TREBLE <sup>JET</sup> <sub>RATE</sub>




VOLUME <sub>GATE</sub>

NOISE GATE


Name/Description: **Tube Drive**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup> <sub>FBDK</sub>



MID <sup>SUB/</sup> <sub>COMP</sub>



TREBLE <sup>JET</sup> <sub>RATE</sub>



VOLUME <sub>GATE</sub>

NOISE GATE



Toe

Expression Pedal Position




Heel or  
Not Connected


Name/Description: **Screamer**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup> <sub>FBDK</sub>



MID <sup>SUB/</sup> <sub>COMP</sub>



TREBLE <sup>JET</sup> <sub>RATE</sub>




VOLUME <sub>GATE</sub>

NOISE GATE


Name/Description: **Screamer**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup> <sub>FBDK</sub>



MID <sup>SUB/</sup> <sub>COMP</sub>



TREBLE <sup>JET</sup> <sub>RATE</sub>



VOLUME <sub>GATE</sub>

NOISE GATE



Toe

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position



Heel or Not Connected

Name/Description: **Overdrive**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE      BASS <sup>JET</sup> FBDK      MID <sup>SUB/</sup> COMP      TREBLE <sup>JET</sup> RATE      VOLUME <sub>GATE</sub>

NOISE GATE



Toe

Name/Description: **Overdrive**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE      BASS <sup>JET</sup> FBDK      MID <sup>SUB/</sup> COMP      TREBLE <sup>JET</sup> RATE      VOLUME <sub>GATE</sub>

NOISE GATE

Expression Pedal Position



Heel or Not Connected

Name/Description: **Classic Distortion**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE      BASS <sup>JET</sup> FBDK      MID <sup>SUB/</sup> COMP      TREBLE <sup>JET</sup> RATE      VOLUME <sub>GATE</sub>

NOISE GATE



Toe

Name/Description: **Classic Distortion**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE      BASS <sup>JET</sup> FBDK      MID <sup>SUB/</sup> COMP      TREBLE <sup>JET</sup> RATE      VOLUME <sub>GATE</sub>

NOISE GATE

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position




Heel or Not Connected


Name/Description: **Heavy Distortion**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION


FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP •




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE




VOLUME GATE

NOISE GATE


Name/Description: **Heavy Distortion**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION


FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP •




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE



VOLUME GATE

NOISE GATE



Toe

Expression Pedal Position




Heel or Not Connected


Name/Description: **Color Drive**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION


FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP •




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE



VOLUME GATE

NOISE GATE




Toe


Name/Description: **Color Drive**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION


FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP •




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE



VOLUME GATE

NOISE GATE

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position




Heel or Not Connected


Name/Description: **Buzz Saw**

FACIAL FUZZ JUMBO FUZZ  
 BUZZ SAW FUZZ PI  
 COLOR DRIVE  
 HEAVY DISTORTION JET FUZZ  
 CLASSIC DISTORTION LINE 6 DRIVE  
 OVERDRIVE LINE 6 DISTORTION  
 SCREAMER SUB OCTAVE FUZZ  
 TUBE DRIVE OCTAVE FUZZ  
 BOOST/COMP


DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup> <sub>FBDK</sub>



MID <sup>SUB/</sup> <sub>COMP</sub>



TREBLE <sup>JET</sup> <sub>RATE</sub>



VOLUME <sub>GATE</sub>

NOISE GATE

Expression Pedal Position




Heel or Not Connected


Name/Description: **Facial Fuzz**

FACIAL FUZZ JUMBO FUZZ  
 BUZZ SAW FUZZ PI  
 COLOR DRIVE  
 HEAVY DISTORTION JET FUZZ  
 CLASSIC DISTORTION LINE 6 DRIVE  
 OVERDRIVE LINE 6 DISTORTION  
 SCREAMER SUB OCTAVE FUZZ  
 TUBE DRIVE OCTAVE FUZZ  
 BOOST/COMP


DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup> <sub>FBDK</sub>



MID <sup>SUB/</sup> <sub>COMP</sub>



TREBLE <sup>JET</sup> <sub>RATE</sub>



VOLUME <sub>GATE</sub>


NOISE GATE

Toe


Name/Description: **Facial Fuzz**

FACIAL FUZZ JUMBO FUZZ  
 BUZZ SAW FUZZ PI  
 COLOR DRIVE  
 HEAVY DISTORTION JET FUZZ  
 CLASSIC DISTORTION LINE 6 DRIVE  
 OVERDRIVE LINE 6 DISTORTION  
 SCREAMER SUB OCTAVE FUZZ  
 TUBE DRIVE OCTAVE FUZZ  
 BOOST/COMP


DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup> <sub>FBDK</sub>



MID <sup>SUB/</sup> <sub>COMP</sub>



TREBLE <sup>JET</sup> <sub>RATE</sub>



VOLUME <sub>GATE</sub>

NOISE GATE

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position



Heel or Not Connected

Name/Description: **Jumbo Fuzz**

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sup>GATE</sup>

NOISE GATE



Toe

Name/Description: **Jumbo Fuzz**

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sup>GATE</sup>

NOISE GATE

Expression Pedal Position



Heel or Not Connected

Name/Description: **Fuzz Pi**

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sup>GATE</sup>

NOISE GATE



Toe

Name/Description: **Fuzz Pi**

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER • OCTAVE FUZZ  
 TUBE DRIVE • BOOST/COMP

DM4 Distortion Modeler PROGRAMMABLE OVERDRIVE & DISTORTION

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sup>GATE</sup>

NOISE GATE

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position




Heel or  
Not Connected


Name/Description: **Jet Fuzz**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup>FBDK



MID <sup>SUB/</sup>COMP



TREBLE <sup>JET</sup>RATE




VOLUME <sub>GATE</sub>

NOISE GATE


Name/Description: **Jet Fuzz**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup>FBDK



MID <sup>SUB/</sup>COMP



TREBLE <sup>JET</sup>RATE



VOLUME <sub>GATE</sub>

NOISE GATE



Toe

Expression Pedal Position




Heel or  
Not Connected


Name/Description: **Line 6 Drive**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup>FBDK



MID <sup>SUB/</sup>COMP



TREBLE <sup>JET</sup>RATE



VOLUME <sub>GATE</sub>

NOISE GATE




Toe


Name/Description: **Line 6 Drive**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS <sup>JET</sup>FBDK



MID <sup>SUB/</sup>COMP



TREBLE <sup>JET</sup>RATE



VOLUME <sub>GATE</sub>

NOISE GATE

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position




Heel or  
Not Connected


Name/Description: **Line 6 Distortion**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE




VOLUME GATE

NOISE GATE


Name/Description: **Line 6 Distortion**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE



VOLUME GATE

NOISE GATE



Toe

Expression Pedal Position




Heel or  
Not Connected


Name/Description: **Sub Octave Fuzz**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE




VOLUME GATE

NOISE GATE


Name/Description: **Sub Octave Fuzz**

FACIAL FUZZ • JUMBO FUZZ  
 BUZZ SAW • FUZZ PI  
 COLOR DRIVE • JET FUZZ  
 HEAVY DISTORTION • LINE 6 DRIVE  
 CLASSIC DISTORTION • LINE 6 DISTORTION  
 OVERDRIVE • SUB OCTAVE FUZZ  
 SCREAMER •  
 TUBE DRIVE • OCTAVE FUZZ  
 BOOST/COMP


**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION




DRIVE




BASS JET FBDK



MID SUB/COMP



TREBLE JET RATE



VOLUME GATE

NOISE GATE



Toe

# DM4 Distortion Modeler - Effect Presets Reference Guide

Expression Pedal Position



Heel or Not Connected

Name/Description: **Octave Fuzz**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

Facial Fuzz, Buzz Saw, Jumbo Fuzz, Color Drive, Heavy Distortion, Classic Distortion, Overdrive, Screamer, Tube Drive, Boost/Comp, Fuzz Pi, Jet Fuzz, Line 6 Drive, Line 6 Distortion, Sub Octave Fuzz, Octave Fuzz

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sub>GATE</sub>

NOISE GATE



Toe

Name/Description: **Octave Fuzz**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

Facial Fuzz, Buzz Saw, Jumbo Fuzz, Color Drive, Heavy Distortion, Classic Distortion, Overdrive, Screamer, Tube Drive, Boost/Comp, Fuzz Pi, Jet Fuzz, Line 6 Drive, Line 6 Distortion, Sub Octave Fuzz, Octave Fuzz

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sub>GATE</sub>

NOISE GATE

Expression Pedal Position



Heel or Not Connected

Name/Description: **Bias Tremolo**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

Facial Fuzz, Buzz Saw, Jumbo Fuzz, Color Drive, Heavy Distortion, Classic Distortion, Overdrive, Screamer, Tube Drive, Boost/Comp, Fuzz Pi, Jet Fuzz, Line 6 Drive, Line 6 Distortion, Sub Octave Fuzz, Octave Fuzz

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sub>GATE</sub>

NOISE GATE



Toe

Name/Description: **Bias Tremolo**

**DM4 Distortion Modeler** PROGRAMMABLE OVERDRIVE & DISTORTION

Facial Fuzz, Buzz Saw, Jumbo Fuzz, Color Drive, Heavy Distortion, Classic Distortion, Overdrive, Screamer, Tube Drive, Boost/Comp, Fuzz Pi, Jet Fuzz, Line 6 Drive, Line 6 Distortion, Sub Octave Fuzz, Octave Fuzz

DRIVE BASS <sup>JET</sup>FBDK MID <sup>SUB/</sup>COMP TREBLE <sup>JET</sup>RATE VOLUME <sub>GATE</sub>

NOISE GATE