

ZIKINF



OPTIONS



SPECIFICATIONS

| | SX-KN600 | SX-KN800 |
|-------------------------------|---|--------------------------------|
| Keyboard | 61 keys (touch sensitive keyboard) | |
| Sound Source | PCM | |
| Polyphonic | 16 | 23 |
| Presets Sounds | Poly 1/2, Accom 1/2/3: 96 sounds (48 switches x 2 variations) | |
| Tones | piano 1/2, e. grand, harpsichord, e. piano 1/2, guitar, jazz guitar, solid guitar, hawaiian guitar, mute guitar, rock guitar, harp, banjo, clavi, glocken, vibetone, chime, xylophone, steel drum, kalimba, pipe organ 1/2, jazz organ 1/2, pop organ 1/2, violin, strings, synth string, brass, trumpet, french horn, trombone, synth brass 1/2, accordion, tenor sax, alto sax, oboe, clarinet, harmonica, pan flute, flute, whistle, special 1/2/3 | |
| | Bass: 16 sounds (8 switches x 2 variations) | |
| | organ, tuba, acoustic, electric, chopper, special 1/2/3 | |
| Sound Edit | Parameter tone assign mode (normal, dual, duet, trio) • tone select • volume (level, key balance) • pitch (key shift, detune) • envelope (attack & decay, release) • vibrato (depth, speed, delay) • repeat (speed) • auto bend & trill (pattern, depth, speed) • pitch release (depth, time) • touch sense (volume, auto bend & trill) • glide (on/off), split-octave (on/off), sound name | |
| Effect | Sound Memory poly 1, 2, accomp 1, 2, 3: 16 memories • bass: 8 memories | |
| | Chorus on/off (poly 1/2, accomp 1/2/3) | |
| | Sustain on/off (poly 1/2, accomp 1/2/3, bass) | |
| Reverb | on/off (poly 1/2, accomp 1/2/3, bass, drums), type (room, hall, stage, cathedral, symphony hall, echo 1/2/3), total on/off, depth, user 1-4 (decay, echo-time) | |
| Modulation | vibrato on/off | |
| Pitch Bend | ○ (pitch bend wheel) ±200 cent | |
| Transpose | ○ | |
| Techni-Chord | ○ | |
| BGS | thunder bird, windchimes, special 1/2, wind, stream, wave, church bell, fade-out | |
| Pattern | march, polka, country, waltz, tango, latin, samba, bossanova, swing, dixie, jazz waltz, shuffle, rock ballad, swing rock, samba rock, latin rock, 8 beat 1/2, rock'n'roll, 16 beat 1/2, jazz rock, funk, disco | |
| Rhythm | start/stop, synchro & break, fill-in, intro & ending, tempo | |
| | Manual Percussion pad 1, 2, 3 | |
| | Keyboard Percussion 36 | |
| | Auto Play Chord 48 | |
| Arranger | fingered, one-finger, memory accomp 1, 2 & 3, drums, variation ○ (one touch playstyle select) | |
| One Touch Play | set, 1-8 | |
| Memory Functions | Panel Memory Composer 5 tracks (part: accomp 1, 2 & 3, bass, drums), memory... 1-8 • input mode... real time, step • editing functions... copy, recording chord select • resolution... real time; J -1/96, step; J -1/32 | |
| | Sequencer 8 tracks (part: poly 1/2, bass, accomp 1/chord, accomp 2, 3, drums, control) • input mode... real time, step • editing functions... punch-in/out, track assign, song all clear, track clear, track merge, measure delete, measure erase, measure insert, measure copy, velocity change, quantize • resolution... real time; J -1/96, step; J -1/32 • 3 demonstration songs | |
| Musical Director | liquid crystal display (20 letters x 2 lines) | |
| Controls | shift, page Δ, ▽, balance Δ, ▽, conductor (poly 1, 2, bass, keyboard percussion), tempo/program dial, key split | |
| MIDI | part (poly 1/2, accomp 1/2/3, bass, drums, control) • available channels 1-16 • MIDI input select (conductor/direct) • MIDI output select (ACMP APC/chord, Techni-Chord on/off) • MIDI function select COMMON: (initial, note only, transpose oct., program change mode, song select, real time command, MIDI clock, MIDI data load), PART: (octave shift, panel memory program change, program change, sustain, pitch bend, modulation, volume, chorus, expression, intro) | |
| External Memory | memory card (SY-P5, optional), digital disk recorder (SY-FD20, optional), digital memory disk (SY-D20, optional) | |
| Terminals | headphone, line out (R/R+L, L), line in (R/R+L, L), MIDI (IN, OUT, THRU), foot switch, foot controller | |
| Others | power switch, main volume, memory card slot | |
| Output | 10W x 2 | |
| Speakers | 16cm (6 1/4") x 2 | |
| Power Requirement | 70W, AC 120/220/240V, 50/60Hz | |
| Dimensions (W x H x D) | 103.2 x 13.2 x 35.7cm | (40 1/4" x 5 1/16" x 14 1/16") |
| Net Weight | 11.2kg (24.7 lbs.) | 11.4kg (25.1 lbs.) |
| Accessories | music rack, AC cord, dust cover | |

Technics
Matsushita Electric