





# YSM1P

active studio monitor



#	Part#	Description
<b>Labeled Components</b>		
1	YSM1PTWTR	1" TWEETER WITH BUCKING MAGNET
2	YSM1PWFR	6.5 INCH WOOFER W/BUCKING MAGNET
3a	8255D	Y LOGO YSM1P BLUE SMALL DOMED
3b	8256D	YSM1P LEFT ACTIVE LED LOGO DOMED
3c	8257D	YSM1P RIGHT ACTIVE LED LOGO DOMED
4	YSM1IGAS	DRESS GASKET FOR YSM1I AND YSM1P
5	3425	DPDT PUSH SW PCMT MAKE B4 BREAK
6	8636	BUTTON KNOB FLAT BLACK
7	3396	4POSITION DIP SW KAP1104E
8	4497	_10K B LIN 9MM HORIZONTAL P29
9	3645	AC SOCKET RECEPTACLE WITH 0.250 TAB
10	3698	SPST ROKR SW QUIK 180" AC PWR BL/BL
11	3445	1/4"&XLR PCB MT HORZ COMBO
12	3428	8' 3/18 SJT AC LINE CORD REMOVABLE
15		
16		
17		
18		
19		
20		
21		
22		



\*NOTE: Replacement grills & HF Driver supports are 'Special-Order' and are only available while the model is in production.

‡ Grilles & Support replacements are for CURRENT models only.

\*\* Internal Lightbulb not shown

**Real Gear.  
Real People.**