

In uses the unit before, please read the instruction manual carefully and keep the instruction manual properly in order to need in future.

Preface

Thank you for choosing our multi-channel microphone products. In order to guarantee you use this products well, please read this instruction booklet carefully before using, understood correct operating procedures, to obtain the best effect.

Security and Environment

- 1. Keep the facility under cool condition, and do not put this machine in the site which is high temperature, moist, dusty or close to liquid stuff.
- 2. Do not open the machine in case Fire, electric shock risk.
- 3. Only can use the power adapter which the machine offers and confirm whether the working power voltage is fit for adapter access specification. It may be damage if using adapter that supply by other distributor.
- 4. Turn off the machine and pull out the adapter when you leave for long time.

Product presentation

- 1. This wireless Ear-monitor System is used in stage performance and sound broadcast which can replace traditional complex sound monitoring equipment, achieve admirable listening effect.
- 2. With using the latest high frequency transmission and audio signal dynamic processing technology, also improve the signal—to—noise ratio of the dynamic range so that the system has the best anti–interference to show the perfect original sound again.

Main features


- UHF band Phase lock PLL
- Among the band of 32MHz, the preset 40 frequencies can be arbitrary switching
- Dynamic expansion circuit, greatly improve signal-to-noise ratio
- Elegant liquid crystal display panel
- With power and RF receiving indecator lamp
- With using two No. 5 batteries and efficient power circuit, long service time
- Metal housing, sturdy and durable
- The transmitter adopts balanced and unbalanced sharing socket
- The transmitter is with output monitoring phone jack

Main function

The system consists of a mini receiver and transimtter combination, and its main funtion and characteristics are described below:


- Among the band of 32MHz, you can preset 40 frequencies which can be arbitrary switching.
- With using advanced circuit design, clear the receiving blind angle to make the system's receiving signal steady. The system is strong resistance to fall because of the housing is made by tough metal material. It is the best choice of stage performance monitor product.

The front panel instruction of single channel receiver



- 1. Power switch
- 2. Function setting key: choose the function of setting
- 3. LCD display: show the operation of each item and setting the content
- 4. USB function setting key: adjusted the function of USB play, volume control etc.
- 5. Earphone volume potentiometer: adjusted the volume of earphone
- 6. 6.3 earphone output socket: connecting the stereo earphone, monitoring the output signal
- 7. USB socket: connecting USB disk, MP3 audio frequency input
- 8. USB indicate light: to indicate the working condition of USB disk


The back side panel instruction of single channel receiver




- 1. Antenna
- 2. Right channel potentiometer: adjusted volume
- 3. Left channel potentiometer: adjusted volume
- 4. Right channel output: can use balanced and unbalanced
- 5. Left channel output: can use balanced and unbalanced
- 6. DC power: connecting 12V DC power input socket, the voltage of the outlet center is positive voltage

The instruction way to use single channel transmitter


- 1.Turn on / off: long press the button "POWER"
- 2.Group choosing : ① pressed " \bigcirc ", ② turned " \bigcirc " to left or right to choose the frequency range you need.
- 3.Channel choosing: ① pressed 2X " 🌷 ", ② turned " 💍 " to left or right to choose the frequency range you need.






- 4. USB using method:
- ①Start/pause USB: insert USB or MP3, pressed " To " lightly
- ②Choose music: turned " " to left or right to choose last or next song
- ③Adjusted USB volume: turned " " to left or right to decrease or increase volume.

Single Channel Desktop Transmitter Front View




- 1. 6.35mm headphone output: connect stereo headphone, monitor output signal
- 2. Headphone volume potentiometer: adjust stereo headphone volume
- 3. SET seletion: choose setting function
- 4. LED: display operation and content
- 5. DOWN selection: choose setting function
- 6. Power switch: turn on/turn off

Single Channel Desktop Transmitter Front View




- DC power socket: connect with 12V DC power input socket, the socket center connect positive voltage
- 2. The left channel: balanced and unbalanced sharing input
- 3. The right channel: balanced and unbalanced sharing input
- 4. Left volume adjustment potentiometer
- 5. Right volume control potentiometer
- 6. Antenna

Double Channel Desktop Transmitter Front View




- 1. 6.35mm headphone output: connect stereo headphone, monitor output signal
- 2. Headphone volume potentiometer: adjust stereo headphone volume
- 3. SET seletion: choose setting function
- 4. LED: display operation and content
- 5. DOWN selection: choose setting function
- 6. Power switch: turn on/turn off

Double Channel Desktop Transmitter Front View




- 7. DC power socket: connect with 12V DC power input socket, the socket center connect positive voltage
- 8. The left channel: balanced and unbalanced sharing input
- 9. The right channel: balanced and unbalanced sharing input
- 10. Left volume adjustment potentiometer
- 11. Right volume control potentiometer
- 12. Antenna

Bodypack Transmitter




- 1. LED: Display working content
- 2. UP selection: choose setting function
- 3. DOWN selection: choose setting function
- 4. SET seletion: choose setting function
- 5. Power switch: turn on/turn off
- 6. Battery warehouse: after inserting two number 5 batteries, cover it
- 7. low voltage indicator lamp:batteries work out
- 8. Volume peak indicator light
- 9. Mic input in
- 10. Mute switch
- 11. Antenna

Bodypack Receiver



- 1. LED: Display working content
- 2. UP selection: choose setting function
- 3. DOWN selection: choose setting function
- 4. SET seletion: choose setting function
- 5. Power switch: turn on/turn off
- 6. Battery warehouse: after inserting two number 5 batteries, cover it
- 7. low voltage indicator lamp:batteries work out
- 8. RF indicator light: indicate receiving signal information
- 9. Power switch + volume potentiometer: turn on or turn off and adjust volume
- 10. 3.5mm headphone output: connect headphone
- 11. Antenna: assemble fixed antenna

Usage illustration instruction



System settings


Desktop Ttransmitter Settings

- 1. Turn on/Turn off: long press POWER button
- 2. Group selection: 1 SET or press 2 Reverse 1 to the left or right
- 3. Channel selection: 1) 2xSET or press 2x 2 Reverse to the left or right

Group

B.CH


AF



Bodypack Ttransmitter Settings

- 1. Turn on/Turn off:long press ON/OFF
- 2. Group seletion: (1)SET (2) / (4)
- 3. Channel seletion: 12xSET 2 ♥/♠

Group



Bodypack Receiver Settings

1.Turn on/Turn off:


Rotate volume potentiometer





- 2.Group selection: ①SET ② 🐨 / 🖺 ③ ESC
- 3.Channel selection: ① 2xSET ② ♥/▲ ③ ESC

Group
H.E



Technical Data

standard 1U Transmitter
metal panel
PLL synthesized
±0.005%
UHF798~830MHz
32MHz
40 channels separately set 4groups
manual adjust
± 48KHz
50Hz~15KHz±3dB
100mW(50Ω)
<4NW
XLR, ϕ 6.35mmjack
φ 6.35mm stereophonic socket
≥16Ω
DC 12V/250mA
TNC socket (50Ω)

Oscillation mode: PLL synthesized Receiver
Frequency stability: ±0.005%
Frequency range: UHF798~830MHz
Frequency interval: 32MHz
Preset Channel: 40channels separately set 4 groups
Operate mode: manual adjust
Receiving mode: single tuning
Sensitivity: deviation 25 KHz, with connecting 7dBuV, S/N>78dB
Max Deviation: ±48KHz
Comprehensive S/N ratio: >94 db (1KHZ-A)
Comprehensive T.H.D: <3%@1KHz
Frequency response: 80Hz~15KHz ± 3dB
Output power (32Ω): 2X35mw@1KHZ
Earphone load impedance: ≥16Ω
Output socket: \$\phi 3.5mm stereo earphone socket
Volume output adjusts: adjust when using
Power box: batteries AAX2
Current drain: 3V/120mA(Under the mediant degrees of the
volume control)
Antenna: fixed 1 / 2 λ

IN-EAR MONITOR SYSTEMS

The specification won't do and further notice for the improvement Actual product will not be as pictured